


Field Modification Kits

Pilot Devices

• Revised •
07/20/15

Selection

Push Buttons and Selector Switches	Class	Enclosure Type	Controller Size or (Lighting Rating)	Type	Catalog Number	List Price \$	
 49SBPB5  49SBSB1  49SAP05  49SAS01	14, 40, LC, LEN, CLM [Ⓛ]	Open	00-4	Start, Stop Push Buttons	49SAPB5		
		1	00-4 or (20–100A)	Hand-Off-Auto Selector Switch	49SASB1		
				Off-On Selector Switch	49SASB4		
				Start, Stop Push Buttons	49SBPB5		
				Hand-Off-Auto Selector Switch	49SBSB1		
			5-8 or (200–400A)	Off-On Selector Switch	49SBSB4		
				Start, Stop Push Buttons	49SAP05		
			12, 4/4X	00-8 or (20–400A)	Hand-Off-Auto Selector Switch	49SAS01	
					Keyed Hand-Off-Auto (key removable in all positions)	49SAS09	
		Off-On Selector Switch			49SAS04		
		Start, Stop Push Buttons			49SAP05		
		22, 43	Open	00-4	Forward-Off-Reverse Selector Switch	49SASB2	
1	00-4		Forward-Off-Reverse Selector Switch	49SBSB2			
	5-8		Forward, Reverse, Stop Push Buttons	49SAP02			
			Forward-Off-Reverse Selector Switch	49SAS02			
	12, 4/4X		0-8	Forward, Reverse, Stop Push Buttons	49SAP02		
Forward-Off-Reverse Selector Switch				49SAS02			
30 (2S1W)	Open		0-4	High-Off-Low Selector Switch	49SASB3		
	1		0-1 ¾	High-Off-Low Selector Switch	49SBSB3		
			2-4	High, Low, Stop Push Buttons	49SAP03		
				High-Off-Low Selector Switch	49SAS03		
			12, 4/4X	0-4	High, Low, Stop Push Buttons	49SAP03	
	High-Off-Low Selector Switch				49SAS03		
	30 (2S2W)	Open	0-4	High-Off-Low Selector Switch	49SASB3		
		1	0-4	High-Off-Low Selector Switch	49SBSB3		
		12, 4/4X	0-4	High, Low, Stop Push Buttons	49SAP03		
				High-Off-Low Selector Switch	49SAS03		
		1, 12, 4/4X	0-8 (20-400A)	Start, Stop Push Buttons	49SAP05		
				Hand-Off-Auto Selector Switch	49SAS01		
Keyed Hand-Off-Auto (key removable in all positions)	49SAS09						
Off-On Selector Switch	49SAS04						
Forward, Reverse, Stop Push Buttons	49SAP02						
Forward-Off-Reverse Selector Switch	49SAS02						
25, 26	1, 12, 4/4X	0-8	High, Low, Stop Push Buttons	49SAP03			
			32	1, 12, 4/4X	0-4	High, Low, Stop Push Buttons	49SAP03

① To be used for replacement of switch only. Does not include relay or extra contact block on 30-400A CLM and CM Lighting Contactors. Class 49SB not available for these devices.