

OPERATING INSTRUCTIONS FOR STREAMLIGHT PRO TAC® HL

WARNING:

Use of light in "strobe" mode may cause seizure in persons with photosensitive epilepsy.

WARNING:

FIRE, EXPLOSION, BURN HAZARD - USE ONLY RECOMMENDED LITHIUM BATTERIES

Inferior quality lithium batteries can cause fire, explosion, burns. We recommend the use of **ONLY** Streamlight or Panasonic, Sanyo, Energizer or Duracell batteries in our products. Use of other batteries or mixing brands and old and new batteries may risk leakage, fire, explosion and serious personal injury. To further avoid this risk for any brand lithium battery, do not recharge, misuse, short circuit, disassemble, improperly store or discard, expose to high temperatures.

**CAUTION: LED RADIATION;
(RG-2)
DO NOT STARE INTO BEAM,
MAY BE HARMFUL TO EYES.**

BATTERY INSTALLATION/REMOVAL

- Unscrew the tail cap (and remove depleted batteries).
- Insert batteries positive end first.
- Screw tail cap onto flashlight barrel and tighten.

GENERAL OPERATION

The ProTac® HL features a programmable switch with momentary operation (light press or tap) and constant on operation (press until click). The light is shipped from the factory in the default Hi-Strobe-Lo program.

- **High:** Tap and hold; click to lock on; click again for off.
- **Strobe:** Fast double tap (within 0.4 seconds) and hold; click to lock on; click again for off.
- **Low:** Fast triple tap (within 0.4 seconds per tap) and hold; click to lock on; click again for off.

Accessing Other Programs

The ProTac® HL features a TEN-TAP™ programmable switch allowing the user to select one of three different programs. To change to the next program, tap the switch rapidly 9 times (within 0.4 seconds per tap) and hold it down the 10th time. Continue holding the switch until the light turns off (approximately 1 second), then release the switch.

Available programs are **Hi-Strobe-Lo** (Factory Default), **Hi Only** or **Lo-Hi**.

Streamlight's Limited Lifetime Warranty

Streamlight warrants this product to be free of defects for a lifetime of use except for batteries and bulbs, abuse and normal wear. We will repair, replace or refund the purchase price of this product should we determine it to be defective. This limited lifetime warranty also excludes rechargeable batteries, chargers, switches and electronics which have a 2 year warranty with proof of purchase. **THIS IS THE ONLY WARRANTY, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARE EXPRESSLY DISCLAIMED EXCEPT WHERE SUCH LIMITATION IS PROHIBITED BY LAW.** You may have other specific legal rights which vary by jurisdiction.

Go to www.streamlight.com/support for a complete copy of the warranty, and information on product registration and the location of authorized service centers. Retain your receipt for proof of purchase.

MAINTENANCE AND SERVICE

It is important to keep the O-ring on the tail cap lubricated.
Streamlight recommends the factory or authorized service centers for any repairs.

Contact us at:

Customer Service
STREAMLIGHT, INC.
30 Eagleville Road
Suite 100
Eagleville, PA U.S.A. 19403-3996
Phone: (800) 523-7488 Toll-Free
Fax: (800) 220-7007
997659www.streamlight.com