
# Raychem<sup>®</sup>

## H910

### WinterGard® Splice and Tee Kit with End Seal



#### **Approvals**





718K Pipe Heating Cable or 877Z De-icing and Snow Melting Equipment

#### **Installation Instructions**

#### Description

The WinterGard® H910 Splice and Tee Kit is for use with WinterGard self-regulating heating cables to make splice, tee, and end seal connections. The kit contains materials for one splice and one end seal, or one tee connection and one end seal. This kit does not provide a power connection; use an H900 or H908 power connection kit for a complete installation.

#### **Applications**

Use the H910 kit with the following WinterGard heating cables: H311, H611, H612, H621, and H622. All are designed for pipe freeze protection in dry locations, but H612 and H622 cables are designed for both wet and dry areas, as well as for roof and gutter de-icing. The cable type is printed on the outer jacket of the cable.


#### **Tools Required**

- · Diagonal Cutters
- · Needle nose pliers
- Utility knife
- · Heat gun or torch
- Crimp tools (Ideal 30-425 and T&B WT112M or WT2000)
- Hammer and nail (for gutter/downspout applications only)

#### **Installation and Support**

The minimum installation temperature for this kit is 0°F (-18°C). See the WinterGard Application and Design Guide (H53585), H900, or H908 installation instructions for design information. For additional technical support call Tyco Thermal Controls at (800) 545-6258.

#### **Kit Contents:** Item Description Insulated bus wire crimps В Uninsulated braid crimps 3 С Cable ties D 6 Mastic strips Heat-shrinkable cap Heat-shrinkable tube (6" long, 1" dia.) Black cloth tape (6" long) G Clamp tie End seal



#### **!** WARNING:


This component is an electrical device that must be installed correctly to ensure proper operation and to prevent shock or fire. Read these important warnings and carefully follow all the installation instructions.


- To minimize the danger of fire from sustained electrical arcing if the heating cable is damaged or improperly installed, and to comply with the requirements of Tyco Thermal Controls, agency certifications, and national electrical codes, groundfault equipment protection must be used. Arcing may not be stopped by conventional circuit breakers.
- Bus wires will short if they contact each other. Keep bus wires separated.


- Keep components and heating cable ends dry before and during installation.
- The black heating cable core is conductive and can short. It must be properly insulated and kept dry.
- Component approvals and performance are based on the use of Tyco Thermal Controls-specified parts only.
   Do not use substitute parts or vinyl electrical tape.
- Leave these instructions with end user for reference and future use.


## **Splice or Tee Connections**

The instructions are shown for a tee connection. Splice connections are done the same way, without the third heating cable section.














- · Position braid on same side of each heating cable section.
- Straighten the braid and twist into a "pigtail".









































## End Seal Installation Instructions for H612 and H622 Heating Cables

Note: The end seal is designed to be installed only once. It cannot be removed from the heating cable once it is installed. Do not install it until instructed to do so in Step 3









## End Seal Installation Instructions for H311, H611 and H621 Heating Cables

Note: The end seal is designed to be installed only once. It cannot be removed from the heating cable once it is installed. Do not install it until instructed to do so in Step 3





Firmly push end seal onto the cable (at least 1½ inch). Some gel may ooze out.
Do not twist or try to remove the end seal during or after insertion.
Do not reuse an end seal.

Slide the braid up against the end seal and secure with the 6-inch length of tape provided.

#### Worldwide Corporate Headquarters Tyco Thermal Controls

2415 Bay Road Redwood City, CA 94063-3032

Tel: (800) 545-6258
Tel: (650) 216-1526
Fax: (800) 527-5703
Fax: (650) 474-7711
info@tycothermal.com
www.tycothermal.com

#### Canada Tvco Thermal Controls

250 West St. Trenton, Ontario Canada K8V 5S2 Tel: (800) 545-6258 Fax: (800) 527-5703 Important: All information, including illustrations, is believed to be reliable. Users, however, should independently evaluate the suitability of each product for their particular application. Tyco Thermal Controls makes no warranties as to the accuracy or completeness of the information, and disclaims any liability regarding its use. Tyco Thermal Controls' only obligations are those in the Tyco Thermal Controls Standard Terms and Conditions of Sale for this product, and in no case will Tyco Thermal Controls or its distributors be liable for any incidental, indirect, or consequential damages arising from the sale, resale, use, or misuse of the product. Specifications are subject to change without notice. In addition, Tyco Thermal Controls reserves the right to make changes — without notification to Buyer — to processing or materials that do not affect compliance with any applicable specification.

Tyco, Raychem and WinterGard are trademarks of Tyco Thermal Controls LLC or its affiliates.