## **Protection Equipment**



#### Price groups

PG 140, 41B, 41E, 41F, 41G, 41H, 41J, 42F, 42J

#### 7/2 Introduction

#### Motor starter protectors/ circuit breakers

SIRIUS 3RV2 motor starter protectors/circuit breakers up to 80 A

7/7 General data

7/21 For motor protection **NEW** 

For motor protection with overload relay function **NEW** 

26 For starter combinations **NEW** 

7/28 For transformer protection **NEW** 

7/29 For system protection according to UL 489/CSA C22.2 No. 5 NEW

7/30 For transformer protection according to UL 489/CSA C22.2 No.5 NEW

Accessories

7/31 - Mountable accessories

7/34 - Busbar accessories

7/37 - Rotary operating mechanisms

7/38 - Mounting accessories

7/43 - Enclosures and front plates

7/46 3RV29 infeed system

SIRIUS 3RV1 motor starter protectors/circuit breakers up to 100 A

7/51 General data

7/63 For motor protection

7/64 For motor protection with overload relay function

7/65 For starter combinations

7/66 For fuse monitoring

7/67 For system protection according to

UL 489/CSA C22.2 No. 5

7/68 For distance protection

Accessories

7/69 - Mountable accessories

7/72 - Busbar accessories

7/73 - Rotary operating mechanisms

7/75 - Mounting accessories

777 - Front plates

SIRIUS 3RV1 molded case motor starter

protectors up to 800 A

7/78 General data

7/83 For motor protection

7/84 For starter combinations

Accessories

7/85 - Mountable accessories7/86 - Rotary operating mecha

- Rotary operating mechanisms, mounting accessories

NEW

Click on the Article No. in the catalog PDF to access it in the Industry Mall and get all related information.

#### Article-No.



Or directly in the Internet, e. g. www.siemens.com/product?3RA1943-2C

## Overload relays

7/87 General data

SIRIUS 3RU2

thermal overload relays

7/95 3RU2 up to 80 A

for standard applications **NEW** 

7/103 Accessories

7/106

SIRIUS 3RU1

thermal overload relays
3RU11 up to 100 A
for standard applications

7/112 Accessories

SIRIUS 3RB3

electronic overload relays

7/114 3RB30, 3RB31 up to 80 A for standard applications **NEW** 

7/122 Accessories

SIRIUS 3RB2 electronic overload relays

7/124 3RB20, 3RB21 up to 630 A for standard applications

7/133 Accessories for 3RB20, 3RB21

7/135 3RB22, 3RB23 up to 630 A for High-Feature applications

7/143 3RB24 for IO-Link, up to 630 A for High-Feature applications

7/150 Current measuring modules for 3RB22, 3RB23, 3RB24

7/153 Accessories for 3RB22, 3RB23, 3RB24

Notes:

The 3RV1, 3RU1 and 3RB2 devices (sizes S00/S0 to S12) can be found

- in the Catalog Add-On IC 10 AO · 2015 at the Information and Download Center
- in the interactive catalog CA 01
- in the Industry Mall

Conversion tool, e.g. from

- 3RV1 to 3RV2
- 3RU11 to 3RU21
- 3RB20/3RB21 to 3RB30/3RB31

see

www.siemens.com/sirius/conversion-tool

## **Protection Equipment**

## Motor Starter Protectors/Circuit Breakers

### Introduction

#### Overview













Туре		3RV20 3RV21		21		3RV2	23		3RV2	24		3RV2	27	3RV2	28		
SIRIUS 3RV2 motor starte	r pro	tecto	rs/c	ircuit brea	kers	up t	o 80 A										
Applications																	
System protection		<b>√</b> 1)			<b>√</b> <sup>1)</sup>									1		/	
Motor protection		/															
Motor protection with overload relay function	t				1												
Starter combinations								1									
<ul> <li>Transformer protection</li> </ul>											/			/		/	
Size		S00,	S0, S	2	S00,	S0, S	62	S00,	S0, 5	32	S00,	S0, 5	S2	S00,	S0	S00,	S0
Rated current I <sub>n</sub>																	
<ul><li>Size S00</li><li>Size S0</li><li>Size S2</li></ul>	A A A	Up to Up to Up to	40		Up to Up to Up to	32		Up to Up to Up to	40		Up to Up to Up to	25		Up to Up to		Up to Up to	
Rated operational voltage $U_{\rm e}$ according to IEC	V	690 /	4C <sup>2)</sup>		690 A	4C <sup>2)</sup>		690 /	AC <sup>2)</sup>		690 /	4C <sup>2)</sup>		690 A	AC	690 A	AC
Rated frequency	Hz	50/60	)		50/60	)		50/60	)		50/60	)		50/60	)	50/60	)
Trip class		CLAS CLAS		(S00 S2), (S2)	CLAS	SS 10	)				CLAS	SS 10	)				
Thermal overload releases	A A		70 80		0.11 0.16 up to 70 80			None	e <sup>3)</sup>		0.11 54		16 up to	0.16 Non-	22 adjustable	0.16 Non-	22 adjustable
Electronic release A multiple of the rated current				13 times		13 tir	nes		20 tir	nes		13 tir	nes	20 tir	nes		
Short-circuit breaking capacity I <sub>cu</sub> at 400 V AC	kA	20/55			55/65/100		20/5	5/65/	100	55/6	5/100	)	4)		4)		
Pages		7/21	7/2	23	7/25			7/26,	7/27	7	7/28			7/29		7/30	
Accessories																	
For sizes		S00	S0	S2	S00	S0	S2	S00	S0	S2	S00	S0	S2	S00	S0	S00	S0
Auxiliary switches		/	1	1	/	/	/	/	/	/	/	/	1	/	1	/	✓
Signaling switches		/	1	✓	1	/	✓	1	/	✓	1	/	1				
Undervoltage releases		/	1	✓				/	/	/	/	/	1	1	1	1	✓
Shunt releases		/	1	✓				✓	✓	✓	/	✓	✓	/	✓	/	✓
Isolator modules		/	1	✓	/	1	✓	1	✓	✓	/	✓	✓				
Insulated three-phase busbar system		1	/	✓				✓	✓	✓	✓	1	✓				
Busbar adapters		✓	1	✓	1	✓	✓	✓	✓	✓	✓	✓	✓				
Door-coupling rotary operating mechanisms		1	1	✓	✓	/	✓	1	1	1	1	1	1	✓	✓	1	✓
Link modules		✓	1	✓	1	✓	✓	1	1	✓	✓	1	✓				
Enclosures for surface mounting		✓	1	✓	1	✓	✓	✓	✓	✓	1	✓	✓				
Enclosures for flush mounting		✓	1		1	✓		1	1		✓	1					
Front plates		/	1	✓	1	✓	/	✓	✓	✓	1	✓	1				
Infeed system		/	✓					✓	✓		✓	✓					
Terminal covers for ring termina lug connections	l	<b>√</b> <sup>5)</sup>	<b>√</b> 5)										-				
Sealable scale covers for setting knobs	9	1	1	✓	✓	/	✓				1	1	1				
Pages		7/31	7/5	50													

<sup>✓</sup> Has this function or can use this accessory

<sup>--</sup> Does not have this function or cannot use this accessory

<sup>1)</sup> For symmetrical loading of the three phases.

With molded-plastic enclosure 500 V AC. For DC applications, see "Technical Specifications" — "DC Short-Circuit Breaking Capacity", page 7/16.

<sup>3)</sup> For overload protection of the motors, appropriate overload relays must be used.

<sup>&</sup>lt;sup>4)</sup> According to UL 489 at 480 Y/277 V AC: 65 kA or 50 kA.

<sup>5)</sup> Terminal covers are available for 3RV20 motor starter protectors with ring terminal lug connection to ensure finger-safety.

# **Protection Equipment**Motor Starter Protectors/Circuit Breakers

## <u>Intro</u>duction













		12	0 0		45 45		
Туре		3RV10	3RV11	3RV13	3RV16	3RV16	3RV17
SIRIUS 3RV1 motor sta	rte	r protectors/circ	uit breakers up to	100 A			
Applications							
<ul> <li>System protection</li> </ul>		<b>✓</b> <sup>1)</sup>	<b>√</b> <sup>1)</sup>				✓
<ul> <li>Motor protection</li> </ul>		1					
<ul> <li>Motor protection with overload relay function</li> </ul>			1				
<ul> <li>Starter combinations</li> </ul>				✓			
<ul> <li>Transformer protection</li> </ul>							✓
<ul> <li>Fuse monitoring</li> </ul>					✓		
<ul> <li>Voltage transformer circuit breakers for distance protection</li> </ul>						✓	
Size		S3	S3	S3	S00	S00	S3
Rated current In							
• Size S00	Α				0.2	Up to 3	
• Size S3		Up to 100	Up to 100	Up to 100			Up to 70
Rated operational voltage $U_{\rm e}$ according to IEC	٧	690 AC <sup>2)</sup>	690 AC <sup>2)</sup>	690 AC <sup>2)</sup>	690 AC <sup>2)</sup>	400 AC	690 AC
Rated frequency	Hz	50/60	50/60	50/60	50/60	16 <sup>2</sup> / <sub>3</sub> 60	50/60
Trip class		CLASS 10, 20	CLASS 10				
Thermal overload releases	A	11 16 up to 80 100	11 16 up to 80 100	Without <sup>3)</sup>	0.2	1.4 3	10 70 non-adjustable
Electronic release A multiple of the rated current		13 times	13 times	13 times	6 times	4 7 times	13 times
Short-circuit breaking capacity I <sub>cu</sub> at 400 V AC	kΑ	50/100	50/100	50/100	100	50	4)
Pages		7/63	7/64	7/65	7/66	7/68	7/67
Accessories							
For sizes		S3	S3	S3	S00	S00	S3
Auxiliary switches		1	/	1	✓	1	<b>√</b> <sup>5)</sup>
Signaling switches		/	/	✓			
Undervoltage releases		✓		✓			✓
Shunt releases		✓		✓			✓
Busbar adapters		✓	✓	✓			
Door-coupling rotary operating mechanisms		✓	✓	✓			✓
Remote motorized operating mechanisms		✓	✓	✓			
Link modules		✓	✓	✓			
Front plates		✓	✓	✓			

✓ Has this function or can use this accessory

Pages

-- Does not have this function or cannot use this accessory

7/69 ... 7/77

- 1) For symmetrical loading of the three phases.
- 2) With molded-plastic enclosure 500 V AC. For DC applications, see "Technical Specifications" 

  "DC Short-Circuit Breaking Capacity", page 7/58.
- $^{\rm 3)}$  For overload protection of the motors, appropriate overload relays must be used.
- Acc. to UL 489At 480 Y/277 V AC: 65 kA
  - At 480 V AC: 65 kA (10 A to 30 A)
- <sup>5)</sup> Only lateral auxiliary switches can be fitted.

# Protection Equipment Motor Starter Protectors/Circuit Breakers

## Introduction





Type	3RV10			3RV13					
SIRIUS 3RV1 molded cas	se motor st	arter protect	ors up to 800	) A					
Applications									
<ul> <li>Motor protection</li> </ul>	✓								
Starter combinations				1					
Switching capacity	Standard	switching capa	city	Standard swit	ching capacit	ty		Increased so capacity	witching
Size	3RV1063	3RV1073	3RV1083	3RV1353	3RV1363	3RV1373	3RV1383	3RV1364	3RV1374
Rated current I <sub>n</sub>	100 200	400	630	1 32	100 250	400, 630	630, 800	100 250	400
Rated operational voltage VUe according to IEC	690 AC			690 AC					
Rated frequency	lz 50/60			50/60					
Trip class	CLASS 10	A, 10, 20, 30		1)					
Thermal overload releases A				Without <sup>1)</sup>					
Electronic release A multiple of the rated current	Adjustable	e, 6 13 times		Non-adjustable 1 12.5 A: 13 times; Adjustable 20 A, 32 A: 6 12 times	1 10 times	3			
Short-circuit breaking k capacity I <sub>cu</sub> at 400 V AC	A 120	120	100	85	120	120	100	200	200
Trip unit (release)	TU 4			TU 1: 1 12.5 A; TU 2: 20 A, 32 A	TU 3				
Pages	7/83			7/84					
Accessories									

Accessories									
For molded case motor starter protectors	3RV1063	3RV1073	3RV1083	3RV1353	3RV1363	3RV1373	3RV1383	3RV1364	3RV1374
Auxiliary switches	✓	✓	1	1	✓	✓	✓	✓	✓
Undervoltage releases	✓	✓	1	1	✓	1	✓	✓	✓
Shunt releases	✓	✓	1	1	1	1	1	✓	1
Rotary operating mechanisms	✓	1	✓	✓	1	1	1	1	✓
Connection methods • Extended terminals on the front • Cable terminals on the front	√ √	✓ ✓	 •	✓ ✓	/ /	✓ ✓	 ⁄	/ /	✓ ✓
Rear terminals	✓	✓	✓	✓	✓	✓	✓	✓	✓
Pages	7/85, 7/86								

<sup>✓</sup> Has this function or can use this accessory

<sup>--</sup> Does not have this function or cannot use this accessory

<sup>1)</sup> For overload protection of the motors, appropriate overload relays must be

## Protection Equipment Overload Relays

Introduction







Туре		3RU2	1		3RB3	0		3RB3	1		
SIRIUS overload relays up to 8	0 A										
Applications											
System protection		<b>√</b> 1)			<b>√</b> 1)			<b>√</b> 1)			
Motor protection		1			✓			✓			
Alternating current, three-phase		✓			1			1			
Alternating current, single-phase		1									
Direct current		✓									
Size contactor		S00, S	30, S2		S00, S	S0, S2		S00, S	30, S2		
Rated operational current I <sub>e</sub>											
• Size S00	Α	Up to	16		Up to	16		Up to	16		
• Size S0	Α	Up to	40		Up to	40		Up to	40		
• Size S2	Α	Up to	80		Up to	80		Up to	80		
Rated operational voltage U <sub>e</sub>	V	690 A	690 AC			.C		690 A	.C		
Rated frequency	Hz	50/60						50/60			
Trip class		CLAS	CLASS 10, 10A			S 10E, 2	20E		S 5E, 10 stable)	)E, 20E, 30E	
Thermal overload releases	A A	0.11 70 8	0.16 u 80	p to							
Electronic overload releases	A A				0.1	0.4 up <sup>1</sup> 80	to	0.1 20	0.4 up t 80	to	
Pages		7/100	7/102	2	7/119	, 7/120		7/121			
Accessories											
For sizes		S00	S0	S2	S00	S0	S2	S00	S0	S2	
Terminal supports for stand-alone installation		1	1	✓	✓	✓	✓	1	✓	✓	
Mechanical RESET		1	✓	✓	1	✓	✓	✓	1	✓	
Cable releases for RESET		/	/	✓	✓	1	✓	✓	1	✓	
Electrical remote RESET		/ / /					Integr	rated in	the unit		
Terminal covers											
<ul> <li>Ring terminal lug connections</li> </ul>		<b>/</b> 2)	<b>/</b> 2)								
<ul> <li>For box terminals</li> </ul>				✓			✓			✓	
Sealable covers for setting knobs		1				✓	✓	✓	✓	✓	

7/122, 7/123

 $\ensuremath{\checkmark}$  Has this function or can use this accessory

Pages

-- Does not have this function or cannot use this accessory

7/103 ... 7/105

1) The units are responsible in the main circuit for overload protection of the assigned electrical loads (e.g. motors), feeder cable, and other switching and protection devices in the respective load feeder.

7/122, 7/123

<sup>2)</sup> Terminal covers for ensuring finger-safe touch protection are available for 3RU21 overload relays with ring terminal lug connections for mounting onto contactors.

## **Protection Equipment**

## Overload Relays

## Introduction











									-0	- Continue	-	W.			
Туре		3RU11	3RE	B20			3RB	21		3RB	22, 3F	RB23		3F	B24
SIRIUS overload relays up to 63	0 A														
Applications															
System protection		<b>√</b> 1)	<b>√</b> 1)				<b>/</b> 1)			<b>√</b> 1)					
Motor protection		✓	/				/			/					
Alternating current, three-phase		✓	/				/			/					
Alternating current, single-phase		✓								1					
Direct current		✓													
Size contactor		S3	S3 .	S	12		S3	. S1	2	S00 .	S12	2			
Rated operational current I <sub>e</sub>															
• Sizes S00 and S0	Α									with	curre	nt mea	mm v asurinç /3RB2	g mod	
• Size S2	Α												5 mm		
• Size S3	Α	Up to 100	Up	to 1	00		Up t	o 10	00			nt mea 2JG1	asurino	g mod	ule
• Size S6	Α		Up	to 2	00		Up t	o 20	00	with	curre	nt mea	20 mn asuring 3RB29	g mod	ules
• Size S10/S12	А		Up	to 6	30		Up t	o 63	80	with	curre		45 mn asuring		
• Size 14 (3TF68/3TF69)	Α		Up	to 6	30		Up t	o 63	30	Up to 820 with current measuring module 3RB2906-2BG1 and transformer 3UF1868-3GA00					
Rated operational voltage <i>U</i> <sub>e</sub>	V	690/1 000 AC	690	)/1 0	00 AC		690/	1 00	00 AC	690/	1 000	AC <sup>2)</sup>			
Rated frequency	Hz	50/60	50/	60			50/6	0		50/60	)				
Trip class		CLASS 10	CLA	ASS	10, 20		CLA Adju		5, 10, 20, 30 ble		SS 5, stable	10, 20	), 30		
Thermal overload releases	A A	18 25 up to 80 100					'								
Electronic overload releases	A A			5 6	50 up to		12.5 160		50 up to 30	0.3 63	. 3 up 630	o to			
Pages		7/111	7/13	30, 7	7/131		7/13	2				42, 7/	152	7/	149, 7/152
Accessories															
For sizes		S3	S3	S6	S10/S12	2	S3	S6	S10/S12	S00	S0	S2	S3	S6	S10/S12
Terminal supports for stand-alone installation		✓	3)	3)	3)		3)	3)	3)	3)	3)	3)	3)	3)	3)
Mechanical RESET		/	/	/	/		/	/	/						
Cable releases for RESET		✓	/	/	/		/	/	✓						
Electrical remote RESET		1					Inte	grate	ed in the unit	Inte	grated	d in th	e unit		
Terminal covers		✓	1	1	/		/	<b>√</b>	✓				1	1	✓
Sealable covers for setting knobs		Integrated in the unit	/	/	/		/	/	✓	/	/	/	/	/	✓
Operator panel for 3RB24 evaluation module										✓	1	1	1	1	√
Pages		7/112, 7/113	7/13	33. 7	7/134		7/13	3. 7.	/134	7/15	2 7	7/154			
•			, , ,	- , .			,	- , - 1		,					

 $<sup>\</sup>ensuremath{\checkmark}$  Has this function or can use this accessory

<sup>--</sup> Does not have this function or cannot use this accessory

<sup>1)</sup> The units are responsible in the main circuit for overload protection of the assigned electrical loads (e.g. motors), feeder cable, and other switching and protection devices in the respective load feeder.

 $<sup>^{\</sup>rm 2)}$  With reference to the 3RB29.6 current measuring modules.


<sup>3)</sup> Stand-alone installation without accessories is possible.

General data

#### Overview

The following illustration shows our 3RV2 motor starter protector/circuit breaker with the accessories which can be mounted for the sizes S00 to S2, see also "Introduction" → "Overview", page 7/2.

Accessories, see page 7/31 onwards.



Mountable accessories for SIRIUS 3RV2 motor starter protectors/circuit breakers



SIRIUS motor starter protector with spring-type terminals, size S0 (left) and SIRIUS motor starter protector with screw terminals, size S00 (right)

The new SIRIUS 3RV2 motor starter protectors/circuit breakers are compact, current limiting motor starter protectors/circuit breakers which are optimized for load feeders. The motor starter protectors/circuit breakers are used for switching and protecting three-phase motors of up to 37 kW at 400 V AC and for other loads with rated currents of up to 80 A.

For 3RV1 motor starter protectors/circuit breakers in size S3 up to 100 A, see page 7/63 onwards.

The new 3RV2 motor starter protectors/circuit breakers are usually approved according to IEC and UL/CSA. According to UL 508/UL 60947-4-1, the 3RV2 motor starter protectors in sizes S00 to S2 are approved as:

- "Manual Motor Controllers"
- "Manual Motor Controllers" for "Group Installations"
- "Manual Motor Controllers Suitable for Tab Conductor Protection in Group Installations"
- "Self-Protected Combination Motor Controllers (Type E)"
   Please note that for this approval the 3RV20 motor starter
   protectors must be equipped with additional infeed terminals
   or phase barriers. More information, see "Accessories" on
   page 7/38.

Corresponding short-circuit values, see pages 7/10 to 7/15.

The 3RV27 and 3RV28 circuit breakers are approved as circuit breakers according to UL 489; they are a special version of the 3RV2 motor starter protectors.

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

#### General data

#### Type of construction

The 3RV2 motor starter protectors are available in three sizes:

- Size S00 width 45 mm, max. rated current 16 A, at 400 V AC suitable for three-phase motors up to 7.5 kW
- Size S0 width 45 mm, max. rated current 40 A, at 400 V AC suitable for three-phase motors up to 18.5 kW
- Size S2 width 55 mm, max. rated current 80 A, at 400 V AC suitable for three-phase motors up to 37 kW

Size S3 of the 3RV1 motor starter protectors up to 100 A, see page 7/63 onwards.

#### Circuit breakers acc. to UL 489

The 3RV27 and 3RV28 circuit breakers are available in two sizes:

- Size S00 width 45 mm, max. rated current 15 A, for 480 Y/277 V AC
- For size S0 width 45 mm, max. rated current 22 A, at 480 Y/277 V AC

For size S3 of the 3RV1742 circuit breakers up to 70 A, see page 7/67.

#### Connection methods

The 3RV2 motor starter protectors/circuit breakers can be supplied with screw terminals, spring-type terminals and ring cable lug connections.

Screw terminals

Spring-type terminals

Ring terminal lug connections

The terminals are indicated in the corresponding

tables by the symbols shown on orange backgrounds.

## "Increased safety" type of protection EEx e according to ATEX directive 94/9/EC

3RV20 motor starter protectors are suitable for overload protection of explosion-proof motors with "increased safety" type of protection EEx e.

EC type test certificate for Category (2)  $\mbox{G/D}$  has been submitted. More details on request.

Comprehensive technical information, see manuals/operating instructions, http://support.automation.siemens.com/WW/view/en/20357458/133300.

#### Article No. scheme

Digit of the Article No.	1st - 3rd	4th	5th	6th	7th		8th	9th	10th	11th	12th		13th	14th	15th	16th	
bigit of the Article No.																	
						-						-					
Motor starter protectors/ circuit breakers	3 R V																
SIRIUS 2nd generation		2															
Type of motor starter protector/ circuit breaker																	
Size																	
Breaking capacity																	
Setting range for overload release																	
Trip class (CLASS)																	
Connection methods																	
With or without auxiliary switch																	
Special versions																	
Example	3 R V	2	0	1	1	_	1	Α	Α	1	0						

#### Note:


The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

General data

#### Benefits

#### Advantages through energy efficiency



Overview of the energy management process

We offer you a unique portfolio for industrial energy management, using an energy management system that helps to optimally define your energy needs. We split up our industrial energy management into three phases – identify, evaluate and realize – and we support you with the appropriate hardware and software solutions in every process phase.

The innovative products of the SIRIUS industrial controls portfolio can also make a substantial contribution to a plant's energy efficiency (see www.siemens.com/sirius/energysaving).

3RV2 motor starter protectors/circuit breaker contribute to energy efficiency throughout the plant as follows:

- Minimization of energy losses through optimization of the bimetal trip units
- Reduction of inherent power loss
- · Less heating of the control cabinet
- Smaller control cabinet air conditioners can be used

### Application

#### Operating conditions

3RV2 motor starter protectors/circuit breakers are suitable for use in any climate. They are intended for use in enclosed rooms in which no severe operating conditions (such as dust, caustic vapors, hazardous gases) prevail. When installed in dusty and damp areas, suitable enclosures must be provided.

3RV2 motor starter protectors/circuit breakers can optionally be fed from the top or from below.

The permissible ambient temperatures, the maximum switching capacities, the tripping currents and other boundary conditions can be found in the technical specifications and tripping characteristics, see the manual

"SIRIUS Innovations – SIRIUS 3RV2 Motor Starter Protectors", http://support.automation.siemens.com/WW/view/en/60279172.

3RV2 motor starter protectors/circuit breakers are suitable for operation in IT systems (IT networks). In this case, the different short-circuit breaking capacity in the IT system must be taken into account, see page 7/11.

Since operational currents, starting currents and current peaks are different even for motors with identical power ratings due to the inrush current, the motor ratings in the selection tables are only guide values. The specific rated and startup data of the motor to be protected is always paramount to the choice of the most suitable motor starter protector/circuit breaker. This also applies to motor starter protectors for transformer protection.

#### Note:

For the use of 3RV2 motor starter protectors in conjunction with highly energy-efficient IE3 motors, please observe the information on dimensioning and configuring, see

"Configuration Manual for SIRIUS Controls with IE3 Motors", http://support.automation.siemens.com/WW/view/en/94770820.

More information, see 1/3.

#### Possible uses

The 3RV2 motor starter protectors can be used:

- For short-circuit protection
- For motor protection (also with overload relay function)
- For system protection
- For short-circuit protection for starter combinations
- For transformer protection
- As main and EMERGENCY-STOP switches
- For operation in IT systems (IT networks)
- For switching of DC currents
- In areas subject to explosion hazard (ATEX)
- Approved as circuit breakers according to UL 489 (3RV27 and 3RV28)

For more information, see

- System manual "SIRIUS Innovations System Overview", http://support.automation.siemens.com/WW/view/en/60311318
- Manual "SIRIUS Innovations SIRIUS 3RV2 Motor Starter Protectors",

http://support.automation.siemens.com/WW/view/en/60279172

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

### General data

#### Technical specifications

## Short-circuit breaking capacity $I_{\mathrm{cu}}$ , $I_{\mathrm{cs}}$ according to IEC 60947-2

This table shows the rated ultimate short-circuit breaking capacity  $I_{\rm Cu}$  and the rated service short-circuit breaking capacity  $I_{\rm Cs}$  of the 3RV2 motor starter protectors/circuit breakers with different operating voltages dependent on the rated current  $I_{\rm n}$  of the motor starter protectors/circuit breakers.

Power can be supplied to the motor starter protectors/circuit breakers via the terminals at the top or at the bottom without restricting the rated data. If the short-circuit current at the place of installation exceeds the rated short-circuit breaking capacity of the motor starter protector/circuit breaker as specified in the table, a back-up fuse is required. It is also possible to install an upstream motor starter protector/circuit breaker with a limiter function.

The maximum rated current of this back-up fuse is indicated in the tables. The rated ultimate short-circuit breaking capacity then applies as specified on the fuse.

#### Fuseless design

Motor starter protector/contactor assemblies for short-circuit currents up to 150 kA can be ordered as fuseless load feeders, see Chapter 8 "Load Feeders and Motor Starters for Use in the Control Cabinet".

Motor starter protectors/	Rated current I <sub>n</sub>	Up to	240 \	/ AC <sup>1)</sup>	Up to 415 \	400 \ / AC <sup>2)</sup>	/ AC <sup>1)</sup> /	Up to 460 \	440 \ / AC <sup>2)</sup>	/ AC <sup>1)</sup> /	Up to 525 \	500 \ / AC <sup>2)</sup>	/ AC <sup>1)</sup> /	Up to	690 \	/ AC <sup>1)</sup>
circuit breakers		$I_{\mathrm{CU}}$	$I_{\mathrm{CS}}$	Max. fuse (gG)	$I_{ m CU}$	$I_{\mathrm{CS}}$	Max. fuse (gG) <sup>3)</sup>	$I_{\mathrm{CU}}$	$I_{\mathrm{CS}}$	Max. fuse (gG) <sup>3)</sup>	$I_{ m CU}$	$I_{\mathrm{CS}}$	Max. fuse (gG) <sup>3)</sup>	$I_{ m CU}$	$I_{\mathrm{CS}}$	Max. fuse (gG) <sup>3)4)</sup>
Туре	Α	kA	kA	А	kA	kA	А	kA	kA	А	kA	kA	А	kA	kA	А
Size S00																
3RV2.11	0.16 1.6 2; 2.5 3.2	100 100 100	100 100 100	0 0	100 100 100	100 100 100	0	100 100 100	100 100 100	o o	100 100 100	100 100 100	o o	100 10 10	100 10 10	。 25 32
	4; 5 6.3 8	100 100 100	100 100 100	0 0	100 100 100	100 100 100	0	100 100 50	100 100 50	。 。 63	100 100 42	100 100 42	。 63	6 6 6	4 4 4	32 50 50
	10 12.5 16	100 100 100	100 100 100	0 0	100 100 55	100 100 30	。 100	50 50 50	50 50 10	80 80 80	42 42 10	42 42 5	63 80 80	6 6 4	4 4 4	50 63 63
Size S0																
3RV2.21	0.16 1.6 2; 2.5 3.2	100 100 100	100 100 100	0	100 100 100	100 100 100	0	100 100 100	100 100 100	0	100 100 100	100 100 100	0	100 10 10	100 10 10	。 25 32
	4; 5 6.3 8	100 100 100	100 100 100	0 0	100 100 100	100 100 100	0	100 100 50	100 100 50	。 。 63	100 100 42	100 100 42	。 63	6 6 6	4 4 4	32 50 50
	10 12.5 16	100 100 100	100 100 100	0 0	100 100 55	100 100 25	。 100	50 50 50	50 50 10	80 80 80	42 42 10	42 42 5	63 80 80	6 6 4	4 4 2	50 63 63
	20 22; 25 28; 32 36; 40	100 100 100 100	100 100 100 100	0	55 55 55 20	25 25 25 10	125 125 125 125	50 50 30 12	10 10 10 8	80 100 125 125	10 10 10 6	5 5 5 3	80 80 100 100	4 4 4 3	2 2 2 2	63 63 100 100
Size S2																
3RV2.31	14; 17 20 25	100 100 100	100 100 100	0	65 65 65	30 30 30	100 100 100	50 50 50	25 25 15	100 100 100	12 12 12	6 6 6	63 80 80	5 5 5	3 3 3	63 80 80
	32; 36 40; 45 52	100 100 100	100 100 100	0	65 65 65	30 30 30	125 160 160	50 50 50	15 15 15	125 125 125	10 10 10	5 5 5	100 100 125	4 4 4	2 2 2	100 100 125
	59 80	Value	s on re	equest												
Size S2, with in switching capac																
3RV2.32	14; 17 20; 25 32 45 52	100 100 100 100	100 100 100 100	0	100 100 100 100	50 50 50 50	0 0 0	65 65 65 65	30 30 30 30	100 100 125 125	18 18 15 15	10 10 8 8	63 80 100 125	8 8 6 6	5 5 4 4	63 80 100 125

<sup>°</sup> No back-up fuse required, since short-circuit resistant up to 100 kA

<sup>1) 10 %</sup> overvoltage.

<sup>&</sup>lt;sup>2)</sup> 5 % overvoltage.

 $<sup>^{\</sup>rm 3)}$  Back-up fuse only required if short-circuit current at the place of installation >  $I_{\rm cu}.$ 

<sup>4)</sup> Alternatively, fuseless limiter combinations for 690 V AC can also be used.

General data

### Short-circuit breaking capacity $I_{\text{culT}}$ in the IT system (IT network) according to IEC 60947-2

3RV2 motor starter protectors/circuit breakers are suitable for use in IT systems. The values of  $I_{\rm Cu}$  and  $I_{\rm Cs}$  apply for the three-pole short circuit. In case of a double ground fault in different phases at the input and output side of a motor starter protector, the special short-circuit breaking capacity  $I_{\rm culT}$  applies. The specifications in the table below apply to 3RV2 motor starter protectors/circuit breakers.

If the short-circuit current at the place of installation exceeds the motor starter protector/circuit breaker's specified rated short-circuit breaking capacity, you will need to use a back-up fuse. The maximum rated current of this back-up fuse is indicated in the tables. The rated short-circuit breaking capacity then applies as specified on the fuse.

Motor starter	Rated	Up to 240 V	<b>AC</b> <sup>1)</sup>	Up to 400 V A	AC <sup>1)</sup> /415 V AC <sup>2)</sup>	Up to 500 V A	C <sup>1)</sup> /525 V AC <sup>2)</sup>	Up to 690 V	AC <sup>1)5)</sup>
protectors	current I <sub>n</sub>	$I_{CulT}$	Max. fuse (gG) <sup>3)</sup>	$I_{culT}$	Max. fuse (gG) <sup>3)4)</sup>	$I_{\mathrm{CulT}}$	Max. fuse (gG) <sup>3)</sup>	$I_{CulT}$	Max. fuse (gG) <sup>3)</sup>
Туре	Α	kA	А	kA	А	kA	А	kA	А
Size S00									
3RV2.11	0.16 0.4 0.5 0.63; 0.8	100 100 100	o o o	100 100 100	0 0	100 100 100	o o	100 0.5 0.5	° 4 6
	1 1.25 1.6	100 100 100	0 0	100 100 100	0	8 8 8	10 16 20	2 2 2	10 16 16
	2; 2.5 3.2 4; 5	100 100 100	o o o	8 8 4	25 32 32	8 8 2	25 32 32	2 2 2	20 25 25
	6.3; 8 10 12.5 16	100 100 100 55	。 。 80	4 4 4 4	50 50 63 63	2 2 2 2	40 40 50 50	1.5 1.5 1.5 1.5	35 40 40 40
Size S0						_		1.12	
3RV2.21	0.16 0.4 0.5 0.63; 0.8	100 100 100	0	100 100 100	0 0	100 100 100	0	100 0.5 0.5	6 6
	1 1.25 1.6	100 100 100	0 0	100 100 100	0	8 8 8	10 16 20	2 2 2	10 16 16
	2; 2.5 3.2 4; 5	100 100 100	o o o	8 8 4	25 32 32	8 8 2	25 32 32	2 2 2	20 25 25
	6.3; 8 10 12.5	100 100 100	0 0	4 4 4	50 50 63	2 2 2	40 40 50	1.5 1.5 1.5	35 40 40
	16 20 25 28; 32 36; 40	55 55 55 20	80 80 80 80	4 4 2 2	63 63 63	2 2 2 2	50 50 63 63	1.5 1.5 1.5 1.5	40 50 63 63
Size S2									
3RV2.31	14 25 32 45 52	100 100 100	0 0	8 6 4	100 125 160	6 4 3	80 100 125	4 3 2	63 80 100
	59 80	Values on red	quest						
Size S2, with in switching capa	acity								
3RV2.32	14 25 32 45 52	100 100 100	o o o	8 6 6	100 125 160	6 6 6	80 100 125	4 4 4	63 80 100
	59 80	Values on red	quest						

 $<sup>^{\</sup>circ}\,\,$  No back-up fuse required, since short-circuit resistant up to 100 kA

<sup>1) 10 %</sup> overvoltage.

<sup>&</sup>lt;sup>2)</sup> 5 % overvoltage.

 $<sup>^{3)}</sup>$  Back-up fuse only required if short-circuit current at the place of installation >  $I_{\rm culT}$ 

<sup>&</sup>lt;sup>4)</sup> Alternatively, fuseless limiter combinations for 690 V AC can also be used.

 $<sup>^{5)}</sup>$  Overvoltage category II applies for applications in IT systems > 600 V.

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

#### General data

#### Limiter function with standard devices for 500 V AC and 690 V AC according to IEC 60947-2

The table shows the rated ultimate short-circuit breaking capacity  $I_{\rm CU}$  and the rated service short-circuit breaking capacity  $I_{\rm CS}$  with an upstream standard motor starter protector/circuit breaker that fulfills the limiter function at voltages 500 V AC and 690 V AC.

The short-circuit breaking capacity can be increased significantly with an upstream standard motor starter protector/circuit breaker with limiter function. The motor starter protector/circuit breaker which is connected downstream must be set to the rated current of the load.

With motor starter protector/circuit breaker assemblies, note the clearance to grounded parts and between the motor starter protectors/circuit breaker. Short-circuit proof wiring between the motor starter protectors/circuit breaker must be ensured. The motor starter protectors/circuit breakers can be mounted side by side in a modular arrangement.

Standard motor starter	protectors/circuit breakers	Rated current In	Up to 500 V AC <sup>1)</sup> /5	25 V AC <sup>2)</sup>	Up to 690 V AC <sup>1)</sup>	
	With limiter rated current $I_{\rm n}$		$I_{ extsf{Cu}}$	$I_{\mathtt{CS}}$	$I_{ extsf{Cu}}$	$I_{ t CS}$
Type	Type	Α	kA	kA	kA	kA
Size S00						
3RV2011	<b>Size S0:</b> $I_{\cap} = 32 \text{ A}$	2 6.3 8 10 16	 100 100	 50 50	50 20 20 <sup>3)</sup>	25 10 10 <sup>3)</sup>
	Size S2: 3RV1331-4HC10	10 16			50	25
	$I_{\rm n} = 50 \ {\rm A}$					
Size S0						
3RV2021	<b>Size S0:</b> $I_{\cap} = 32 \text{ A}$	16 32	100	50	20 <sup>3)</sup>	10 <sup>3)</sup>
	Size S2: 3RV1331-4HC10	16 32			50	20
	$I_{\rm n} = 50 \ {\rm A}$					
Size S2					•	_
3RV2031		14 80	Values on request	_	_	_
Size S2, with increas	ze S2, with increased switching capacity				•	
3RV2032			Values on request			

<sup>--</sup> No limiter required

<sup>1) 10 %</sup> overvoltage.

<sup>&</sup>lt;sup>2)</sup> 5 % overvoltage.

 $<sup>^{3)}</sup>$  Infeed to the limiter is always on the side 1L1/3L2/5L3.

General data

#### Permissible rated data of approved devices for North America (UL/CSA)

Motor starter protectors of the 3RV2 series are approved for UL/CSA, and according to UL508/UL 60947-4-1 and CSA C22.2 No. 14/CSA C22.2 No. 60947-4-1 they can be used on their own or as load feeders in combination with a contactor.

These motor starter protectors/circuit breakers can be used as "Manual Motor Controllers" for "Group Installations", as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" and as "Self-Protected Combination Motor Controllers" (Type E).

#### 3RV2 motor starter protectors as "Manual Motor Controllers"

If used as a "Manual Motor Controller", the motor starter protector is always operated in combination with an upstream short-circuit protection device. Approved fuses or a circuit breaker according to UL 489/CSA C22.2 No. 5 can be used. These devices must be dimensioned according to the National Electrical Code (UL) or Canadian Electrical Code (CSA).

The file numbers for the approval of the 3RV2 as a Manual Motor Controller are as follows:

- UL File No. 47705, CCN: NLRV
- CSA Master Contract 165071, Product Class: 3211 05

Motor starter		hp rating	j <sup>1)</sup> for FLA <sup>2)</sup>	Rated	240 V AC		480 V A		600 V AC	
protectors		max.		current I <sub>n</sub>	UL I <sub>bc</sub> <sup>3)</sup>	CSA $I_{\rm bc}^{3)}$	UL I <sub>bc</sub> <sup>3)</sup>	CSA $I_{ m bc}^{-3)}$	UL I <sub>bc</sub> <sup>3)</sup>	CSA $I_{ m bc}^{(3)}$
Туре	V	Single- phase	Three- phase	А	kA	kA	kA	kA	kA	kA
Size S00										
3RV2011, 3RV2111	I, 3RV2311, 3R\	/2411		0.16 12.5 16	65 65	65 65	65 65	65 65	30	30
FLA <sup>2)</sup> max.	115	1	2							
16 A, 480 V;	200 230	2	2 3 5							
12.5 A, 600 V	460		10							
	575/600		10							
Size S0										
3RV2021, 3RV2121	I, 3RV2321, 3R\	/2421		0.16 12.5	65	65	65	65	30	30
FLA <sup>2)</sup> max.	115	3	5	16 25 28, 32	65 65	65 65	65 50	65 50	/(30) <sup>4)</sup>	/(30) <sup>4)</sup>
40 A, 480 V	200	5	10	36, 40	65	65	12	12		
40 A, 400 V	230	7 1/2	10							
	460 575/600		30							
Size S2										
3RV2031, 3RV2032	RV2031, 3RV2032, 3RV2131,				Values on request					

#### 3RV2031, 3RV2032, 3RV2131,

3RV2331, 3RV2332, 3RV2431

-- No approval

<sup>1)</sup> hp rating = Power rating in horse power (maximum motor rating).

<sup>2)</sup> FLA = Full Load Amps/motor full load current.

<sup>3)</sup> Corresponds to "short-circuit breaking capacity" according to UL/CSA.

<sup>4)</sup> The values in brackets only apply to 3RV2.23 motor starter protectors.

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

#### General data

3RV20 motor starter protectors (up to 80 A) as "Manual Motor Controller Suitable for Tap Conductor Protection in Group Installations"

The application as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" is only available for UL. CSA does not recognize this approval! When the motor starter protector is used as a "Manual Motor Controller Suitable for Tap Conductor Protection in Group Installations", it must always be combined with upstream short-circuit protection. Approved fuses or a circuit breaker according to UL 489 can be used. These devices must be dimensioned according to the National Electrical Code.

The 3RV20 motor starter protectors are approved as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" under the following file number:

• UL File No. 47705, CCN: NLRV

Motor starter protectors		hp rating <sup>1)</sup> max.	for FLA <sup>2)</sup>	Rated current I <sub>n</sub>	<b>240 V AC</b> UL <i>I</i> <sub>bc</sub> <sup>3)</sup>	Up to 480 Y/277 V AC UL $I_{\rm bc}^{3)}$	Up to 600 Y/347 V AC UL $I_{\rm bc}^{~3)}$
Туре	V	Single- phase	Three- phase	А	kA	kA	kA
Size S00							
3RV2011				0.16 12.5 16	65 65	65 65	30
FLA <sup>2)</sup> max. 16 A, 480 V; 12.5 A, 600 V	115 200 230 460 575/600	1 2 2 	2 3 5 10 10				
Size S0							
<b>3RV2021</b> FLA <sup>2)</sup> max. 32 A, 480 V	115 200 230 460 575/600	2 3 5 	5 7 1/2 10 20	0.16 12.5 16 25 28; 32	65 65 50	65 65 50	30
Size S2							
3RV2031, 3RV2032					Values on request		

<sup>--</sup> No approval

<sup>1)</sup> hp rating = Power rating in horse power (maximum motor rating).

<sup>2)</sup> FLA = Full Load Amps/motor full load current.

<sup>3)</sup> Corresponds to "short-circuit breaking capacity" according to UL.

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

General data

#### 3RV20 motor starter protectors (up to 80 A) as "Self-Protected Combination Motor Controller (Type E)"

UL 508/UL 60947-4-1 approval demands 1-inch clearance and 2-inch creepage distance at line side for "Self-Protected Combination Motor Controller Type E".

Therefore, 3RV20 motor starter protectors of sizes S00 to S2 are approved according to UL 508/UL 60947-4-1 in combination with the terminal blocks listed below.

CSA does not require these extended clearances and creepage distances. According to CSA, these terminal blocks can be omitted when the device is used as a "Self-Protected Combination Motor Controller".

The 3RV20 motor starter protectors are approved as "Self-Protected Combination Motor Controllers" under the following file numbers:

- UL File No. E156943, CCN: NKJH
- CSA Master Contract 165071, Product Class: 3211 08

Motor starter		hp rating <sup>1)</sup> for FLA <sup>2)</sup>		Rated	Up to 240 \	Up to 240 V AC		Y/277 V AC	Up to 600 Y/347 V AC	
protectors		max.		current I <sub>n</sub>	UL	CSA	UL	CSA	UL	CSA
					$I_{bc}^{3)}$	$I_{bc}^{3)}$	$I_{bc}^{3)}$	$I_{\rm bc}^{3)}$	$I_{\rm bc}^{3)}$	$I_{bc}^{3)}$
Туре	V	Single-	Three-		1. 4		1. 4			1. 4
0: 000		phase	phase	A	kA	kA	kA	kA	kA	kA
Size S00	4) =)									
3RV2011 + 3RV29	28-1H <sup>4)5)</sup>			0.16 12.5 16	65 65	65 65	65 65	65 65	30	30 
FLA <sup>2)</sup> max.	115	1	2							
16 A, 480 V;	200	2	2 3 5							
12.5 A, 600 V	230	2	5 10							
	460 575/600		10							
Size S0										
3RV2021 + 3RV29	28-1H <sup>4)5)</sup>			0.16 12.5 16 25	65 65	65 65	65 65	65 65	30	30
FLA <sup>2)</sup> max.	115	2	5	28; 32	50	50	50	50		
32 A, 480 V	200	2	7 1/2							
,	230	5	10							
	460 575/600		20							

## 3RV2031/3RV2032 + 3RV2938-1K4)

- -- No approval
- 1) hp rating = Power rating in horse power (maximum motor rating).
- 2) FLA = Full Load Amps/motor full load current.

#### Values on request

- 3) Corresponds to "short-circuit breaking capacity" according to UL/CSA.
- 4) Not required for CSA.
- 5) Alternatively, the 3RV2928-1K phase barrier can also be used.

## 3RV27 and 3RV28 motor starter protectors as "circuit breakers"

These motor starter protectors are approved as circuit breakers according to UL 489 and CSA 22.2 No. 5. They can be used therefore as upstream short-circuit protective devices for "Manual Motor Controllers" and "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations".

3RV27 and 3RV28 motor starter protectors are approved as "circuit breakers" under the following file numbers:

- UL File No. E235044, CCN: DIVQ
- CSA Master Contract 165071, Product Class: 1432 01

Circuit breakers	Rated current I <sub>n</sub>	240 V AC		480 Y/277 V AC		600 Y/347 V AC	
		UL	CSA	UL	CSA	UL	CSA
		$I_{\rm bc}^{-1)}$	$I_{bc}^{1)}$	$I_{bc}^{1)}$	$I_{bc}^{1)}$	$I_{bc}^{1)}$	$I_{bc}^{1)}$
Туре	A	kA	kA	kA	kA	kA	kA
Size S00							
3RV2711	0.16 12.5 15	65 65	65 65	65 65	65 65	10	10
3RV2811	0.16 12.5 15	65 65	65 65	65 65	65 65	10	10
Size S0							
3RV2721	20; 22	50	50	50	50		
3RV2821	20; 22	50	50	50	50		

<sup>1)</sup> Corresponds to "short-circuit breaking capacity" according to UL.

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

General data						
Туре			3RV2.1.	3RV2.2.	3RV2.3.	3RV27, 3RV28
Size			S00	S0	S2	S00, S0
Dimensions (W x H x D)						,
<ul><li>Screw terminals</li><li>Spring-type terminals</li></ul>	₩ Vo	mm mm	45 x 97 x 91 45 x 106 x 91	45 x 97 x 91 45 x 119 x 91	55 x 140 x 149	45 x 144 x 92 
Standards			10 % 100 % 01	10 % 1 10 % 0 1		
• IEC 60947-1, EN 60947-1 (VDE 0660 Par			Yes			
<ul> <li>IEC 60947-2, EN 60947-2 (VDE 0660 Part</li> <li>IEC 60947-4-1, EN 60947-4-1 (VDE 0660</li> </ul>			Yes Yes	Yes	Yes	
• UL 508/UL 60947-4-1, CSA C22.2 No. 14			Yes	Yes	Yes	
• UL 489, CSA C22.2 No. 5	· 					Yes
Number of poles			3			
Max. rated current I <sub>n max</sub> (= max. rated operational current I <sub>e</sub> )		Α	16	40	80	22
Permissible ambient temperature						
Storage/transport		°C	-50 +80			
Operation	<i>I</i> <sub>n</sub> : 0.16 32 A	°C	-20 +70	abaya (00 °C)		
	<i>I</i> <sub>n</sub> : 36 40 A	°C	(current reduction	-20 +40		
	-11			(the devices must		
				not be mounted side-by-side and		
				they must not be		
				assembled with		
				link modules with contactors.		
				A lateral clear-		
				ance of 9 mm is		
	<i>I</i> <sub>n</sub> : 14 80 A	°C		required.)	-20 +70	
	-11				(current reduction	
					above +60 °C)	
Permissible rated current at inside temperature +60 °C	erature of control cabinet	%	100			
• +70 °C		%	87			
Permissible rated current at ambient tem	perature of enclosure					
(applies for motor starter protector/circu			400			
• +35 °C • +60 °C		% %	100 87		On request	100 87
Rated operational voltage U <sub>e</sub>		70	01		request	01
• Acc. to IEC		V AC	690 (when a mold	led-plastic enclosur	e is used only 500 '	V)
Acc. to UL/CSA		V AC	600			
Rated frequency		Hz	50/60			
Rated insulation voltage $U_{\rm i}$		V	690			
Rated impulse withstand voltage $U_{imp}$		kV	6			
Utilization category	:!* != == = ! . = =\		٨			
<ul> <li>IEC 60947-2 (motor starter protector/circulate IEC 60947-4-1 (motor starter)</li> </ul>	uit breaker)		A AC-3			
Trip class CLASS	Acc. to IEC 60947-4-1		10		10/20	
DC short-circuit breaking capacity (time					10/20	
1 conducting path 150 V DC	oonotant to only	kA	10		On	10
2 conducting paths in series 300 V DC     3 conducting paths in series 450 V DC		kA kA	10 10		request	10 10
• 3 conducting paths in series 450 V DC	1 · 0 10		5			5
Power loss P <sub>v</sub> for each motor starter protector/circuit breaker	<i>I</i> <sub>n</sub> : 0.16 0.63 A <i>I</i> <sub>n</sub> : 0.8 6.3 A	W	6			6
Dependent on	<i>I</i> <sub>n</sub> : 8 16 A	W	7			7
	I <sub>n</sub> : 16 A	W		7	10	7
the rated current $I_n$	1 <sub>n</sub> . 10 A			8	12	8
(upper setting range)	<i>I</i> <sub>n</sub> : 17 25 A	W			4.4	
(upper setting range)	<i>I</i> <sub>n</sub> : 17 25 A <i>I</i> <sub>n</sub> : 28 32 A	W		11	14	
	I <sub>n</sub> : 17 25 A I <sub>n</sub> : 28 32 A I <sub>n</sub> : 36 40 A I <sub>o</sub> : 45 52 A		 	11 14 	15	
(upper setting range)	<i>I</i> <sub>n</sub> : 17 25 A <i>I</i> <sub>n</sub> : 28 32 A	W W	  	14		
(upper setting range)	I <sub>n</sub> : 17 25 A I <sub>n</sub> : 28 32 A I <sub>n</sub> : 36 40 A I <sub>o</sub> : 45 52 A	W W W	   25/11 (square and	14  	15 17	
(upper setting range) $R_{\text{per conducting path}} = \frac{P}{I^2 \times 3}$	I <sub>n</sub> : 17 25 A I <sub>n</sub> : 28 32 A I <sub>n</sub> : 36 40 A I <sub>n</sub> : 45 52 A I <sub>n</sub> : 80 A	W W W		14  	15 17	
(upper setting range) $R_{\rm per  conducting  path} = \frac{P}{I^2 \times 3}$ Shock resistance	In: 17 25 A In: 28 32 A In: 36 40 A In: 45 52 A In: 80 A Acc. to IEC 60068-2-27	W W W	25/11 (square and IP20	14  	15 17 On request	
(upper setting range) $R_{\rm per  conducting  path} = \frac{P}{I^2 \times 3}$ Shock resistance ${}$ Degree of protection	I <sub>n</sub> : 17 25 A I <sub>n</sub> : 28 32 A I <sub>n</sub> : 36 40 A I <sub>n</sub> : 45 52 A I <sub>n</sub> : 80 A Acc. to IEC 60068-2-27	W W W	25/11 (square and IP20	14   d sine pulse)	15 17 On request	
(upper setting range) $R_{\rm per  conducting  path} = \frac{P}{I^2 \times 3}$ Shock resistance Degree of protection Touch protection	In: 17 25 A In: 28 32 A In: 36 40 A In: 45 52 A In: 80 A Acc. to IEC 60068-2-27 Acc. to IEC 60529 Acc. to EN 50274	W W W W	25/11 (square and IP20 Finger-safe for vertical and IP20 -20 +60	14   d sine pulse)	15 17 On request	   No
(upper setting range) $R_{\rm per  conducting  path} = \frac{P}{I^2 \times 3}$ Shock resistance Degree of protection Touch protection Temperature compensation	In: 17 25 A In: 28 32 A In: 36 40 A In: 45 52 A In: 80 A Acc. to IEC 60068-2-27 Acc. to IEC 60529 Acc. to EN 50274 Acc. to IEC 60947-4-1 Acc. to IEC 60947-4-1	W W W W	25/11 (square and IP20) Finger-safe for verification +60 Yes (only for 3RV2)	14 d sine pulse)	15 17 On request	
(upper setting range) $R_{\rm per  conducting  path} = \frac{P}{I^2 \times 3}$ Shock resistance Degree of protection Touch protection Temperature compensation Phase failure sensitivity	In: 17 25 A In: 28 32 A In: 36 40 A In: 45 52 A In: 80 A Acc. to IEC 60068-2-27 Acc. to IEC 60529 Acc. to EN 50274 Acc. to IEC 60947-4-1 Acc. to IEC 60947-4-1	W W W W	25/11 (square and IP20) Finger-safe for verification +60 Yes (only for 3RV2)	14 d sine pulse)  rtical contact from the starter professional start	15 17 On request	
(upper setting range) $R_{\rm per  conducting  path} = \frac{P}{I^2 \times 3}$ Shock resistance $\frac{P}{I^2 \times 3}$ Degree of protection $\frac{P}{I^2 \times 3}$ Touch protection $\frac{P}{I^2 \times 3}$ Explosion protection - Safe operation of "increased safety" type of protection $\frac{P}{I^2 \times 3}$ Explosion protection - Safe operation of "increased safety" type of protection $\frac{P}{I^2 \times 3}$	In: 17 25 A In: 28 32 A In: 36 40 A In: 45 52 A In: 80 A Acc. to IEC 60068-2-27 Acc. to IEC 60529 Acc. to EN 50274 Acc. to IEC 60947-4-1 Acc. to IEC 60947-4-1 motors with	W W W W	25/11 (square and IP20) Finger-safe for verification +60 Yes (only for 3RV2)	14 d sine pulse)  rtical contact from the contact fro	15 17 On request	
(upper setting range) $R_{\rm per  conducting  path} = \frac{P}{I^2 \times 3}$ Shock resistance Degree of protection Touch protection Temperature compensation Phase failure sensitivity Explosion protection – Safe operation of "increased safety" type of protection	In: 17 25 A In: 28 32 A In: 36 40 A In: 45 52 A In: 80 A Acc. to IEC 60068-2-27 Acc. to IEC 60529 Acc. to EN 50274 Acc. to IEC 60947-4-1 Acc. to IEC 60947-4-1 motors with	W W W W	25/11 (square and IP20) Finger-safe for verolder -20 +60 Yes (only for 3RV2) Yes (only for 3RV2)	14 d sine pulse)  rtical contact from the contact fro	15 17 On request ne front ectors)	No

General data (continued)						
<b>Type</b> Size			<b>3RV2.1.</b> S00	<b>3RV2.2.</b> S0	<b>3RV2.3.</b> S2	<b>3RV27, 3RV28</b> S00, S0
Dimensions (W x H x D)  • Screw terminals  • Spring-type terminals	T W O	mm mm	45 x 97 x 91 45 x 106 x 91	45 x 97 x 91 45 x 119 x 91	55 x 140 x 149	45 x 144 x 92
Isolating function Main and EMERGENCY-STOP switch characteristics (with corresponding accessories)	Acc. to IEC 60947-2 Acc. to DIN EN 60204-1		Yes Yes			
Protective separation between main and auxiliary circuits, required for PELV applications • Up to 400 V +10 % • Up to 415 V +5 % (higher voltages on re	Acc. to IEC 60947-1		Yes Yes			
Permissible mounting position			Any, acc. to IEC 6	0447 start comman	d "I" right-hand side	e or top
Mechanical endurance	Operat	ing cycles	100 000		52 A: 50 000, 80 A: On request	100 000
Electrical endurance	Operat	ing cycles	100 000		52 A: 50 000, 80 A: On request	100 000
Max. switching frequency per hour (mot	tor starts)	1/h	15			

Rated data of the auxiliary switches and signaling switches	S				
		Lateral auxiliary switch with	Signaling switches	Transverse auxiliary switch	with
		1 NO + 1 NC, 2 NO, 2 NC, 2 NO + 2 NC		1 CO	1 NO + 1 NC, 2 NO
Max. rated voltage					
• Acc. to NEMA (UL)	V AC	600			250
• Acc. to NEMA (CSA)	V AC	600			250
Uninterrupted current	А	10		5	2.5
Switching capacity		1 NO + 1 NC, 2 NO, 2 NC: A600, Q300; 2 NO + 2 NC: A300, Q300	A600, Q300	B600, R300	C300, R300

Front transverse auxiliary switches			
		Switching capacity for	different voltages
		1 CO	1 NO + 1 NC, 2 NO
Rated operational current I <sub>e</sub>			
<ul> <li>At AC-15, alternating voltage</li> <li>24 V</li> <li>230 V</li> </ul>	A A	4 3	2 0.5
<ul> <li>At AC-12 = I<sub>th</sub>, alternating voltage</li> <li>24 V</li> <li>230 V</li> </ul>	A A	10 10	2.5 2.5
<ul> <li>At DC-13, direct voltage L/R 200 ms</li> <li>24 V</li> <li>48 V</li> <li>60 V</li> <li>110 V</li> <li>220 V</li> </ul>	A A A A	1  0.22 0.1	1 0.3 0.15 
Minimum load capacity	V mA	17 1	

Front transverse solid-state com	patible auxiliary switches		
			Switching capacity for different voltages
			1 CO
Rated operational voltage U <sub>e</sub>	Alternating voltage	V	125
Rated operational current I <sub>e</sub> /AC-14	at $U_{\rm e}$ = 125 V	Α	0.1
Rated operational voltage U <sub>e</sub>	Direct voltage L/R 200 ms	V	60
Rated operational current I <sub>e</sub> /DC-13	at $U_e$ = 60 V	Α	0.3
Minimum load capacity		V	5
		mA	1

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

Lateral auxiliary switches with signaling switch		
		Switching capacity for different voltages: Lateral auxiliary switch with 1 NO + 1 NC, 2 NO, 2 NC, 2 NO + 2 NC Signaling switch
Rated operational current I <sub>e</sub>		
At AC-15, alternating voltage     24 V     230 V     400 V     690 V  At AC-12 = I <sub>th</sub> , alternating voltage     24 V	A A A	6 4 3 1
- 230 V - 400 V - 690 V	A A A	10 10 10
<ul> <li>At DC-13, direct voltage L/R 200 ms</li> <li>24 V</li> <li>110 V</li> <li>220 V</li> <li>440 V</li> </ul>	A A A	2 0.5 0.25 0.1
Minimum load capacity	V mA	17 1

Auxiliary releases			
		Undervoltage releases	Shunt releases
Power consumption			
<ul><li>During pick-up</li><li>AC voltages</li><li>DC voltages</li></ul>	VA/W W	20.2/13 20	20.2/13 13 80
<ul><li>During uninterrupted duty</li><li>AC voltages</li><li>DC voltages</li></ul>	VA/W W	7.2/2.4 2.1	
Response voltage			
• Tripping	V	0.35 0.7 x U <sub>s</sub>	0.7 1.1 x U <sub>s</sub>
• Pick-up	V	0.85 1.1 x U <sub>s</sub>	
Opening time maximum	ms	20	

Short-circuit protection for auxiliary and control circuits		
Melting fuses operational class gG	Α	10
Miniature circuit breakers C characteristic	Α	6 (prospective short-circuit current < 0.4 kA)

Conductor cross-sections of main circuit						
Туре		3RV2.11	3RV2.21	3RV2.31-4B1., 3RV2.31-4D.1., 3RV2.31-4E.1., 3RV2.31-4P.1., 3RV2.31-4S.1., 3RV2.31-4T.1., 3RV2.31-4U.1., 3RV2.31-4V.1.	3RV2.31-4J.1., 3RV2.31-4K.1., 3RV2.31-4R.1., 3RV2.31-4W.1., 3RV2.31-4X.1., 3RV2431-4VA1., 3RV2.32	3RV27, 3RV28
Size		S00	S0	S2		S00, S0
Connection type		Screw term	inals			
Terminal screw		M3, Pozidriv size 2	M4, Pozidriv size 2	M6, Pozidriv size 2		M4, Pozidriv size 2
Operating devices	mm	Ø 5 6	Ø 5 6	Ø 5 6		Ø 5 6
Prescribed tightening torque	Nm	0.8 1.2	2 2.5	3.0 4.5		2.5 3
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected						
<ul> <li>Solid or stranded</li> <li>Finely stranded with end sleeve (DIN 46228-1)</li> </ul>	mm <sup>2</sup>	2 x (0.75 2.5) <sup>1)</sup> , 2 x 4 2 x (0.5 1.5) <sup>1)</sup> ,	$2 \times (1 \dots 2.5)^{1)}$ $2 \times (2.5 \dots 10)^{1)}$ $2 \times (1 \dots 2.5)^{1)}$	2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup> 2 x (1 16) <sup>1)</sup> ,	2 x (1 35) <sup>1</sup> , 1 x (1 50) <sup>1</sup> , 2 x (1 25) <sup>1</sup> ,	2 x (1 10) <sup>1)</sup> , max. 1 x 25 1 x (1 16),
		2 x (0.75 2.5) <sup>1)</sup>	2 x (2.5 6) <sup>1)</sup> , 1 x 10	1 x (1 25) <sup>1)</sup>	1 x (1 35) <sup>1)</sup>	max. 6 + 16
AWG cables, solid or stranded	AWG	2 x (20 16) <sup>1)</sup> , 2 x (18 12) <sup>1)</sup>	2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup>	2 x (18 3) <sup>1)</sup> , 1 x (18 2) <sup>1)</sup>	2 x (18 2) <sup>1)</sup> , 1 x (18 1) <sup>1)</sup>	2 x (14 10)
Connection type		Spring-type	terminals			
Operating devices	mm	3.0 x 0.5 and 3.5 >	( 0.5			
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected						
Solid or stranded	$\rm mm^2$	2 x (0.5 4)	2 x (1 10)			
<ul> <li>Finely stranded without end sleeve</li> </ul>	mm <sup>2</sup>	2 x (0.5 2.5)	2 x (1 6)			
• Finely stranded with end sleeve (DIN 46228-11)	mm <sup>2</sup>	2 x (0.5 2.5)	2 x (1 6)			
<ul> <li>AWG cables, solid or stranded</li> </ul>	AWG	2 x (20 12)	2 x (18 8)			
Max. external diameter of the conductor insulation	mm	3.6	3.6			
Connection type		Ring termin	al lug connection	IS		
Terminal screw		M3, Pozidriv size 2	M4, Pozidriv size 2			
Operating devices	mm	Ø 5 6	Ø 5 6			
Prescribed tightening torque	Nm	0.8 1.2	2 2.5			
Usable ring terminal lugs  • DIN 46234 without insulation sleeve  • DIN 46225 without insulation sleeve  • DIN 46237 with insulation sleeve  • JIS C2805 Type R without insulation sleeve  • JIS C2805 Type RAV with insulation sleeve  • JIS C2805 Type RAP with	mm	d <sub>2</sub> = min. 3.2, d <sub>3</sub> = max. 7.5	$d_2 = min. 4.3,$ $d_3 = max. 12.2$			
insulation sleeve						

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

## General data

Туре		3RV2.11	3RV2.21	3RV2.31, 3RV2.32	3RV27, 3RV2	
Size		S00	S0	S2	S00, S0	
Connection type	Screw t	erminals				
Terminal screw		M3, Pozidriv s	ize 2			
Operating devices	mm	Ø 5 6				
Prescribed tightening torque	Nm	0.8 1.2				
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected						
Solid or stranded	mm <sup>2</sup>	2 x (0.5 1.5)	) <sup>1)</sup> , 2 x (0.75 2	1.5) <sup>1)</sup>		
<ul> <li>Finely stranded with end sleeve (DIN 46228-1)</li> </ul>	mm <sup>2</sup>	2 x (0.5 1.5)	) <sup>1)</sup> , 2 x (0.75 2	(.5) <sup>1)</sup>		
AWG cables, solid or stranded	AWG	2 x (18 14) <sup>1</sup>	<sup>)</sup> , 2 x (20 16) <sup>1</sup>	)		
Connection type		Spring-	type terminals			
Operating devices	mm	3.0 x 0.5 and	3.5 x 0.5			
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected						
Solid or stranded	mm <sup>2</sup>	2 x (0.5 2.5)	)			
Finely stranded without end sleeve	$mm^2$	2 x (0.5 2.5)	)			
<ul> <li>Finely stranded with end sleeve (DIN 46228-1)</li> </ul>	mm <sup>2</sup>	2 x (0.5 1.5)				
AWG cables, solid or stranded	AWG	2 x (20 14)				
Max. external diameter of the conductor insulation	mm	3.6				
Connection type		Ring ter	minal lug conn	ections		
Terminal screw		M3, Pozidriv s	ize 2			
Operating devices	mm	Ø 5 6				
Tightening torque	Nm	0.8 1.2				
Usable ring terminal lugs  DIN 46234 without insulation sleeve  DIN 46225 without insulation sleeve  DIN 46237 with insulation sleeve  JIS C2805 Type R without insulation sleeve  JIS C2805 Type RAV with insulation sleeve  JIS C2805 Type RAP with insulation sleeve	mm	d <sub>2</sub> = min. 3.2,	d <sub>3</sub> = max. 7.5			

# Terminals for "Self-Protected Combination Motor Controllers (Type E) according to UL 508/UL 60947-4-1"

Туре			3RV2928-1H
Prescribed tigh	tening torque	Nm	2.5 3
Conductor cros	ss-sections		
B0_00479	g point connected Solid Finely stranded with end sleeve Stranded AWG cables, solid or stranded Terminal screw	mm² mm² mm² AWG	1 10 1 16 2.5 25 14 3
	point connected		
SB0_00480	Solid Finely stranded with end sleeve Stranded AWG cables, solid or stranded Terminal screw	mm² mm² mm² AWG	1 10 1 16 1.5 25 14 6
Both clamping	points connected		
NSB0_00481	Front clamping point: Solid Finely stranded with end sleeve Stranded AWG cables, solid or stranded Terminal screw	mm² mm² mm² AWG	1 10 1 10 <sup>1)</sup> , 1 6 <sup>1)</sup> 2.5 10 14 6 M4
-	Rear clamping point: Solid Finely stranded with end sleeve Stranded AWG cables, solid or stranded Terminal screw	mm² mm² mm² AWG	1 10 1 10 <sup>1</sup> ), 1 16 <sup>1</sup> ) 2.5 10 16 3 M4


<sup>1)</sup> The following can be connected when both clamping points are connected:


- Front 1 ... 10 mm² and rear 1 ... 10 mm²
- Front 1 ... 6 mm<sup>2</sup> and rear 1 ... 16 mm<sup>2</sup>

For motor protection

## Selection and ordering data

## CLASS 10, without auxiliary switches<sup>1)</sup>













0AA10 3F
JAA10 3

RV2011-0EA20 3RV2

3RV2021-4AA10

3RV2021-4AA20

Rated current	Suitable for three-phase motors <sup>2)</sup> with <i>P</i>	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking capacity at 400 V AC		Screw terminals	<b></b>	DT	Spring-type terminals	
$I_{n}$		<b>G</b>	[ >	$I_{\mathrm{CU}}$		Article No.	Price per PU		Article No.	Price per PU
Α	kW	A	A	kA			perro			perro
Size S0	0									
0.16	0.04	0.11 0.16	2.1	100	<b></b>	3RV2011-0AA10		<b></b>	3RV2011-0AA20	
0.2	0.06	0.14 0.2	2.6	100	▶	3RV2011-0BA10		▶	3RV2011-0BA20	
0.25	0.06	0.18 0.25	3.3	100	▶	3RV2011-0CA10		▶	3RV2011-0CA20	
0.32	0.09	0.22 0.32	4.2	100	<b>&gt;</b>	3RV2011-0DA10		<b></b>	3RV2011-0DA20	
0.4	0.09	0.28 0.4	5.2	100	<b>&gt;</b>	3RV2011-0EA10		<b>&gt;</b>	3RV2011-0EA20	
0.5	0.12	0.35 0.5	6.5	100	<b>&gt;</b>	3RV2011-0FA10		<b>&gt;</b>	3RV2011-0FA20	
0.63 0.8	0.18 0.18	0.45 0.63 0.55 0.8	8.2 10	100 100	<b>&gt;</b>	3RV2011-0GA10 3RV2011-0HA10		<b>&gt;</b>	3RV2011-0GA20 3RV2011-0HA20	
1			13		-			-		
	0.25	0.7 1 0.9 1.25	13 16	100	<b>&gt;</b>	3RV2011-0JA10		<b>•</b>	3RV2011-0JA20	
1.25 1.6	0.37 0.55	1.1 1.6	21	100 100	<b>&gt;</b>	3RV2011-0KA10 3RV2011-1AA10		<b>&gt;</b>	3RV2011-0KA20 3RV2011-1AA20	
2	0.75	1.4 2	26	100		3RV2011-1AA10		<b>•</b>	3RV2011-1BA20	
2.5	0.75	1.8 2.5	33	100	<b>•</b>	3RV2011-1CA10		<b>&gt;</b>	3RV2011-1CA20	
3.2	1.1	2.2 3.2	42	100		3RV2011-1CA10		-	3RV2011-1CA20	
4	1.5	2.8 4	52	100		3RV2011-1EA10		•	3RV2011-1EA20	
5	1.5	3.5 5	65	100	▶	3RV2011-1FA10		<b></b>	3RV2011-1FA20	
6.3	2.2	4.5 6.3	82	100	<b></b>	3RV2011-1GA10		<b></b>	3RV2011-1GA20	
8	3	5.5 8	104	100	<b></b>	3RV2011-1HA10		<b>&gt;</b>	3RV2011-1HA20	
10	4	7 10	130	100	▶	3RV2011-1JA10		▶	3RV2011-1JA20	
12.5	5.5	9 12.5 10 <sup>3)</sup> 16	163	100	▶	3RV2011-1KA10		▶	3RV2011-1KA20	
16	7.5	10 <sup>3)</sup> 16	208	55	<b>&gt;</b>	3RV2011-4AA10		▶	3RV2011-4AA20	
Size S0										
0.63	0.18	0.45 0.63	8.2	100 N	EW B	3RV2021-0GA10		В	3RV2021-0GA20	
8.0	0.18	0.55 0.8	10	100 N	<i>EW</i> B	3RV2021-0HA10		В	3RV2021-0HA20	
1	0.25	0.7 1	13		<i>EW</i> B	3RV2021-0JA10		В	3RV2021-0JA20	
1.25	0.37	0.9 1.25	16		<i>EW</i> B	3RV2021-0KA10		В	3RV2021-0KA20	
1.6	0.55	1.1 1.6	21		EW B	3RV2021-1AA10		В	3RV2021-1AA20	
2	0.75	1.4 2	26		<i>EW</i> B	3RV2021-1BA10		В	3RV2021-1BA20	
2.5	0.75	1.8 2.5	33		EW B	3RV2021-1CA10		В	3RV2021-1CA20	
3.2	1.1	2.2 3.2	42		EW B	3RV2021-1DA10		В	3RV2021-1DA20	
4 5	1.5 1.5	2.8 4 3.5 5	52 65		EW B EW B	3RV2021-1EA10 3RV2021-1FA10		B B	3RV2021-1EA20 3RV2021-1FA20	
6.3	2.2	4.5 6.3 5.5 8	82 104		EW B EW B	3RV2021-1GA10		B B	3RV2021-1GA20	
8 10	3	5.5 8 7 10	130		EW B	3RV2021-1HA10 3RV2021-1JA10		В	3RV2021-1HA20 3RV2021-1JA20	
12.5	5.5	9 12.5	163		EW B	3RV2021-16A10		В	3RV2021-16A20	
16	7.5	10 <sup>3)</sup> 16	208	55	<b>&gt;</b>	3RV2021-4AA10		<b></b>	3RV2021-4AA20	
20	7.5	13 <sup>3)</sup> 20	260	55		3RV2021-4BA10		<b>&gt;</b>	3RV2021-4BA20	
22	11	16 <sup>3)</sup> 22 18 <sup>3)</sup> 25	286	55	<b>•</b>	3RV2021-4CA10		<b>&gt;</b>	3RV2021-4CA20	
25	11	18 <sup>3)</sup> 25	325	55	▶	3RV2021-4DA10		▶	3RV2021-4DA20	
28	15	23 28	364	55	<b></b>	3RV2021-4NA10		<b></b>	3RV2021-4NA20	
32 <sup>4)</sup>	15	27 32	400	55	<b>&gt;</b>	3RV2021-4EA10		<b></b>	3RV2021-4EA20	
Ε'										
36 <sup>5)</sup>	18.5	30 36	432	20	▶	3RV2021-4PA10				
40 <sup>5)</sup>	18.5	34 40	480	20	▶	3RV2021-4FA10				

The 3RV20.1-..A.0 motor starter protectors up to 32 A are also available with ring terminal lug connection. The Article No. must be changed in the 11th digit to "4": e.g. 3RV2011-0AA40.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).

<sup>&</sup>lt;sup>2)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.


<sup>3)</sup> The setting range of the thermal overload releases has been extended.

<sup>4)</sup> Suitable for use with IE3 motors up to a starting current of 256 A. For higher starting currents we recommend using 3RV2 motor starter protectors size S2.

<sup>5)</sup> The devices must not be mounted side-by-side and they must not be assembled with link modules with contactors. A lateral clearance of 9 mm is required. For use with IE3 motors we recommend using 3RV2 motor starter protectors size S2.

### For motor protection

#### CLASS 10, without auxiliary switches







3RV2031-4.A10

3RV2032-4.A10

Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking ca at 400 V AC	apacity	Screw terminals	<b></b>	PU (UNIT, SET, M)	PS*	PG
$I_{D}$		<b>G</b>	<i>I</i> >	$I_{\mathrm{CU}}$		Article No.	Price per PU			
Α	kW	A	A	kA			perro			
Size S2	2									
14	5.5	9.5 14	208	65	<i>NEW</i> A	3RV2031-4SA10		1	1 unit	41E
17	7.5	12 17	260	65	<i>NEW</i> A	3RV2031-4TA10		1	1 unit	41E
20	7.5	14 20	260 325	65	NEW A	3RV2031-4BA10		1	1 unit	41E
25	11	18 25		65	<i>NEW</i> A	3RV2031-4DA10		ı ı	1 unit	41E
32	15	22 32	416	65	<i>NEW</i> A	3RV2031-4EA10		1	1 unit	41E
36	18.5	28 36	520	65 65	NEW A	3RV2031-4PA10 3RV2031-4UA10		1	1 unit	41E 41E
40 45	18.5 22	32 40 35 45	585 650	65 65	NEW A	3RV2031-4VA10		1	1 unit 1 unit	41E 41E
52 59 <sup>2)</sup>	22 30	42 52 49 59	741 845	65 65	NEW A	3RV2031-4WA10 3RV2031-4XA10		1	1 unit 1 unit	41E 41E
65 <sup>2)</sup>	30	49 59 54 65	845	65	NEW X	3RV2031-4JA10		1	1 unit	41E 41E
73 <sup>2)</sup>	37	62 73	949	65	NEW X	3RV2031-4KA10		1	1 unit	41E
80 <sup>2)3)</sup>	37	70 80	1 040	65	NEW X	3RV2031-4RA10		1	1 unit	41E
Size S2	, with increase	d switching capacit	у							
14	5.5	9.5 14	208	100	NEW A	3RV2032-4SA10		1	1 unit	41E
17	7.5	12 17	260	100	<i>NEW</i> A	3RV2032-4TA10		1	1 unit	41E
20	7.5	14 20	260	100	<i>NEW</i> A	3RV2032-4BA10		1	1 unit	41E
25	11	18 25	325	100	<i>NEW</i> A	3RV2032-4DA10		1	1 unit	41E
32	15	22 32	416	100	<i>NEW</i> A	3RV2032-4EA10		1	1 unit	41E
36	18.5	28 36	520	100	<i>NEW</i> A	3RV2032-4PA10		1	1 unit	41E
40	18.5	32 40	585	100	<i>NEW</i> A	3RV2032-4UA10		1	1 unit	41E
45	22	35 45	650	100	<i>NEW</i> A	3RV2032-4VA10		1	1 unit	41E
52	22	42 52	741	100	NEW A	3RV2032-4WA10		1	1 unit	41E
59 <sup>2)</sup>	30	49 59	845	100	NEW X	3RV2032-4XA10		1	1 unit	41E
65 <sup>2)</sup> 73 <sup>2)</sup>	30 37	54 65 62 73	845	100	NEW X	3RV2032-4JA10		1	1 unit	41E 41E
80 <sup>2)3)</sup>	37 37	62 73 70 80	949 1 040	100 100	NEW X	3RV2032-4KA10 3RV2032-4RA10		1	1 unit 1 unit	41E 41E
00				100		UIII LUUL TIIM IU			I UIIIL	

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).


<sup>&</sup>lt;sup>2)</sup> Start of delivery on request.

<sup>3)</sup> Suitable for use with IE3 motors up to a starting current of 720 A. For higher starting currents we recommend using 3RV1 motor starter protectors

For motor protection

#### CLASS 10, with transverse auxiliary switch (1 NO + 1 NC)

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41E \end{array}$ 





3RV2011-4AA15 with integrated transverse auxiliary switch



3RV2011-0EA25 with integrated transverse auxiliary switch



3RV2021-4AA15 with integrated transverse auxiliary switch



3RV2021-4AA25 with integrated transverse auxiliary switch

Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking capacity at 400 V AC	DT	Screw terminals	<b>+</b>	DT	Spring-type terminals	8
$I_{N}$		G	<i>I</i> >	$I_{ m CU}$		Article No.	Price per PU		Article No.	Price per PU
Α	kW	A	A	kA			perro			perro
Size S0	0									
0.16	0.04	0.11 0.16	2.1	100	<b>&gt;</b>	3RV2011-0AA15		<b>&gt;</b>	3RV2011-0AA25	
0.2	0.06	0.14 0.2	2.6	100		3RV2011-0BA15			3RV2011-0BA25	
0.25 0.32	0.06 0.09	0.18 0.25 0.22 0.32	3.3 4.2	100 100		3RV2011-0CA15 3RV2011-0DA15		<b>&gt;</b>	3RV2011-0CA25 3RV2011-0DA25	
0.4	0.09 0.12	0.28 0.4 0.35 0.5	5.2	100		3RV2011-0EA15		<b>&gt;</b>	3RV2011-0EA25	
0.5 0.63	0.12	0.35 0.5	6.5 8.2	100 100		3RV2011-0FA15 3RV2011-0GA15			3RV2011-0FA25 3RV2011-0GA25	
0.8	0.18	0.55 0.8	10	100		3RV2011-0HA15		-	3RV2011-0GA25	
1	0.25	0.7 1	13	100	<u> </u>	3RV2011-0JA15		<u> </u>	3RV2011-0JA25	
1.25	0.23	0.7 1	16	100		3RV2011-05A15			3RV2011-05A25	
1.6	0.55	1.1 1.6	21	100	•	3RV2011-1AA15		<b>•</b>	3RV2011-1AA25	
2	0.75	1.4 2	26	100	<b>&gt;</b>	3RV2011-1BA15		<b></b>	3RV2011-1BA25	
2.5	0.75	1.8 2.5	33	100	<b></b>	3RV2011-1CA15		<b></b>	3RV2011-1CA25	
3.2	1.1	2.2 3.2	42	100	<b>&gt;</b>	3RV2011-1DA15		<b>&gt;</b>	3RV2011-1DA25	
4	1.5	2.8 4	52	100	<b>&gt;</b>	3RV2011-1EA15		<b></b>	3RV2011-1EA25	
5	1.5	3.5 5	65	100	<b>&gt;</b>	3RV2011-1FA15		<b></b>	3RV2011-1FA25	
6.3	2.2	4.5 6.3	82	100	<b>&gt;</b>	3RV2011-1GA15		<b>&gt;</b>	3RV2011-1GA25	
8	3	5.5 8	104	100	<b>&gt;</b>	3RV2011-1HA15		<b></b>	3RV2011-1HA25	
10	4	7 10	130	100	<b>&gt;</b>	3RV2011-1JA15		<b></b>	3RV2011-1JA25	
12.5 16	5.5 7.5	9 12.5 10 <sup>2)</sup> 16	163 208	100 55	<b>&gt;</b>	3RV2011-1KA15		<b>&gt;</b>	3RV2011-1KA25	
		10-7 16	208	55		3RV2011-4AA15			3RV2011-4AA25	
Size S0										
16	7.5	10 <sup>2)</sup> 16	208	55	<b>&gt;</b>	3RV2021-4AA15		<b>&gt;</b>	3RV2021-4AA25	
20	7.5	13 <sup>2)</sup> 20	260	55	<b>&gt;</b>	3RV2021-4BA15		<b></b>	3RV2021-4BA25	
22	11	16 <sup>2)</sup> 22	286	55	<b>•</b>	3RV2021-4CA15		<b>&gt;</b>	3RV2021-4CA25	
25	11	18 <sup>2)</sup> 25	325	55	<b></b>	3RV2021-4DA15		<b></b>	3RV2021-4DA25	
28 32 <sup>3)</sup>	15	23 28	364	55	<b>&gt;</b>	3RV2021-4NA15		<b></b>	3RV2021-4NA25	
32 <sup>3)</sup>	15	27 32	400	55	<b>&gt;</b>	3RV2021-4EA15		<b></b>	3RV2021-4EA25	
36 <sup>4)</sup>	18.5	30 36	432	20	•	3RV2021-4PA15				
40 <sup>4)</sup>	18.5	30 36	432 480	20 20		3RV2021-4PA15 3RV2021-4FA15			_	
+0	10.0	J+ 4U	400	20		31142021-4FA13				

1) Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

<sup>2)</sup> The setting range of the thermal overload releases has been extended.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).


<sup>3)</sup> Suitable for use with IE3 motors up to a starting current of 256 A. For higher starting currents we recommend using 3RV2 motor starter protectors size S2.

<sup>4)</sup> The devices must not be mounted side-by-side and they must not be assembled with link modules with contactors. A lateral clearance of 9 mm is required. For use with IE3 motors we recommend using 3RV2 motor starter protectors size S2.

SIRIUS 3RV2 Motor Starter Protectors up to 80 A

## For motor protection

#### CLASS 20, without auxiliary switches







3RV2031-4.B10

3RV2031-4WB10

Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking cap at 400 V AC	pacity	DT	Screw terminals	<b></b>	PU (UNIT, SET, M)	PS*	PG
I <sub>n</sub>	kW	日 A	[ <i>I</i> >	$I_{ m CU}$ kA			Article No.	Price per PU			
Size S2											
14 17 20 25	5.5 7.5 7.5 11	9.5 14 12 17 14 20 18 25	208 260 260 325	65 65 65 65	NEW NEW NEW NEW	A	3RV2031-4SB10 3RV2031-4TB10 3RV2031-4BB10 3RV2031-4DB10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
32 36 40 45	15 18.5 18.5 22	22 32 28 36 32 40 35 45	416 520 585 650	65 65 65 65	NEW NEW NEW NEW	A A	3RV2031-4EB10 3RV2031-4PB10 3RV2031-4UB10 3RV2031-4VB10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
52 59 <sup>2)</sup> 65 <sup>2)</sup>	22 30 30	42 52 49 59 54 65	741 845 845	65 65 65	NEW NEW	Χ	3RV2031-4WB10 3RV2031-4XB10 3RV2031-4JB10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).

<sup>2)</sup> Start of delivery on request.

For motor protection with overload relay function

#### Selection and ordering data

#### CLASS 10, with overload relay function (automatic RESET), without auxiliary switches



<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).

<sup>2)</sup> Accessories for mounting on the right and 3RV2915 three-phase busbars cannot be used.

<sup>&</sup>lt;sup>3)</sup> The setting range of the thermal overload releases has been extended.

<sup>4)</sup> Suitable for use with IE3 motors up to a starting current of 256 A. For higher starting currents we recommend using 3RV2 motor starter protectors size S2

<sup>5)</sup> Start of delivery on request.

<sup>6)</sup> Suitable for use with IE3 motors up to a starting current of 720 A. For higher starting currents we recommend using 3RV1 motor starter protectors size S3


## SIRIUS 3RV2 Motor Starter Protectors up to 80 A

## For starter combinations

#### Selection and ordering data

#### Without auxiliary switches

PU (UNIT, SET, M) = 1 PS\* PG = 1 unit = 41E











3RV2311-4AC10

3RV2311-0JC20

3RV2321-4AC10

3RV2321-4AC20

Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Thermal overload release <sup>2)</sup>	Instantaneous overcurrent release	Short-circuit breaking capacity at 400 V AC	у	Screw terminals	<b>+</b>	DT	Spring-type terminals	
$I_{n}$		[4]	<i>I</i> >	$I_{\mathrm{CU}}$		Article No.	Price per PU		Article No.	Price per PU
Α	kW	A	A	kA			perro			perro
Size S0	0									
0.16	0.04	Without	2.1	100	В	3RV2311-0AC10		В	3RV2311-0AC20	
0.2	0.06	Without	2.6	100	В	3RV2311-0BC10		В	3RV2311-0BC20	
0.25	0.06	Without	3.3	100	В	3RV2311-0CC10		В	3RV2311-0CC20	
0.32	0.09	Without	4.2	100	В	3RV2311-0DC10		В	3RV2311-0DC20	
0.4	0.09	Without	5.2	100	В	3RV2311-0EC10		В	3RV2311-0EC20	
0.5	0.12	Without	6.5	100	В	3RV2311-0FC10		В	3RV2311-0FC20	
0.63	0.18	Without	8.2	100	В	3RV2311-0GC10		В	3RV2311-0GC20	
8.0	0.18	Without	10	100	В	3RV2311-0HC10		В	3RV2311-0HC20	
1	0.25	Without	13	100	В	3RV2311-0JC10		В	3RV2311-0JC20	
1.25	0.37	Without	16	100	В	3RV2311-0KC10		В	3RV2311-0KC20	
1.6	0.55	Without	21	100	В	3RV2311-1AC10		В	3RV2311-1AC20	
2	0.75	Without	26	100	В	3RV2311-1BC10		В	3RV2311-1BC20	
2.5	0.75	Without	33	100	В	3RV2311-1CC10		В	3RV2311-1CC20	
3.2	1.1	Without	42	100	В	3RV2311-1DC10		В	3RV2311-1DC20	
4	1.5	Without	52	100	В	3RV2311-1EC10		В	3RV2311-1EC20	
5	1.5	Without	65	100	В	3RV2311-1FC10		В	3RV2311-1FC20	
6.3	2.2	Without	82	100	В	3RV2311-1GC10		В	3RV2311-1GC20	
8	3	Without	104	100	В	3RV2311-1HC10		В	3RV2311-1HC20	
10	4	Without	130	100	В	3RV2311-1JC10		В	3RV2311-1JC20	
12.5	5.5	Without	163	100	В	3RV2311-1KC10		В	3RV2311-1KC20	
16	7.5	Without	208	55	В	3RV2311-4AC10		В	3RV2311-4AC20	
Size S0										
1.6	0.55	Without	21		<b>W</b> B	3RV2321-1AC10		В	3RV2321-1AC20	
2	0.75	Without	26	100 NE	<b>W</b> B	3RV2321-1BC10		В	3RV2321-1BC20	
2.5	0.75	Without	33		<b>W</b> B	3RV2321-1CC10		В	3RV2321-1CC20	
3.2	1.1	Without	42		<b>W</b> B	3RV2321-1DC10		В	3RV2321-1DC20	
4	1.5	Without	52		<b>W</b> B	3RV2321-1EC10		В	3RV2321-1EC20	
5	1.5	Without	65	100 NE	<b>W</b> B	3RV2321-1FC10		В	3RV2321-1FC20	
6.3	2.2	Without	82		<b>W</b> B	3RV2321-1GC10		В	3RV2321-1GC20	
8	3	Without	104		<b>W</b> B	3RV2321-1HC10		В	3RV2321-1HC20	
10	4	Without	130		<b>W</b> B	3RV2321-1JC10		В	3RV2321-1JC20	
12.5	5.5	Without	163	100 NE	<b>W</b> B	3RV2321-1KC10		В	3RV2321-1KC20	
16	7.5	Without	208	55	В	3RV2321-4AC10		В	3RV2321-4AC20	
20	7.5	Without	260	55	В	3RV2321-4BC10		В	3RV2321-4BC20	
22	11	Without	286	55	В	3RV2321-4CC10		В	3RV2321-4CC20	
25	11	Without	325	55	В	3RV2321-4DC10		В	3RV2321-4DC20	
28	15	Without	364	55	В	3RV2321-4NC10		В	3RV2321-4NC20	
32 <sup>3)</sup>	15	Without	400	55	В	3RV2321-4EC10		В	3RV2321-4EC20	
4)										
36 <sup>4)</sup>	18.5	Without	432	20	В	3RV2321-4PC10				
40 <sup>4)</sup>	18.5	Without	480	20	В	3RV2321-4FC10			-	
1) 0			011 400 1/ 40		4) -	1 2 2				

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Size S2, see page 7/27.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).


 $<sup>^{2)}\,</sup>$  For overload protection of the motors, appropriate overload relays must be

<sup>3)</sup> Suitable for use with IE3 motors up to a starting current of 256 A. For higher starting currents we recommend using 3RV2 motor starter protectors size S2.

<sup>4)</sup> The devices must not be mounted side-by-side and they must not be assembled with link modules with contactors. A lateral clearance of 9 mm is required. For use with IE3 motors we recommend using 3RV2 motor starter protectors size S2.

For starter combinations

#### Without auxiliary switches (continued)











)	3RV2	2332-4.C	:10	ЗRV	2332-	4V

Screw	terminals	

Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Thermal overload release <sup>2)</sup>	Instantaneous overcurrent release	Short-circuit breaking ca at 400 V AC	pacity	DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
I <sub>n</sub>	1.147	Ē	[ >	$I_{\mathrm{CU}}$			Article No.	Price per PU			
A	kW	A	A	kA							
Size S2											
14	5.5	Without	208	65	NEW		3RV2331-4SC10		1	1 unit	41E
17 20	7.5 7.5	Without Without	260 260	65 65	NEW NEW		3RV2331-4TC10 3RV2331-4BC10		1	1 unit 1 unit	41E 41E
25	11	Without	325	65	NEW		3RV2331-4DC10		i	1 unit	41E
32	15	Without	416	65	NEW	Α	3RV2331-4EC10		1	1 unit	41E
36	18.5	Without	520	65	NEW		3RV2331-4PC10		1	1 unit	41E
40 45	18.5 22	Without Without	585 650	65 65	NEW NEW		3RV2331-4UC10 3RV2331-4VC10		1 1	1 unit 1 unit	41E 41E
	22	Without	741	65	NEW		3RV2331-4VC10 3RV2331-4WC10		1	1 unit	41E
52 59 <sup>3)</sup> 65 <sup>3)</sup> 73 <sup>3)</sup>	30	Without	845	65	NEW		3RV2331-4WC10 3RV2331-4XC10		1	1 unit	41E 41E
65 <sup>3)</sup>	30	Without	845	65	NEW		3RV2331-4JC10		i	1 unit	41E
73 <sup>3)</sup>	37	Without	949	65	NEW		3RV2331-4KC10		1	1 unit	41E
80 <sup>3)4)</sup>	37	Without	1 040	65	NEW	Х	3RV2331-4RC10		1	1 unit	41E
Size S2,	with increased s	witching capacit	У								
14	5.5	Without	208	100	NEW		3RV2332-4SC10		1	1 unit	41E
17 20	7.5 7.5	Without Without	260 260	100 100	NEW		3RV2332-4TC10 3RV2332-4BC10		1	1 unit 1 unit	41E 41E
25	7.5 11	Without	325	100	NEW NEW		3RV2332-4DC10		1	1 unit	41E
32	15	Without	416	100	NEW		3RV2332-4EC10		1	1 unit	41E
36	18.5	Without	520	100	NEW		3RV2332-4PC10		i	1 unit	41E
40	18.5	Without	585	100	NEW		3RV2332-4UC10		1	1 unit	41E
45	22	Without	650	100	NEW	Α	3RV2332-4VC10		1	1 unit	41E
52 59 <sup>3)</sup> 65 <sup>3)</sup> 73 <sup>3)</sup>	22	Without	741	100	NEW		3RV2332-4WC10		1	1 unit	41E
59 <sup>3</sup> )	30 30	Without Without	845 845	100 100	NEW NEW		3RV2332-4XC10 3RV2332-4JC10		1	1 unit	41E 41E
73 <sup>3</sup> )	30 37	Without	949	100	NEW		3RV2332-4JC10 3RV2332-4KC10		1	1 unit 1 unit	41E 41E
80 <sup>3)4)</sup>	37	Without	1 040	100	NEW		3RV2332-4RC10		i	1 unit	41E

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).

Without 1) Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

<sup>&</sup>lt;sup>2)</sup> For overload protection of the motors, appropriate overload relays must be

<sup>3)</sup> Start of delivery on request.

 $<sup>^{\</sup>rm 4)}$  Suitable for use with IE3 motors up to a starting current of 720 A. For higher starting currents we recommend using 3RV1 motor starter protectors

SIRIUS 3RV2 Motor Starter Protectors up to 80 A

### For transformer protection

#### Selection and ordering data

#### CLASS 10, without auxiliary switches

Motor starter protectors for the protection of transformers with high inrush current

PU(UNIT, SET, M) = 1PS<sup>3</sup> = 1 unitPG = 41E



NEW A

NEW A

*NEW* A

**NEW** A

NEW X

3RV2431-4EA10

3RV2431-4PA10

3RV2431-4UA10

3RV2431-4VA10

3RV2431-4WA10

3RV2431-4XA10

3RV2431-4JA10

65

65

65

65

65

656

820

820

922

1 025

1 332

22 ...

35 . 45

42 52

54 ... 65

28 ... 36

32 ... 40

49 ... 59

32

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).

40

45

52

 $65^{2}$ 

<sup>1)</sup> The setting range of the thermal overload releases has been extended.

<sup>2)</sup> Start of delivery on request.


## Motor Starter Protectors/Circuit Breakers SIRIUS 3RV2 Circuit Breakers up to 80 A

For system protection according to UL 489/CSA C22.2 No. 5

## Selection and ordering data

### Without auxiliary switches

Circuit breakers for system protection and non-motor loads according to UL/CSA





3RV2711-0AD10

Rated current <sup>1)</sup>	Thermal overload releases (non-adjustable)	Instantaneous overcurrent release	Short-circuit breaking capacity at 480 Y/277 V AC <sup>2)</sup>	DT	Screw terminals	<b></b>	PU (UNIT, SET, M)	PS*	PG
$I_n^{1)}$	G	<i>I</i> >	$I_{ t DC}$		Article No.	Price per PU			
Α	A	A	kA			per PU			
Size S00									
0.16 0.2 0.25 0.32	0.16 0.2 0.25 0.32	2.1 2.6 3.3 4.2	65 65 65 65	В В В В	3RV2711-0AD10 3RV2711-0BD10 3RV2711-0CD10 3RV2711-0DD10		1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
0.4 0.5 0.63 0.8	0.4 0.5 0.63 0.8	5.2 6.5 8.2 10	65 65 65 65	В В В	3RV2711-0ED10 3RV2711-0FD10 3RV2711-0GD10 3RV2711-0HD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
1 1.25 1.6 2	1 1.25 1.6 2	13 16 21 26	65 65 65 65	В В В В	3RV2711-0JD10 3RV2711-0KD10 3RV2711-1AD10 3RV2711-1BD10		1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
2.5 3.2 4 5	2.5 3.2 4 5	33 42 52 65	65 65 65 65	В В В В	3RV2711-1CD10 3RV2711-1DD10 3RV2711-1ED10 3RV2711-1FD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
6.3 8 10 12.5 15	6.3 8 10 12.5 15	82 104 130 163 208	65 65 65 65 65	B B B B	3RV2711-1GD10 3RV2711-1HD10 3RV2711-1JD10 3RV2711-1KD10 3RV2711-4AD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E
Size S0 20 22	20 22	260 286		NEW B	3RV2721-4BD10 3RV2721-4CD10		1	1 unit 1 unit	41E 41E

<sup>1)</sup> Rated value 100 % according to UL 489 and IEC 60947-2 ("100 % rated breaker").

Lateral and transverse auxiliary switches can be ordered separately (see "Accessories" from page 7/32 onwards).

<sup>&</sup>lt;sup>2)</sup> Values for 600 Y/347 V AC, see page 7/15.


SIRIUS 3RV2 Circuit Breakers up to 80 A

## For transformer protection according to UL 489/CSA C22.2 No.5

### Selection and ordering data

### Without auxiliary switches

Circuit breakers for system and transformer protection according to UL/CSA, specially designed for transformers with high inrush current





3RV2811-0AD10

Rated current <sup>1)</sup>	Thermal overload releases (non-adjustable)	Instantaneous overcurrent release	Short-circuit breaking capacity at 480 Y/277 V AC <sup>2)</sup>	DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
$I_{n}^{1)}$	[]	<i>I</i> >	$I_{ m bc}$		Article No.	Price per PU			
Α	А	Α	kA						
Size S00									
0.16 0.2 0.25 0.32	0.16 0.2 0.25 0.32	3.3 4.2 5.2 6.5	65 65 65 65	B B B	3RV2811-0AD10 3RV2811-0BD10 3RV2811-0CD10 3RV2811-0DD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
0.4 0.5 0.63 0.8	0.4 0.5 0.63 0.8	8.2 10 13 16	65 65 65 65	B B B	3RV2811-0ED10 3RV2811-0FD10 3RV2811-0GD10 3RV2811-0HD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
1 1.25 1.6 2	1 1.25 1.6 2	21 26 33 42	65 65 65 65	B B B	3RV2811-0JD10 3RV2811-0KD10 3RV2811-1AD10 3RV2811-1BD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
2.5 3.2 4 5	2.5 3.2 4 5	52 65 82 104	65 65 65 65	B B B	3RV2811-1CD10 3RV2811-1DD10 3RV2811-1ED10 3RV2811-1FD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
6.3 8 10 12.5 15	6.3 8 10 12.5 15	130 163 208 260 286	65 65 65 65 65	B B B B	3RV2811-1GD10 3RV2811-1HD10 3RV2811-1JD10 3RV2811-1KD10 3RV2811-4AD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E
Size S0 20 22	20 22	325 364		NEW B	3RV2821-4BD10 3RV2821-4CD10		1	1 unit 1 unit	41E 41E

<sup>1)</sup> Rated value 100 % according to UL 489 and IEC 60947-2 ("100 % rated breaker").

Lateral and transverse auxiliary switches can be ordered separately (see "Accessories" from page 7/32 onwards).

<sup>&</sup>lt;sup>2)</sup> Values for 600 Y/347 V AC, see page 7/15.

## Motor Starter Protectors/Circuit Breakers SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

Mountable accessories

## Overview

#### Mounting location and function

The 3RV2 motor starter protectors/circuit breakers have three main contact elements. In order to achieve maximum flexibility, auxiliary switches, signaling switches, auxiliary releases and isolator modules can be supplied separately.

These components are easily fitted to the switches without the use of any tools according to requirements.

Overview graphic, see page 7/7.

isolator modules can be supplied separa	ately.	Overview graphile, see page 1/1.						
Front side Note:  • A maximum of four auxiliary contacts with auxiliary switches can be mounted on each motor starter protector/circuit breaker.	Transverse auxiliary switches, solid-state compatible transverse auxiliary switches 1 NO + 1 NC or 2 NO or 1 CO	An auxiliary switch block can be inserted transversely on the front. The overall width of the motor starter protectors/circuit breakers remains unchanged.						
Left-hand side  Notes:  A maximum of four auxiliary contacts with auxiliary switches can be mounted on each motor starter protector/circuit breaker.  Lateral auxiliary switches (two contacts) and signaling switches can be mounted	Lateral auxiliary switches (2 contacts) 1 NO + 1 NC or 2 NO or 2 NC	One of the three lateral auxiliary switches can be mounted on the left side per motor starter protector/circuit breaker. The contacts of the auxiliary switch close and open together with the main contacts of the motor starter protector/circuit breaker.  The width of the lateral auxiliary switch with two contacts is 9 mm.						
separately or together.  The signaling switch cannot be used for the 3RV27 and 3RV28 circuit breakers.	Lateral auxiliary switches (4 contacts) 2 NO + 2 NC	One lateral auxiliary switch with four contacts can be mounted on the side per motor starter protector/circuit breaker. The contacts of the au switch close and open together with the main contacts of the motor st protector/circuit breaker.  The width of the lateral auxiliary switch with four contacts is 18 mm.						
	Signaling switches	One signaling switch can be mounted on the left side of each motor starter						
	Tripping 1 NO + 1 NC	protector.						
	Short circuit 1 NO + 1 NC	The signaling switch has two contact systems.  One contact system always signals tripping irrespective of whether this was caused by a short circuit, an overload or an auxiliary release. The other contact system only switches in the event of a short circuit. There is no signaling as a result of <a href="switching off">switching off</a> with the actuator.  In order to be able to switch on the motor starter protector again after a short						
		circuit, the signaling switch must be reset manually after the error cause has been eliminated.						
		The overall width of the signaling switch is 18 mm.						
Right-hand side	Auxiliary releases							
Notes:  One auxiliary release can be mounted per motor starter protector/circuit breaker.  Accessories cannot be mounted at the	Shunt releases	For remote-controlled tripping of the motor starter protector/circuit breake The release coil should only be energized for short periods (see circuit diagrams).						
right-hand side of the 3RV21 motor starter	or							
protectors for motor protection with overload relay function.	Undervoltage releases	Trips the motor starter protector/circuit breaker when the voltage is inter- rupted and prevents the motor from being restarted accidentally when the voltage is restored. Used for remote-controlled tripping of the motor start protector/circuit breaker.						
		Particularly suitable for EMERGENCY-STOP disconnection by way of cor sponding EMERGENCY-STOP pushbuttons according to DIN EN 60204-						
	or							
	Undervoltage releases with leading auxiliary contacts 2 NO	Function and use as for the undervoltage release without leading auxiliary contacts, but with the following additional function: the auxiliary contacts will open in switch position OFF to deenergize the coil of the undervoltage release, thus interrupting energy consumption. In the "tripped" position, these auxiliary contacts are not guaranteed to open. The leading contacts permit the motor starter protector/circuit breaker to reclose.						
		The overall width of the auxiliary release is 18 mm.						
Top Notes:	Isolator modules	Isolator modules can be mounted to the upper connection side of the motor starter protectors.						
The isolator module cannot be used for the 3RV27 and 3RV28 circuit breakers.		The supply cable is connected to the motor starter protector through the isolator module.						
The isolator module for size S2 can only be used with 3RV2 motor starter protectors/circuit breakers up to max. 65 A cannot be used with the transverse auxiliary switch		The plug can only be unplugged when the motor starter protector is open and isolates all 3 poles of the motor starter protector from the network. The shock-protected isolation point is clearly visible and secured with a padlock to prevent reinsertion of the plug.						
The isolator module covers the terminal screws of the transverse auxiliary switch. If the isolator module is used, we therefore recommend that either the lateral auxiliary switches be fitted or that the isolator module not be mounted until the auxiliary switch has been wired.								

For a complete overview of which accessories can be used for the various motor starter protectors/circuit breakers, see page 7/2.

the auxiliary switch has been wired.

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

## Mountable accessories

#### Selection and ordering data

PU (UNIT, SET, M) = 1

PS\* PG = 1 unit (unless otherwise specified)

= 41E

1 U	- 41L								
		Version	For motor starter protectors/ circuit breakers	DT	Screw terminals	<b>+</b>	DT	Spring-type terminals	
			Size		Article No.	Price per PU		Article No.	Price per PU
Auxiliary switch	hes <sup>1)</sup>								
	_	Transverse auxiliary switch	es						
Ct. Ct. Avan		For front mounting	000 00						
0000	l	1 CO 1 NO + 1 NC <sup>2)</sup>	S00 S2	<b>&gt;</b>	3RV2901-1D 3RV2901-1E		<b></b>	 3RV2901-2E	
3RV2901-1E		2 NO		<b>&gt;</b>	3RV2901-1F		▶	3RV2901-2F	
3RV2901-2E		Electronic compatible transverse auxiliary switches Mountable on the front, for operation in dusty							
6 6 6	l	atmosphere and in electronic circuits with low operating currents							
3RV2901-1G		1 CO	S00 S2	Α	3RV2901-1G				
	ı	Covers for transverse auxiliary switches (PKG* = 10 units)	S00 S2	•	3RV2901-0H				
3RV2901-0H									
		Lateral auxiliary switches Mountable on the left 1 NO + 1 NC <sup>2)</sup> 2 NO 2 NO 2 NC 2 NO + 2 NC	S00 S2	A A	3RV2901-1A 3RV2901-1B 3RV2901-1C 3RV2901-1J		<b>* * *</b>	3RV2901-2A 3RV2901-2B 3RV2901-2C 	
3RV2901-1A 3F	RV2901-2A								
Signaling switch	hes <sup>3)</sup>								
		Signaling switches <sup>2)</sup> One signaling switch can be mounted on the left per motor starter protector. Separate tripped and short-circuit alarms, 1 NO + 1 NC each	S00 S2	•	3RV2921-1M		<b>&gt;</b>	3RV2921-2M	
3RV2921-1M 3F	RV2921-2M								
Isolator module	5 /	Isolator modules <sup>4)</sup>	S00, S0	<b>—</b>	3RV2928-1A			_	
3RV/2928-1A 25	RV2938-1A	Visible isolating distance for isolating individual motor starter protectors from the network, lockable in disconnected position	\$2 <sup>4)</sup> <b>NEV</b>	A	3RV2938-1A			-	
3RV2928-1A 3F	1V∠930-1A			3) Th:			l	1/07 and 2D1/00 aires	

- 1) Each motor starter protector/circuit breaker can be fitted with one transverse and one lateral auxiliary switch. The lateral auxiliary switch with 2 NO + 2 NC is used without a transverse auxiliary switch.
- $^{2)}$  The 3RV29 auxiliary and signaling switches with 1 NO + 1 NC are also available with ring terminal lug connection. The Article No. must be changed in the 8th digit to "4": e.g. 3RV2901-4E.
- 3) This accessory cannot be used for the 3RV27 and 3RV28 circuit breakers.
- <sup>4)</sup> The isolator module for size S2 can be used only with 3RV2 motor starter protectors/circuit breakers up to max. 65 A. Similarly, it cannot be used with the transverse auxiliary switch.

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

**Mountable accessories** 

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41E \end{array}$ 









3RV2902-1AV0 3RV2902-2AV0

3RV2922-1CP0

3RV2902-2DB0

Rated co	ontrol supp	oly voltage U <sub>s</sub>			For motor	DT	Screw terminals	<b>(1)</b>	DT	Spring-type	8
AC 50 Hz	AC 60 Hz	AC 50/60 Hz 100 % ON period <sup>1)</sup>	AC/DC 50/60 Hz, DC 5 s ON period <sup>2)</sup>	DC	starter protectors/ circuit breakers					terminals	
V	V	V	V	V	Size		Article No.	Price per PU		Article No. Pr	
Auxilia	ry releas	ses <sup>3)</sup>									
	ltage rele										
 24 110  230 400	 120 208 240 440	   	   	24    	S00 S2 S00 S2 S00 S2 S00 S2 S00 S2 4) S00 S2 4)	A A A	3RV2902-1AB4 3RV2902-1AB0 3RV2902-1AF0 3RV2902-1AM1 3RV2902-1AP0 3RV2902-1AV0		<b>A A</b>	   3RV2902-2AP0 3RV2902-2AV0	
415 500	480 600				S00 S2 S00 S2	A A	3RV2902-1AV1 3RV2902-1AS0			- -	
	ltage rele	eases with leading 3 2 NO									
24 230 400 415	24 240 440 480	  	  	  	S00 S2 S00 S2 S00 S2 S00 S2 4)	B A A	3RV2922-1CB0 3RV2922-1CP0 3RV2922-1CV0 3RV2922-1CV1		A A A	3RV2922-2CP0 3RV2922-2CV0 3RV2922-2CV1	
Shunt re	eleases										
   	   	20 24 90 110 210 240 350 415 500	20 70 70 190 190 330 330 500 500	   	\$00 \$2 \$00 \$2 4) \$00 \$2 4) \$00 \$2 \$00 \$2	A A A	3RV2902-1DB0 3RV2902-1DF0 3RV2902-1DP0 3RV2902-1DV0 3RV2902-1DS0		A A	3RV2902-2DB0 3RV2902-2DF0 3RV2902-2DP0 	

<sup>1)</sup> The voltage range is valid for 100 % (infinite) ON period. The response voltage lies at 0.9 of the lower limit of the voltage range.

<sup>2)</sup> The voltage range is valid for 5 s ON period at AC 50/60Hz and DC. The response voltage lies at 0.85 of the lower limit of the voltage range.

<sup>3)</sup> One auxiliary release can be mounted on the right per motor starter protector/circuit breaker (does not apply to 3RV21 motor starter protectors with overload relay function).

<sup>4)</sup> The 3RV29 auxiliary releases are also available with ring terminal lug connection. The Article No. must be changed in the 8th digit to "4": e.g. 3RV2902-4APO.

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

Accessories

#### **Busbar accessories**

#### Overview


#### Insulated three-phase busbar system

Three-phase busbar systems provide an easy, time-saving and clearly arranged means of feeding 3RV2 motor starter protector/ circuit breakers with screw terminals. Different versions are available for sizes S00 to S2 and can be used for the various different types of motor starter protectors/circuit breakers (size S0 up to 32 A).


The 3RV1915 and 3RV1935 three-phase busbar systems are generally unsuitable for the 3RV21 motor starter protectors for motor protection with overload relay function and 3RV27 and 3RV28 circuit breakers according to UL 489/CSA C22.2 No. 5.

The busbars are suitable for between two and five motor starter protectors/circuit breakers. However, any kind of extension is possible by clamping the tags of an additional busbar (rotated by 180°) underneath the terminals of the respective last motor starter protector/circuit breaker.

A combination of motor starter protectors/circuit breakers of size S00 and S0 is possible. The motor starter protectors/circuit breakers are supplied by appropriate infeed terminals.



SIRIUS three-phase busbar system size S00/S0



SIRIUS three-phase busbar system size S2

The three-phase busbar systems are finger-safe. They are designed for any short-circuit stress which can occur at the output side of connected motor starter protectors/circuit breakers.

The three-phase busbar systems can also be used to construct "Type E Starters" according to UL/CSA. Special infeed terminals must be used for this purpose, however (see "Selection and Ordering Data", page 7/35).


#### 8US busbar adapters for 60 mm systems

The motor starter protectors/circuit breakers are mounted directly with the aid of busbar adapters on busbar systems with 60 mm center-to-center clearance in order to save space and to reduce infeed times and costs.

The busbar adapters for busbar systems with 60 mm center-tocenter clearance are suitable for copper busbars with a width of 12 mm to 30 mm. The busbars can be 5 mm or 10 mm thick.

The motor starter protectors/circuit breakers are snapped onto the adapter and connected on the line side. This prepared unit is then plugged directly onto the busbar system, and is thus connected both mechanically and electrically at the same time.

For further busbar adapters for snap-mounting direct-on-line starters and reversing starters as well as additional accessories such as line terminals and outgoing terminals, flat copper profile, etc., see Catalog LV 10 "Low-Voltage Power Distribution and Electrical Installation Technology".



SIRIUS load feeders with busbar adapters snapped onto busbars

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

**Busbar accessories** 

## Selection and ordering data

	Modular spacing		of motor starte can be conne		Rated current In		DT	Article No.	Price per PU	PU (UNIT,	PS*	PG
		Without lateral accessories	With lateral auxiliary switch	With auxiliary release	at 690 V	protectors				SET, M)		
	mm				Α	Size						
Three-phase bu	ısbars <sup>1)</sup>											
AAA AAA	mounted		motor starter de on standar on									
3RV1915-1AB	45 <sup>3)</sup>	2			63 63	S00, S0 <sup>2)</sup> S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-1AB 3RV1915-1BB		1	1 unit 1 unit	41E 41E
A LANGE TO THE REAL PROPERTY OF THE PARTY OF		4 5			63 63	S00, S0 <sup>2)</sup> S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-1CB 3RV1915-1DB		1 1	1 unit 1 unit	41E 41E
3RV1915-1BB	55 <sup>4)</sup>		2 3		63 63	S00, S0 <sup>2)</sup> S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-2AB 3RV1915-2BB		1	1 unit 1 unit	41E 41E 41F
			4 5		63 63	S00, S0 <sup>2)</sup> S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-2CB 3RV1915-2DB		1	1 unit 1 unit	41E 41E
3RV1915-1CB	ñ	2 3			108 108	S2 S2	<b>&gt;</b>	3RV1935-1A 3RV1935-1B		1	1 unit 1 unit	41E 41E
MANAGE PROPERTY.	63 <sup>5)</sup>	4		2	108 63	S2 S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1935-1C 3RV1915-3AB		1	1 unit 1 unit	41E 41E
ODV404E 4DD	5 A R			4	63	S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-3CB		1	1 unit	41E
3RV1915-1DB	75 <sup>5)</sup>		2 3 4	2 3 4	108 108 108	S2 S2 S2	<b>&gt; &gt; &gt;</b>	3RV1935-3A 3RV1935-3B 3RV1935-3C		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E

- Not suitable for 3RV21 motor starter protectors for motor protection with overload relay function and for 3RV27 and 3RV28 circuit breakers according to UL 489/CSA C22.2 No. 5.
- $^{2)}$  Approved for motor starter protectors size S0 with  $I_{\rm N}\, \leq 32$  A.
- 3) For 3RV2 motor starter protectors without accessories mounted on the side.
- <sup>4)</sup> For 3RV2 motor starter protectors with auxiliary switches with 1 NO + 1 NC, 2 NO and 2 NC mounted on the left (9 mm wide).
- 5) For 3RV2 motor starter protectors with mounted accessories (18 mm wide). Auxiliary switches with 2 NO + 2 NC or signaling switch (mounted on the left) or with auxiliary release (mounted on the right).

on the side.										
	Conductor c	ross-section		Tightening	For motor	DT		ice PU	PS*	PG
	Solid or stranded	Finely stranded with end sleeve	AWG cables, solid or stranded	torque	starter protectors/ circuit breakers		per	PU (UNIT, SET, M)		
	mm²	mm²	AWG	Nm	Size					
Three-phase infee	d terminals									
889	Connection	from top								
000	2.5 25	2.5 16	10 4	3 4	S00, S0	<b>&gt;</b>	3RV2925-5AB	1	1 unit	41E
PIN PIN PI	2 x	2 x (2.5 35) <sup>1)</sup> ,	2 x (10 1/0) <sup>1)</sup> ,	4 6	S2 NEW	Α	3RV2935-5A	1	1 unit	41E
3RV2925-5AB	1 x	(2.5 35) <sup>1</sup> / <sub>1</sub> , 1 x (2.5 50) <sup>1</sup> )	1 x							
	( ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' '	(	( - , - ,							
3RV2935-5A	Connection	from bolow								
4 4 4	This termina		in place of a s count.	witch, please	take the					
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	2.5 25	2.5 16	10 4	Input: 4, Output: 2 2.5	S00, S0	•	3RV2915-5B	1	1 unit	41E
3RV2915-5B										
Three-phase infee			cting "Type	E Starters	1					
	Connection	•								
25-5-1	2.5 25	2.5 16	10 4	3 4	S00, S0	A	3RV2925-5EB	1	1 unit	41E
	2 x (2.5 50) <sup>1),</sup>	2 x (2.5 35) <sup>1)</sup> ,		4 6	S2 <b>NEW</b>	А	3RV2935-5E	1	1 unit	41E
3RV2925-5EB	1 x (2.5 70) <sup>1)</sup>	1 x (2.5 50) <sup>1)</sup>	1 x (10 2/0) <sup>1)</sup>							

<sup>3</sup>RV2935-5E

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

## **Busbar accessories**

	Version	For motor starter protectors/ circuit breakers Size	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Covers for conne	ction tags							
	Touch protection for empty positions	S00, S0	<b>&gt;</b>	3RV1915-6AB		1	10 units	41E
A MANAGARA		S2	<b>&gt;</b>	3RV1935-6A		1	5 units	41E
3RV1915-6AB								
Ruchar adantere								

#### Busbar adapters









					4	V							
8US1251-5DS10		8US1251-5DT11				8US	1250-	5AS10	8US1250-5AT10				
For motor starter protectors/ circuit breakers	Rated current	Connecting cable	Adapter length	Adapter width	Rated ve	oltage	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG	
Size	Α	AWG	mm	mm	V								
Busbar adapters for	or 60 mm sys	stems											
For flat copper profiles Width: 12 mm and 30 mm. Thickness: 5 mm and also for T and double-	mm 10 mm												
For motor starter pro	tectors/circuit b	reakers with	screw term	inals				Screw terminals	<b>+</b>				
S00, S0	25	12	200	45	690		<b>&gt;</b>	8US1251-5DS10		1	1 unit	140	
S0	32	10	260	45	690		<b>&gt;</b>	8US1251-5NT10		1	1 unit	140	
S2	80	4	200	55	690	NEW	Α	8US1261-5MS13		1	1 unit	140	
S2	80	4	260	55	690	NEW	Α	8US1261-6MT10		1	1 unit	140	
S2 <sup>1)</sup>	80	4	260	118	690	NEW	Α	8US1211-6MT10		1	1 unit	140	
For motor starter pro	tectors/circuit b	reakers with	spring-type	terminals				Spring-type terminals					
S00, S0	25	12	200	45	690		<b></b>	8US1251-5DS11		1	1 unit	140	
S00, S0	25	12	260	45	690		<b>&gt;</b>	8US1251-5DT11		1	1 unit	140	
S0	32	10	260	45	690		<b>&gt;</b>	8US1251-5NT11		1	1 unit	140	
Accessories													
Device holders			200	45			<b></b>	8US1250-5AS10		1	1 unit	140	
For lateral mounting to busbar adapters			260	45			<b></b>	8US1250-5AT10		1	1 unit	140	
Side modules For widening of busbar adapters			200	9			А	8US1998-2BJ10		1	10 units	140	
Spacers For fixing the load feeder onto the busbar adapter							<b>&gt;</b>	8US1998-1BA10		1	50 units	140	
Vibration and shock kits For high vibration and shock loads													
S00/S0							<b>&gt;</b>	8US1998-1CA10		1	2 units	140	
S2						NEW	Α	8US1998-1DA10	20.40	1	1 unit	140	
1) =													

 $<sup>^{1)}\,</sup>$  For the assembly of feeders for reversing starters comprising a motor starter protector and two contactors.

For additional busbar adapters, see Catalog LV 10 "Low-Voltage Power Distribution and Electrical Installation Technology".


SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories


**Rotary operating mechanisms** 

#### Overview

#### Door-coupling rotary operating mechanisms

Motor starter protectors/circuit breakers with a rotary operating mechanism can be mounted in a control cabinet and operated externally by means of a door-coupling rotary operating mechanism. When the cabinet door with motor starter protector/circuit breaker is closed, the operating mechanism is coupled. When the motor starter protector/circuit breaker closes, the coupling is locked which prevents the door from being opened unintentionally. This interlock can be defeated by the maintenance personnel. In the OPEN position, the rotary operating mechanism can be secured against reclosing with up to three padlocks. Inadvertent opening of the door is not possible in this case either.





SIRIUS 3RV2926-2B door-coupling rotary operating mechanisms for arduous conditions

SIRIUS 3RV2926-0K door-coupling rotary operating mechanism

#### Selection and ordering data

Version	Color of handle	Version of extension shaft	For motor starter protectors/ circuit breakers	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		mm	Size						

#### Door-coupling rotary operating mechanisms



The door-coupling rotary operating mechanisms consist of a knob, a coupling driver and a 130/330 mm long extension shaft

The door-coupling rotary operating mechanisms are designed to degree of protection IP64. The door locking device prevents accidental opening of the control cabinet door in the ON position of the motor starter protector/circuit breaker. The OFF position can be locked with up to three padlocks.

Door-coupling rotary operating mechanisms	Black	130 330	S00 S2 S00 S2	<b>&gt;</b>	3RV2926-0B 3RV2926-0K	1	1 unit 1 unit	
EMERGENCY-STOP door-coupling rotary operating mechanisms	Red/yellow	130 330	S00 S2 S00 S2	•	3RV2926-0C 3RV2926-0L	1	1 unit 1 unit	—

#### Door-coupling rotary operating mechanisms for arduous conditions



The door-coupling rotary operating mechanisms consist of a knob, a coupling driver, an extension shaft of 300 mm in length (8 mm x 8 mm), a spacer and two metal brackets, into which the motor starter protector/circuit breaker is inserted.

The door-coupling rotary operating mechanisms are designed to degree of protection IP65. The door interlocking reliably prevents opening of the control cabinet door in the ON position of the motor starter protector/circuit breaker. The OFF position can be locked with up to three padlocks.

Laterally mountable auxiliary releases and two-pole auxiliary switches can be used.

3RV2926-2B	
	1
·	

The door-coupling rota	ary operating	mechanisms thus	s meet the i	requiren	nents	for isolating functions according	g to IEC 60	947-2.	
Door-coupling	Gray	300	S00, S0		3RV2926-2B		1	1 unit	41E
rotary operating mechanisms			S2	NEW	<b>&gt;</b>	3RV2936-2B	1	1 unit	41E
EMERGENCY STOP	Red/yellow	300	S00, S0		<b>&gt;</b>	3RV2926-2C	1	1 unit	41E
door-coupling rotary operating mechanisms			S2	NEW	•	3RV2936-2C	1	1 unit	41E

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

Accessories


#### **Mounting accessories**

#### Overview


#### Accessories for "Self-Protected Combination Motor Controllers (Type E)" according to UL 508/UL 60947-4-1

The 3RV20 motor starter protectors with screw terminals are approved according to UL 508/UL 60947-4-1 as "Self-Protected Combination Motor Controllers (Type E)".

This requires increased clearance and creepage distances (1 inch and 2 inches respectively) at the input side of the device, which are achieved by mounting a terminal block or a phase barrier.



SIRIUS 3RV2928-1H terminal block



SIRIUS 3RV2938-1K phase barrier

Motor starter protectors/ circuit breakers	Size	Essential accessories for "Self-Protected Combination Motor Controllers (Type E)" according to UL 508/UL 60947-4-1
3RV201., 3RV202.	S00/S0	3RV2928-1H terminal block or 3RV2928-1K phase barrier
3RV2031-4B1., 3RV2031-4D.1., 3RV2031-4E1., 3RV2031-4F1., 3RV2031-4F1., 3RV2031-4T1., 3RV2031-4U.1., 3RV2031-4V.1.	\$2	
3RV2031-4J.1., 3RV2031-4K.1., 3RV2031-4R.1., 3RV2031-4W.1., 3RV2031-4X.1., 3RV2032	S2	3RV2938-1K phase barrier

-- No accessories needed

Special three-phase infeed terminals are required for constructing "Type E Starters" with an insulated three-phase busbar system (see "Busbar Accessories", page 7/35).

The 3RV29 infeed system also enables the assembly of "Type E Starters", see page 7/46 onwards.

#### Note:

According to CSA, these terminal blocks and the phase barriers can be omitted when the device is used as a "Self-Protected Combination Motor Controller (Type E)".

#### Link modules

Feeders can be easily assembled from single devices with the help of the link modules. The following table shows the different combination options for devices with screw or spring-type terminals.

Combination devices	3RV2	3RT2 contactors;	Link modules	
aevices	motor starter protec- tors/ circuit breakers	3RW30, 3RW40 soft starters; 3RF34 solid-state contactors	Screw terminals	Spring-type terminals
	Size	Size		
Link modules protectors/cire	for connection to the contract of the contract	cting switching dev ers <sup>1)</sup>	vices to 3RV2 n	notor starter
3RT2 contactors with AC or	S00	S00	3RA1921- 1DA00	3RA2911- 2AA00
DC coil	S0	S00	_	
	S2	S2	3RA2931- 1AA00	
3RT2 contactors with	S0	S0	3RA2921- 1AA00	3RA2921- 2AA00
AC coil	S00	S0		
3RT2 contactors with	S0	S0	3RA2921- 1BA00	3RA2921- 2AA00
DC coil	S00	S0	_	
3RW30 soft starters	S00	S00	3RA2921- 1BA00	3RA2911- 2GA00
	S0	S00	_	
3RW30/ 3RW40	S0	SO	3RA2921- 1BA00	3RA2921- 2GA00
soft starters	S00	S0	_	
	S2 <sup>2)</sup>	S2 <sup>2)</sup>	3RA2931- 1AA00	
3RF34 solid- state contac- tors	S00/S0	S00	3RA2921- 1BA00	
	RV2 motor	connecting contact starter protectors		
3RT2 contactors with AC or		S00	3RA2911- 2FA00	
DC coil	S0	SO	3RA2921- 2FA00	

- Version not possible
- 1) The link modules cannot be used for the 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV2.31-4K.1., 3RV2.31-4R.1., 3RV2.32-4K.1., 3RV2.32-4R.1., 3RV27 and 3RV28 motor starter protectors/circuit breakers.
- 2) To assemble the feeder between a motor starter protector and a soft starter in size S2, the 3RA2932-1AC00 standard mounting rail adapter must be
- 3) The motor starter protector to contactor hybrid link modules cannot be used for the 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV27 and 3RV28 motor starter protectors/circuit breakers. They are only suitable for constructing direct-on-line starters.

#### Note:

- Link modules can be used in
  - Sizes S00 and S0: up to max. 32 A
  - Size S2: up to max. 65 A
- Hybrid link modules can be used in
  - Sizes S00 and S0: up to max. 32 A

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

**Mounting accessories** 

# Selection and ordering data

#### Accessories

	Version	For motor sta protectors/ circuit breake		T	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		Size							
Covers									
3RV2908-0P	Scale covers Sealable, for covering the set current scale	3RV20, 3RV2 3RV24: S00 S2	21, ▶	•	3RV2908-0P		100	10 units	41E
311/23/0-01	Covers for devices with screw terminals (box terminals) Additional touch protection for fastening to the box terminals (2 units required per device)				Screw terminals	<b>+</b>			
3RT2936-4EA2	Main current level	S2	<i>NEW</i> B	3	3RT2936-4EA2		1	1 unit	41B
UNU	Covers for devices with ring terminal lug connection (ensure finger-safety)				Ring terminal lug connections	<b>(1)</b>			
	Main current level	3RV20:	В	3	3RV2928-4AA00		1	1 unit	41E
3RV2928-4AA00	<ul> <li>For transverse auxiliary switches</li> </ul>	S00, S0	В	3	3RV2908-4AA10		1	1 unit	41E
3RV2908-4AA10									
Fixing accessories	s								
3RV2928-0B	Push-in lugs For screwing the motor starter protector/ circuit breakers onto mounting plates For each motor starter protector/circuit breakers, two units are required.	S00, S0	А		3RV2928-0B		100	10 units	41E
Tools for opening	spring-type terminals								
	Screwdrivers For all SIRIUS devices with spring-type te	rminals			Spring-type terminals	8			
3RA2908-1A	Length approx. 200 mm, 3.0 mm x 0.5 mm, titanium gray/black, partially insulated	S00 S2	А	١	3RA2908-1A		1	1 unit	41B
Terminal blocks a	nd phase barriers for "Self-Protecte	ed							

# nation Motor Controllers (Type E)" according to UL 508/UL 60947-4-1



UL 508/UL 60947-4-1 approval demands 1-inch clearance and 2-inch creepage distance for "Self-Protected Combination Motor Controllers (Type E)". The following terminal blocks or phase barriers must be used for the 3RV20 motor starter protectors with screw terminals. The construction of 3RV20 motor starter protectors with spring-type terminals with the 3RV29 infeed system is also approved as "Self-Protected Combination Motor Controllers (Type E)" according to UL 508/UL 60947-4-1.

The terminal block or phase barriers cannot be used in combination with the 3RV19.5 three-phase busbars.



3RV2928-1K



For construction with three-phase busbar	s, see Busba	ir Accessorie	es page 7/34 onwards.			
Terminal blocks type E For extended clearance and creepage distances (1 and 2 inch)	S00, S0	•	3RV2928-1H	1	1 unit	41E
Phase barriers	S00, S0	▶	3RV2928-1K	1	1 unit	41E
For extended clearance and creepage distances (1 and 2 inch)	\$2	NEW A	3RV2938-1K	1	1 unit	41E

# SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

For mechanical and electrical connection between motor

S00/S0

S00/S0

S00/S0

S00/S0

S00/S0

S00/S0

S2

S2

starter protector and contactor with screw terminals

S2

S00

S0

S0

S2

Multi-unit packaging

AC/DC

AC/DC

AC DC AC/DC

#### Accessories

**Mounting accessories** 

#### Link modules

Actuating voltage of	Size		DT	Article No.	Price	PU	PS*	PG
contactor	3RT2 contactors	3RV2 motor starter protectors/ circuit breakers			per PU	(UNIT, SET, M)		

Α

Α

Α

*NEW* A

*NEW* A

Screw terminals

3RA1921-1DA00

3RA2921-1AA00

3RA2921-1BA00

3RA2931-1AA00

3RA1921-1D

3RA2921-1A

3RA2921-1B

3RA2931-1A

**(1)** 

41B

41B

41B

41B

41B

41B

41B

41B

1 unit

1 unit

1 unit

1 unit

10 units

10 units

10 units

5 units

Link modules for	motor starter prot	ector to contac	ctor <sup>1)</sup>				
Maria		and electrical cor and contactor wi					
	Single-unit pac	Single-unit packaging					
	AC/DC	S00	S				
	AC	S0	S				
	DC	S0	S				
OD 1 0001 11 100	A C /DC	60	0				

3RA2921-1AA00

3RA2931-1AA00



3RA2911-2AA00



3RA2911-1CA00

#### Note:

Link modules can be used in

- Sizes S00 and S0 up to max. 32 A
- Size S2 up to max. 65 A

For mechanical and electrical connection between motor starter protector and contactor with spring-type terminals				Spring-type terminals	$\stackrel{\circ}{\mathbb{H}}$			
Single-unit packaging	I							
AC/DC AC <sup>2)</sup> DC	S00 S0 S0	S00 S0 S0	<b>* *</b>	3RA2911-2AA00 3RA2921-2AA00 3RA2921-2AA00		1 1 1	1 unit 1 unit 1 unit	41B 41B 41B
Multi-unit packaging								
AC/DC AC <sup>2)</sup> DC	S00 S0 S0	S00 S0 S0	<b>&gt; &gt;</b>	3RA2911-2A 3RA2921-2A 3RA2921-2A		1 1 1	10 units 10 units 10 units	41B 41B 41B
Spacers <sup>2)</sup> For compensating the h	neight on AC o	contactors						
Single-unit packaging Multi-unit packaging	S0 S0	S0 S0	A A	3RA2911-1CA00 3RA2911-1C		1 1	1 unit 5 units	41B 41B

The link modules from motor starter protector to contactor cannot be used for the 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV2.31-4K.1., 3RV2.31-4R.1., 3RV2.32-4K.1., 3RV2.32-4R.1., 3RV27 and 3RV28 motor starter protectors/ circuit breakers.

 $<sup>^{\</sup>rm 2)}$  A spacer for height compensation on AC contactors size S0 is optionally

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

# **Mounting accessories**

	Size 3RW30, 3RW40 soft starters; 3RF34 solid-state contactors	3RV2 motor starter protectors/circuit breakers	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
	r motor starter protector to so tector to solid-state contacto							
Majula	Connection between motor starte solid-state contactor with screw			Screw terminals	<b></b>			
	Single-unit packaging							
	S00 S0 S2 <sup>2)</sup>	\$00/\$0 \$00/\$0 \$2	A A Z A	3RA2921-1BA00 3RA2921-1BA00 3RA2931-1AA00		1 1 1	1 unit 1 unit 1 unit	41B 41B 41B
3RA2921-1BA00	Multi-unit packaging							
	S00 S0 S2 <sup>2</sup> )	\$00/\$0 \$00/\$0 \$2	A A V A	3RA2921-1B 3RA2921-1B 3RA2931-1A		1 1 1	10 units 10 units 5 units	41B 41B 41B
3RA2931-1AA00								
	Connection between motor starte spring-type terminals	er protector and soft starter		Spring-type terminals	<u> </u>			
	Single-unit packaging							
	S00 S0	S00 S0	<b>&gt;</b>	3RA2911-2GA00 3RA2921-2GA00		1 1	1 unit 1 unit	41B 41B
	Multi-unit packaging							
3RA2921-2GA00	S00 S0	S00 S0	<b>&gt;</b>	3RA2911-2G 3RA2921-2G		1 1	10 units 10 units	41B 41B

#### Note:

Link modules can be used in

- Sizes S00 and S0 up to max. 32 A
- Size S2 up to max. 65 A

- 1) The link modules from motor starter protector to soft starter and from motor starter protector to solid-state contactor cannot be used for the 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV2.31-4K.1., 3RV2.31-4R.1., 3RV2.32-4K.1., 3RV2.32-4K.1. 3RV2.32-4K.1.
- 2) To assemble the feeder between a motor starter protector and a soft starter in size S2, the 3RA2932-1AC00 standard mounting rail adapter must be used.

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

#### **Mounting accessories**

	Actuating voltage of contactor	Size 3RT2 contactors	3RV2 motor starter protectors	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Hybrid link modu	les for motor starter prote	ector to con	tactor <sup>1)</sup>						
4	Mechanical and electrical co protector with screw termina terminals	nnection betw	ween motor starter						
	Single-unit packaging								
BUL	AC/DC AC <sup>2)</sup> /DC	S00 S0	S00 S0		3RA2911-2FA00 3RA2921-2FA00		1	1 unit 1 unit	41B 41B
3RA2911-2FA00	Multi-unit packaging	30	30		3HA2921-2FA00		'	i uiiit	410
Add.	AC/DC AC <sup>2</sup> /DC	\$00 \$0	S00 S0	<b>&gt;</b>	3RA2911-2F 3RA2921-2F		1 1	10 units 10 units	41B 41B
3RA2921-2FA00	2)								
	Spacers <sup>2)</sup> For compensating the height	on AC conta	ctors						
101 2	Single-unit packaging Multi-unit packaging	S0 S0	S0 S0	A A	3RA2911-1CA00 3RA2911-1C		1 1	1 unit 5 units	41B 41B
3RA2911-1CA00									
N.L. I			1) 📆						

#### Note:

Hybrid link modules in sizes S00 and S0 up to max. 32 A can be used

#### More information

#### Manuals

- System Manual "SIRIUS Innovations System Overview" http://support.automation.siemens.com/WW/view/en/60311318
- Manual "SIRIUS Innovations SIRIUS 3RV2 Motor Starter Protectors"
  - http://support.automation.siemens.com/WW/view/en/60279172

<sup>1)</sup> The hybrid link modules for motor starter protector to contactor cannot be used for the 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV27 and 3RV28 motor starter protectors/circuit breakers. They are only suitable for constructing direct-on-line starters.

<sup>2)</sup> A spacer for height compensation on AC contactors size S0 is optionally available.

# **Motor Starter Protectors/Circuit Breakers** SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

Accessories

**Enclosures and front plates** 


#### Overview

#### **Enclosures**


For stand-alone installation of 3RV20 to 3RV24 motor starter protectors size S00 ( $I_{\rm n\,max}$  = 16 A), S0 ( $I_{\rm n\,max}$  = 32 A) and S2 ( $I_{\rm n\,max}$  = 65 A), cast aluminum enclosures for surface mounting and molded-plastic enclosures for flush mounting are available in various dimensions.

When installed in a molded-plastic enclosure the motor starter protectors have a rated operational voltage  $U_{\rm p}$  of 500 V.

The enclosures for surface mounting have the degree of protection IP55; the enclosures for flush mounting also comply with the degree of protection IP55 at the front (the flush-mounted section complies with IP20).



Enclosures for surface mounting



Enclosures (only for sizes S00 and S0)

All enclosures are equipped with N and PE terminals. There are two knock-out cable entries for cable glands at the top and two at the bottom; also on the rear corresponding cable entries are scored. There is a knockout on the top of the enclosure for indicator lights that are available as accessories.

The narrow enclosure can accommodate a motor starter protector without accessories, with transverse auxiliary switch and with lateral auxiliary switch. There is no provision for installing a motor starter protector with a signaling switch.

With size S00 to S2 circuit breakers the molded-plastic enclosures are equipped with a rotary operating mechanism.


The enclosures can be supplied with either a black rotary operating mechanism or with an EMERGENCY-STOP rotary operating mechanism with a red/yellow knob.

In the OFF setting, all rotary operating mechanisms can be locked with up to three padlocks.

#### Front plates

Motor starter protectors are frequently required to be actuated in any enclosure. Front plates equipped with a rotary operating mechanism for 3RV20 to 3RV24 motor starter protectors sizes S00 to S2 are available for this purpose.

A holder for the motor starter protectors size S00 and S0, into which the motor starter protectors can be snapped, is available for the front plates.



Front plate (including holder) for sizes S00 and S0

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

# Enclosures and front plates

Enclosures a										
Selection and	ordering da	ııa								
	Version	Degree of pro- tection	Inte- grated terminals	Width	For 3RV20 to 3RV24 motor starter protectors	DT	Article No. Pric per Pl		PS*	PG
				mm	Size					
Molded-plastic	enclosures	for su	rface mou	unting <sup>1)</sup>						
	With rotary operating mechanism, lockable in	IP55	N and PE/ ground	54 (for motor starter protector + lateral auxiliary switch)	S00, S0	<b>&gt;</b>	3RV1923-1CA00	1	1 unit	41E
3RV1933-1DA00	0 position			72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	•	3RV1923-1DA00	1	1 unit	41E
				82 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S2	Α	3RV1933-1DA00	1	1 unit	41E
	With EMER- GENCY- STOP rotary	IP55	N and PE/ ground	(for motor starter protector + lateral auxiliary switch)	S00, S0	<b>&gt;</b>	3RV1923-1FA00	1	1 unit	41E
3RV1923-1FA00, 3RV1933-1GA00	operating mechanism, lockable in 0 position			72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	•	3RV1923-1GA00	1	1 unit	41E
				82 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S2	A	3RV1933-1GA00	1	1 unit	41E
Cast aluminun	n enclosures	s for su	rface mo	unting <sup>1)</sup>						
	With rotary operating mechanism, lockable in 0 position	IP65	PE <sup>3)</sup>	72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	•	3RV1923-1DA01	1	1 unit	41E
3RV1923-1DA01	With EMER- GENCY- STOP rotary operating mechanism, lockable in 0 position	IP65	PE <sup>3)</sup>	72 (for motor starter protector + lateral auxiliary switch <sup>2</sup> ) + auxiliary release)	S00, S0		3RV1923-1GA01	1	1 unit	41E
Molded-plastic	enclosures	for flu	sh mount	ting <sup>4)</sup>						
	With rotary operating mechanism, lockable in 0 position	IP55 (front side)	N and PE/ ground	72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	А	3RV1923-2DA00	1	1 unit	41E
3RV1923-2DA00	With EMER- GENCY- STOP rotary operating mechanism,	IP55 (front side)	N and PE/ ground	72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	Α	3RV1923-2GA00	1	1 unit	41E

<sup>1)</sup> The rear cable glands cannot be used on 3RV2.11-...2. and 3RV2.21-...2. devices with spring-type terminals.

lockable in 0 position

 $<sup>^{2)}</sup>$  Only valid for lateral auxiliary switches with two auxiliary contacts.

<sup>3)</sup> If required, an additional N terminal can be mounted (e.g. 8WA1011-1BG11).

<sup>4)</sup> Not suitable for 3RV2.11-...2. and 3RV2.21-...2. devices with spring-type terminals

# Motor Starter Protectors/Circuit Breakers 3.3BV2 Motor Starter Protectors/Circuit Breakers up to 80 A

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

# Enclosures and front plates

	Version	Degree of protection	For 3RV20 to 3RV24 motor starter protectors	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
			Size						
Front plates									
	Molded-plastic front plates with rooperating mechanism, lockable in 0 position	otary IP55 (front side)	S00 S2	•	3RV1923-4B		1	1 unit	41E
	For actuation of 3RV2 motor starter protectors in any enclosure								
3RV1923-4B +	Molded-plastic front plates with EMERGENCY-STOP rotary operati mechanism, red/yellow, lockable in 0 position	ing (front side)	S00 S2	Α	3RV1923-4E		1	1 unit	41E
3RV1923-4G	EMERGENCY-STOP actuation of 3RV2 motor starter protectors in any enclosure	,							
	Holders for front plates		S00, S0	<b>&gt;</b>	3RV1923-4G		1	1 unit	41E
	Holder is mounted on front plate, mo starter protector with and without accessories is snapped in.	otor							
	Version	Rated control supply voltage $U_{\rm S}$	For 3RV20 to 3RV24 motor starter protectors	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		V	Size						
Indicator lights									
0000	Indicator lights For all enclosures and front plates  • With LED lamp for versions 110 120 V, with glow lamp for versions 220 500 V  • With colored lenses red, green,	110 120 220 240 380 415 480 500	S00 S2	0000	3RV1903-5B 3RV1903-5C 3RV1903-5E 3RV1903-5G		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
3RV1903-5B	yellow, orange and clear								

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

#### 3RV29 infeed system

#### Overview

The 3RV29 infeed system is a convenient means of energy supply and distribution for a group of several motor starter protectors or complete load feeders with a screw or spring-type connection in sizes S00 and S0 (exception: this system cannot be used for the 3RV21, 3RV27 and 3RV28 motor starter protectors/circuit breakers).

The system is based on a basic module complete with a lateral incoming unit (three-phase busbar with infeed). This infeed with spring-type terminals is mounted on the right or left depending on the version and can be supplied with a maximum conductor cross-section of 25 mm² (with end sleeve). A basic module has two sockets onto each of which a motor starter protector can be snapped.


Expansion modules are available for extending the system (three-phase busbars for system expansion). The individual modules are connected through an expansion plug.

The electrical connection between the three-phase busbars and the motor starter protectors is implemented through plug-in connectors. The complete system can be mounted on a TH 35 stan-

dard mounting rail to IEC 60715 and can be expanded as required up to a maximum current carrying capacity of 63 A.

The system is mounted extremely quickly and easily thanks to the simple plug-in technique. Thanks to the lateral infeed, the system also saves space in the control cabinet. The additional overall height required for the infeed unit is only 30 mm. The alternative infeed possibilities on each side offer a high degree of flexibility for configuring the control cabinet: Infeed on left-hand or right-hand side as well as infeed on one side and outfeed on the other side to supply further loads are all possible. A terminal block with spring-type connections in combination with a standard mounting rail enables the integration of not only SIRIUS motor starter protectors but also single-phase, 2-phase and 3-phase components such as 5SY miniature circuit breakers or SIRIUS relay components.

The 3RV29 infeed system is approved in accordance with IEC to 500 V. It is also UL-approved and authorized for "Self-Protected Combination Motor Controller" (Type E starter) as well as for Type F starter (Type E starter + contactor).



SIRIUS 3RV29 infeed systems

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

3RV29 infeed system

#### 1) Three-phase busbars with infeed

A three-phase busbar with infeed unit is required for connecting the incoming supply. These modules comprise one infeed module and two sockets which each accept one motor starter protector. A choice of two versions with infeed on the left or right is available. The infeed is connected to spring-type terminals. They permit an infeed with conductor cross-sections of up to 25 mm² with end sleeves. An end cover is supplied with each module.

#### (2) Three-phase busbars for system expansion

The three-phase busbars for system expansion support expansion of the system. There is a choice of modules with two or three sockets. The system can be expanded as required up to a maximum current carrying capacity of 63 A. An expansion plug is supplied with each module.

#### 3 a Expansion plug

The expansion plug is used for electrical connection of adjacent three-phase busbars. The current carrying capacity of this plug equals 63 A. One expansion plug is supplied with each three-phase busbar for system expansion. Additional expansion plugs are therefore only required as spare parts.

#### (3)b Extra-wide expansion plug

The wide expansion plug makes the electrical connection between two three-phase busbars, thus performing the same function as the 3RV2917-5BA00 expansion plug; the electrical characteristics (e.g. a current carrying capacity of 63 A) are identical.

The 3RV2917-5E expansion plug is 10 mm wider than the 3RV2917-5BA00 expansion plug, hence in the plugged state there is a distance of 10 mm between the connected three-phase busbars. This distance can be used to lay the auxiliary current and control current wiring ("wiring duct"). The motor starter protector and contactor can be wired from underneath, which means that the complete cable duct above the system can be omitted.

#### (4) End cover

The end cover is used to cover the three-phase busbar at the open end of the system. This cover is therefore only required once for each system. An end cover is supplied with each three-phase busbar system with infeed. Further end covers are therefore only required as spare parts.

#### (5) Plug-in connector

The plug-in connector is used for the electrical connection between the three-phase busbar and the 3RV2 motor starter protector. These plug-in connectors are available for screw or spring-type terminals.

#### 6 Contactor base

Load feeders can be assembled in the system using the S00 and S0 contactor base. The contactor bases are suitable for contactors sizes S00 and S0 with spring-type and screw terminals and are simply snapped onto the three-phase busbars. Direct-on-line starters and reversing starters are possible. One contactor base is required for direct-on-line starters and two are required for reversing starters.

To assemble load feeders for reversing starters, the contactor bases can be arranged alongside each other (90 mm overall width). In this case the mechanical interlocking of the contactors is possible. The S0 contactor bases are also suitable for soft starters size S00 and S0 with screw terminal.

The infeed system is designed for mounting onto a TH 35 standard mounting rail with 7.5 mm overall depth. This standard mounting rail gives the contactor base a stable mounting surface to sit on. If standard mounting rails with a depth of 15 mm are used, the spacer connected to the bottom of the contactor base must be knocked out and plugged into the mating piece that is also on the underside. Then the contactor base also has a stable mounting surface. When standard mounting rails with a depth of 7.5 mm are used, the spacer has no function and can be removed.

The link modules are used for direct start load feeders, in which case the use of a contactor base is not absolutely necessary. Motor starter protector and contactor assemblies can then be directly snapped onto the sockets of the three-phase busbars. For feeders of sizes S00 and S0, the corresponding 3RA1921-1...., 3RA2911-2...., 3RA2921-1.... or 3RA2921-2.... link modules should generally be used.

#### 7) Terminal block

The 3RV2917-5D terminal block enables the integration of not only SIRIUS motor starter protectors but also single-phase, 2-phase and 3-phase components. The three phases can be fed out of the system using the terminal block; which means that single-phase loads can also be integrated in the system. The terminal block is plugged into the slot of the expansion plug and thus enables outfeeding from the middle or end of the infeed system. The terminal block can be rotated through 180° and be locked to the support modules of the infeed system. In addition, the 45 mm wide TH 35 3RV1917-7B standard mounting rail option for screwing onto the support plate facilitates plugging the single-phase, two-phase and three-phase components onto the infeed system.

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

# 3RV29 infeed system

Technical spe	cifications				
General data					
Туре					3RV29.7
Size					S00, S0
Standards					
• IEC 60947-2					Yes
• IEC 60947-4-1					Yes
• UL 508/UL 609	47-4-1				Yes
Rated current In	1			А	63
Permissible rate	ed current at i	nside temperature	of control cabinet		
Motor starter protectors	Size	Rated current	Inside tempera- ture of control cabinet		
• 3RV2.11	S00	14 A	60 °C	%	100
		>14 16 A	40 °C 60 °C	%	100 87
• 3RV2.21	S0	16 A	60 °C	%	100
		> 16 25 A	40 °C 60 °C	%	100 87
		> 25 32 A	40 °C	%	87
Permissible am	bient tempera	iture			
• Storage/transp	ort			°C	–50 +80
<ul> <li>Operation</li> </ul>				°C	-20 +60
Rated operation	al voltage <i>U</i> e				
<ul> <li>Acc. to IEC</li> </ul>		10 % overvolta	ge	V AC	500
		5% overvoltage	)	V AC	525
• Acc. to UL/CSA	A			V AC	600
Rated frequency	у			Hz	50/60
Rated impulse v	vithstand volt	age <i>U</i> imp		kV	6
Short-circuit str	ength				Corresponds to the mounted motor starter protector or load feeder
Degree of prote	ction acc. to I	EC 60529			IP20 (In the terminal compartment of the infeed without connected IP00 conductor)
Touch protectio	n acc. to DIN	VDE 0106, Part 100		-	Finger-safe

Conductor cross-sections			
Туре		Three-phase busbar with infeed 3RV2917-1A, 3RV2917-1E	Terminal block 3RV2917-5D
Conductor cross-sections (min./max.)			
Solid or stranded	mm	<sup>2</sup> 4 25	1.5 6
• Finely stranded with end sleeve	mm	<sup>2</sup> 4 25	1.5 4
• Finely stranded without end sleeve	mm	<sup>2</sup> 6 25	1.5 6
AWG cables	AW	G 10 3	15 10

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

3RV29 infeed system

Selection and orderi	ng data							
	Туре	Version	For 3RV20, 3RV23, 3RV24 motor starter protectors Size	DT	Article No. Price per PU	PU (UNIT, SET, M)	PS*	PG
Three-phase busbars	with infeed							
3RV2917-1A	Three-phase busbars with infeed incl. 3RV2917-6A end cover	For 2 motor starter protectors with screw or spring-type terminals  • With infeed on the left  • With infeed on the right	S00, S0 S00, S0	A A	3RV2917-1A 3RV2917-1E	1	1 unit 1 unit	41E 41E
Three-phase busbars	for system expansi	on						
3RV2917-4A	Three-phase busbars incl. 3RV2917-5BA00 expansion plug		\$00, \$0 \$00, \$0	A A	3RV2917-4A 3RV2917-4B	1	1 unit 1 unit	41E 41E
Plug-in connectors								
3RV2917-5AA00	Plug-in connectors to make contact with the motor starter protectors	For spring-type terminals     Single-unit packaging     Multi-unit packaging	S00 <sup>1)</sup> S0 <sup>2)</sup> S00 <sup>1)</sup> S0 <sup>2)</sup>	A A A	Spring-type terminals  3RV2917-5AA00 3RV2927-5AA00 3RV2917-5A 3RV2927-5A		1 unit 1 unit 10 units 10 units	41E 41E 41E 41E
3NV2917-3AA00		For screw terminals			Screw terminals			
3RV2917-5CA00		<ul><li>Single-unit packaging</li><li>Multi-unit packaging</li></ul>	S00 <sup>1)</sup> S0 <sup>2)</sup> S00 <sup>1)</sup> S0 <sup>2)</sup>	A A A	3RV2917-5CA00 3RV1927-5AA00 3RV2917-5C 3RV1927-5A		1 unit 1 unit 10 units 10 units	41E 41E 41E 41E
1) <i>I</i> > 14 A, please note de	erating: see Manual		<sup>2)</sup> I > 16	A. ple:	ase note derating; see Manual			
"SIRIUS Innovations - S	IRIUS 3RV2 Motor Starte n.siemens.com/WW/view		"SIRIUS	3 Inno	vations – SIRIUS 3RV2 Motor St t.automation.siemens.com/WW/			

	Туре	Version	For contactors	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
			Size						
Contactor bases									
All and a second	Contactor bases	Single-unit packaging	S00	Α	3RV2917-7AA00		1	1 unit	41E
	for mounting direct-on-line or reversing starters		S00, S0	Α	3RV2927-7AA00		1	1 unit	41E
3RV2927-7AA00									

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

# 3RV29 infeed system

	Туре	Version	DT	Article No. Price per PU		PS*	PG
Terminal blocks							
	<b>Terminal blocks</b> For integration of single-phase, two-phase and three-phase components	Single-unit packaging	A	3RV2917-5D	1	1 unit	41E
3RV2917-5D	Aire a veile voidale 45 verus						
TH 35 Standard moun	ting rails, width 45 mm						
3RV1917-7B	TH 35 standard mounting rails acc. to IEC 60715, width 45 mm For mounting onto three-phase busbars	Single-unit packaging	A	3RV1917-7B	1	1 unit	41E
Extra-wide expansion	plugs						
7	Extra-wide expansion plugs As accessory	Single-unit packaging	A	3RV2917-5E	1	1 unit	41E
3RV2917-5E							
Expansion plugs	1)						
	Expansion plugs <sup>1)</sup> As spare part	Single-unit packaging	A	3RV2917-5BA00	1	1 unit	41E
3RV2917-5BA00							
End covers	2)						
3RV2917-6A	End covers <sup>2)</sup> As spare part	Multi-unit packaging	A	3RV2917-6A	100	10 units	41E

<sup>1)</sup> The expansion plug is included in the scope of supply of the 3RV2917-4. three-phase busbars for system expansion.

The end cover is included in the scope of supply of the 3RV2917-1. three-phase busbars with infeed system.

#### SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

General data

#### Overview


The following illustration shows our 3RV1 motor starter protector/circuit breaker with the accessories which can be mounted for size S3, see also "Introduction" — "Overview", page 7/3.

"Accessories", see page 7/69 onwards.

#### Note:

The 3RV1 devices (sizes S00/S0 to S3) can be found

- in the Catalog Add-On IC 10 AO · 2015 at the Information and Download Center
- in the interactive catalog CA 01
- in the Industry Mall



Mountable accessories for size S3

- 1 Transverse auxiliary switch (can not be used with 3RV1742 circuit breakers)
- 2 Lateral auxiliary switch with 2 contacts
- 3 Lateral auxiliary switch with 4 contacts
- 4 Shunt release (can not be used with 3RV11 motor starter protectors)
- 5 Undervoltage release (can not be used with 3RV11 motor starter protectors)
- Undervoltage release with leading auxiliary contacts (can not be used with 3RV11 motor starter protectors)
- Alarm switch (can not be used with 3RV1742 circuit breakers)

SIRIUS 3RV1 motor starter protector/circuit breaker size S3 with mountable accessories



SIRIUS motor starter protector/circuit breaker size S3

3RV1 motor starter protectors/circuit breakers are compact, current limiting motor starter protectors/circuit breakers which are optimized for load feeders. The motor starter protectors/circuit breakers are used according to IEC 60947-2 for switching and protecting three-phase motors of up to 45 kW at 400 V AC and for other loads with rated currents of up to 100 A.

3RV2 motor starter protectors/circuit breakers sizes S00 to S2 up to 80 A, see page 7/21 onwards.

3RV1 motor starter protectors/circuit breakers are generally approved according to IEC and UL/CSA.

According to UL 508/UL 60947-4-1, the 3RV1 motor starter protectors in size S3 are approved as:

- "Manual Motor Controllers"
- "Manual Motor Controllers" for "Group Installations"
- "Manual Motor Controllers Suitable for Tab Conductor Protection in Group Installations"
- "Self-Protected Combination Motor Controllers (Type E)"
   Please note that for this approval the 3RV10 motor starter
   protectors in size S3 must be equipped with additional infeed
   terminals.

The 3RV1742 are approved as circuit breakers according to UL 489; they are a special variant of the 3RV1 motor starter protectors.

Corresponding short-circuit values, see pages 7/54 to 7/57.

#### SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

#### **General data**

#### Type of construction

The 3RV1 motor starter protectors/circuit breakers are available in four sizes:

- Size S00 width 45 mm, max. rated current 12 A,
  - at 400 V AC suitable for three-phase motors up to 5.5 kW
- Size S0 width 45 mm, max. rated current 25 A,
  - at 400 V AC suitable for three-phase motors up to 11 kW
- Size S2 width 55 mm, max. rated current 50 A,
- at 400 V AC suitable for three-phase motors up to 22 kW
- Size S3 width 70 mm, max. rated current 100 A, at 400 V AC suitable for three-phase motors up to 45 kW

Sizes S00 to S2 of the 3RV2 motor starter protectors/circuit breakers up to 80 A, see page 7/21 onwards.

#### Circuit breakers acc. to UL 489


The 3RV1742 circuit breakers are available in size S3 (width 70 mm):

- Maximum rated current 70 A at 480 Y/277 V AC
- Maximum rated current 10 A to 30 A at 480 V AC

For sizes S00 and S0 of the 3RV27 and 3RV28 circuit breakers up to 22 A, see pages 7/29 and 7/30.

#### Connection methods

The SIRIUS 3RV1 motor starter protectors/circuit breakers can be supplied with screw terminals and spring-type terminals.



# "Increased safety" type of protection EEx e according to ATEX directive 94/9/EC

3RV10 motor starter protectors are suitable for the overload protection of explosion-proof motors with "increased safety" type of protection EEx e.

#### Article No. scheme

Digit of the Article No.	1st - 3rd	4th	5th	6th	7th		8th	9th	10th	11th	12th		13th	14th	15th	16th	
						-						-					
Motor starter protectors/ circuit breakers	3 R V																
SIRIUS 1st generation		1															
Type of motor starter protector/ circuit breaker																	
Size																	
Breaking capacity																	
Setting range for overload release																	
Trip class (CLASS)																	
Connection methods																	
With or without auxiliary switch																	
Special versions																	
Example	3 R V	1	0	4	1	_	4	F	Α	1	0						

#### Note:

The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

**General data** 

# Application

#### Operating conditions

3RV1 motor starter protectors/circuit breakers are suitable for use in any climate. They are intended for use in enclosed rooms in which no severe operating conditions (such as dust, caustic vapors, hazardous gases) prevail. When installed in dusty and damp areas, suitable enclosures must be provided.

3RV1 motor starter protectors/circuit breakers can optionally be fed from the top or from below.

The permissible ambient temperatures, the maximum switching capacities, the tripping currents and other boundary conditions can be found in the technical specifications and tripping characteristics, see Reference Manual "Protection Equipment – Circuit Breakers · Molded Case Circuit Breakers", http://support.automation.siemens.com/WW/view/en/65032586.

3RV1 motor starter protectors/circuit breakers are suitable for operation in IT systems (IT networks). In this case, the different short-circuit breaking capacity in the IT system must be taken into account, see page 7/55.

Since operational currents, starting currents and current peaks are different even for motors with identical power ratings due to the inrush current, the motor ratings in the selection tables are only guide values. The specific rated and startup data of the motor to be protected is always paramount to the choice of the most suitable motor starter protector/circuit breaker. This also applies to motor starter protectors for transformer protection.

#### Note:

For the use of 3RV1 motor starter protectors in size S3 in conjunction with highly energy-efficient IE3 motors, please observe the information on dimensioning and configuring, see "Configuration Manual for SIRIUS Controls with IE3 Motors", http://support.automation.siemens.com/WW/view/en/94770820.

More information, see page 3.

#### Possible uses

The 3RV1 motor starter protectors/circuit breakers can be used:

- For short-circuit protection
- For motor protection (also with overload relay function)
- For system protection
- For short-circuit protection for starter combinations
- As main and EMERGENCY-STOP switches
- · For fuse monitoring
- For operation in IT systems (IT networks)
- · For switching of DC currents
- As voltage transformer circuit breakers
- In areas subject to explosion hazard (ATEX)
- Approved as circuit breakers according to UL 489 (3RV1742)

For more details, see Reference Manual "Protection Equipment – Circuit Breakers · Molded Case Circuit Breakers" http://support.automation.siemens.com/WW/view/en/65032586.

SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

#### General data

#### Technical specifications

#### Short-circuit breaking capacity $I_{\rm cu}$ , $I_{\rm cs}$ according to IEC 60947-2

This table shows the rated ultimate short-circuit breaking capacity  $I_{\rm Cu}$  and the rated service short-circuit breaking capacity  $I_{\rm Cs}$  of the 3RV1 motor starter protectors/circuit breakers with different operating voltages dependent of the rated current  $I_{\rm n}$  of the motor starter protectors/circuit breakers.

Power can be supplied to the motor starter protectors/circuit breakers via the terminals at the top or at the bottom without restricting the rated data. If the short-circuit current at the place of installation exceeds the rated short-circuit breaking capacity of the motor starter protector/circuit breaker as specified in the table, a back-up fuse is required. It is also possible to install an upstream motor starter protector/circuit breaker with a limiter function.

The maximum rated current of this back-up fuse is indicated in the tables. The rated ultimate short-circuit breaking capacity then applies as specified on the fuse.

#### Fuseless design

Motor starter protector/contactor assemblies for short-circuit currents up to 100 kA can be ordered as fuseless load feeders, see Chapter 8 "Load Feeders and Motor Starters for Use in the Control Cabinet".

Motor starter protectors/ circuit breakers	Rated current $I_n$	Up to	240 \	/ AC <sup>1)</sup>	Up to 400 V AC <sup>1)</sup> / 415 V AC <sup>2)</sup>			460 V	/ AC <sup>2)</sup>		Up to 500 V AC <sup>1)</sup> / 525 V AC <sup>2)</sup> apply to 3RV1742 circuit I			Up to 690 V AC <sup>1)</sup>		
on our broakers								(thes	e value	es do not ap	ply to	3RV1.	742 circuit k	oreake	rs)	
		$I_{ m CU}$	$I_{\mathrm{CS}}$	Max. fuse (gG)	$I_{ m CU}$	$I_{\mathrm{CS}}$	Max. fuse (gG) <sup>3)</sup>	$I_{ m CU}$	$I_{\mathrm{CS}}$	Max. fuse (gG) <sup>3)</sup>	$I_{\mathrm{CU}}$	$I_{\rm CS}$	Max. fuse (gG) <sup>3)</sup>	$I_{ m CU}$	$I_{ t CS}$	Max. fuse (gG) <sup>3)4)</sup>
Туре	Α	kA	kA	А	kA	kA	А	kA	kA	А	kA	kA	А	kA	kA	Α
Size S00																
3RV1611-0BD10	0.2	100	100	0	100	100	0	100	100	0	100	100	0	100	100	0
Size S3																
3RV1.41	40 50 63 75 90; 100	100 100 100 100	100 100 100 100 100	0	50 50 50 50	25 25 25 25 25	125 125 160 160 160	50 50 50 50	20 20 20 20 20	125 125 160 160 160	12 12 12 8 8	6 6 6 4 4	100 100 100 125 125	6 6 6 5 5	3 3 3 3	63 80 80 100 125
Size S3, with inconstitution switching capaci																
3RV1.42/3RV1742 <sup>5)</sup>	16 / 10 20 / 15 25 / 20 32 / 25 40 / 30	100 100 100 100 100	100 100 100 100 100	0	100 100 100 100 100	50 50 50 50	0	100 100 100 100 100	50 50 50 50	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	30 30 30 22 18	15 15 15 11 9	80 80 80 100 160	12 12 12 12 12	7 7 7 7 6	63 63 63 80
	50 / 35 40 63 / 45 50 75 / 60 90 / 70 100 /	100 100 100 100 100	100 100 100 100 100	0	100 100 100 100 100	50 50 50 50 50	0	100 70 70 70 70	50 50 50 50 50	200 200 200 200	15 15 10 10 10	7.5 7.5 5 5	160 160 160 160	10 7.5 6 6 6	5 4 3 3 3	100 100 125 160 160

<sup>°</sup> No back-up fuse required, since short-circuit resistant up to 100 kA

<sup>1) 10 %</sup> overvoltage.

<sup>&</sup>lt;sup>2)</sup> 5 % overvoltage.

 $<sup>^{\</sup>rm 3)}$  Back-up fuse only required if short-circuit current at the place of installation >  $I_{\rm CII}$ 

<sup>&</sup>lt;sup>4)</sup> Alternatively, fuseless limiter combinations for 690 V AC can also be used.

<sup>5)</sup> The values for the 3RV1742 circuit breakers have been tested only up to 400 V/415 V AC; values > 440 V AC on request.

#### SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

General data

#### Short-circuit breaking capacity I<sub>culT</sub> in the IT system (IT network) according to IEC 60947-2

3RV1 motor starter protectors/circuit breakers are suitable for operation in IT systems. The values of  $I_{\rm Cu}$  and  $I_{\rm Cs}$  apply for the three-pole short circuit. In case of a double ground fault in different phases at the input and output side of a motor starter protector/circuit breaker, the special short-circuit breaking capacity  $I_{\rm culT}$  applies. The specifications in the table apply to 3RV1 motor starter protectors/circuit breakers.

If the short-circuit current at the place of installation exceeds the motor starter protector/circuit breaker's specified rated short-circuit breaking capacity, you will need to use a back-up fuse. The maximum rated current of this back-up fuse is indicated in the tables. The rated short-circuit breaking capacity then applies as specified on the fuse.

Motor starter	Rated	Up to 240 V A	AC1)	Up to 400 V A	C <sup>1)</sup> /415 V AC <sup>2)</sup>	Up to 500 V A	C1)/525 V AC2)	Up to 690 V A	AC <sup>1)5)</sup>
protectors/ circuit breakers	current I <sub>n</sub>	$I_{CuIT}$	Max. fuse (gG) <sup>3)</sup>	$I_{culT}$	Max. fuse (gG) <sup>3)4)</sup>	$I_{CUIT}$	Max. fuse (gG) <sup>3)</sup>	$I_{CUIT}$	Max. fuse (gG) <sup>3)</sup>
Туре	Α	kA	А	kA	Α	kA	Α	kA	Α
Size S00									
3RV1611-0BD10	0.2	100	0	100	0	100	0	100	0
Size S3									
3RV1.41	40 50 63 75 90; 100	50 50 50 50 50	125 125 160 160	10 8 6 5 5	63 80 80 100 125	5 3 3 2 2	50 63 63 80 100	5 3 3 2 2	50 63 63 80 100
Size S3, with incommendations switching capacitation									
3RV1.42	16 32 40 50 63 75 90; 100	100 100 100 100 100 100	0	12 12 10 7.5 6 6	63 80 100 100 125 160	6 6 4 4 3 3	50 63 80 80 100 125	6 6 4 4 3 3	50 63 80 80 100 125

<sup>°</sup> No back-up fuse required, since short-circuit resistant up to 100 kA

#### Limiter function with standard devices for 500 V AC and 690 V AC according to IEC 60947-2

The table shows the rated ultimate short-circuit breaking capacity  $I_{\rm Cu}$  and the rated service short-circuit breaking capacity  $I_{\rm CS}$  with an upstream standard motor starter protector that fulfills the limiter function at voltages 500 V AC and 690 V AC.

The short-circuit breaking capacity can be increased significantly with an upstream standard motor starter protector with limiter function. The motor starter protector which is connected downstream must be set to the rated current of the load. With motor starter protector assemblies, note the clearance to grounded parts and between the motor starter protectors. Short-circuit proof wiring between the motor starter protectors must be ensured. The motor starter protectors can be mounted side by side in a modular arrangement.

Standard motor starter	Standard motor starter protectors		Up to 500 V AC <sup>1)</sup> /525 V AC <sup>2)</sup>		Up to 690 V AC <sup>1)</sup>	
	With limiter rated current $I_n$		$I_{\mathtt{CU}}$	$I_{ extsf{CS}}$	$I_{ m CU}$	$I_{ exttt{CS}}$
Type	Туре	A	kA	kA	kA	kA
Size S3						
3RV1041/3RV10 42	3RV1341-4HC10	32 50	100	50	50	25
	$I_{\rm n} = 50 \ {\rm A}$					
	3RV1341-4MC10	50 100	100	50	50	25
	$I_{\rm n} = 100  {\rm A}$					

<sup>1) 10 %</sup> overvoltage.

<sup>1) 10 %</sup> overvoltage.

<sup>&</sup>lt;sup>2)</sup> 5 % overvoltage.

 $<sup>^{3)}</sup>$  Back-up fuse only required if short-circuit current at the place of installation >  $I_{\rm culT}$ 

<sup>4)</sup> Alternatively, fuseless limiter combinations for 690 V AC can also be used.

<sup>&</sup>lt;sup>5)</sup> Overvoltage category II applies for applications in IT systems > 600 V.

<sup>&</sup>lt;sup>2)</sup> 5 % overvoltage.

#### SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

#### General data

#### Permissible rated data of approved devices for North America (UL/CSA)

Motor starter protectors/circuit breakers of the 3RV1 series are approved for UL/CSA, and according to UL508/UL 60947-4-1 and CSA C22.2 No. 14/CSA 60947-4-1 they can be used on their own or as load feeders in combination with a contactor.

These motor starter protectors/circuit breakers can be used as "Manual Motor Controllers" for "Group Installations", as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" and as "Self-Protected Combination Motor Controllers" (Type E).

#### 3RV1 motor starter protectors/circuit breakers as "Manual Motor Controllers"

If used as a "Manual Motor Controller", the motor starter protector/circuit breaker is always operated in combination with an upstream short-circuit protection device. Approved fuses or a circuit breaker according to UL 489/CSA C22.2 No. 5 can be used. These devices must be dimensioned according to the National Electrical Code (UL) or Canadian Electrical Code (CSA).

The file numbers for the approval of the 3RV1 as a Manual Motor Controller are as follows:

- UL File No. 47705, CCN: NLRV
- CSA Master Contract 165071, Product Class: 3211 05

Motor starter			) for FLA <sup>2)</sup>	Rated	240 V AC		480 V AC		600 V AC	
protectors		max.		current I <sub>n</sub>	$I_{bc}^{(3)}$	CSA $I_{ m bc}^{(3)}$	$I_{\rm bc}^{(3)}$	CSA $I_{\rm bc}^{3)}$	$UL$ $I_{bc}^{3)}$	CSA $I_{bc}^{3)}$
Туре	V	Single- phase	3-phase	Α	kA	kA	kA	kA	kA	kA
Size S00										
3RV1611-0BD10				0.2	65	65	65	65	10	10
Size S3										
3RV1041/3RV1042,	3RV1142, 3R\		342	16 75 90; 100	65 65	65 65	65 65	65 65	30 10	30 10
FLA <sup>2)</sup> max. 100 A, 600 V NEMA size 3	115 200 230 460 575/600	7 1/2 20 20  	 30 40 75 100							

<sup>1)</sup> hp rating = Power rating in horse power (maximum motor rating).

#### 3RV10 motor starter protectors as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations"

The application as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" is only available for UL. CSA does not recognize this approval! When the motor starter protector is used as a "Manual Motor Controller Suitable for Tap Conductor Protection in Group Installations", it must always be combined with upstream short-circuit protection. Approved fuses or a circuit breaker according to UL 489 can be used. These devices must be dimensioned according to the National Electrical Code.

The 3RV10 motor starter protectors are approved as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" under the following file number:

• UL File No. 47705, CCN: NLRV

Motor starter protectors		hp rating <sup>1)</sup> max.	for FLA <sup>2)</sup>	Rated current I <sub>n</sub>	<b>240 V AC</b> UL <i>I</i> <sub>bc</sub> <sup>3)</sup>		Up to 600 Y/347 V AC $\cup$ L $I_{\rm bc}^{(3)}$
Туре	V	Single- phase	3-phase	Α	kA		kA
Size S3							
3RV104.				16 75 90; 100	65 65	65 65	30
FLA <sup>2)</sup> max. 100 A, 480 V 75 A, 600 V NEMA size 3	115 200 230 460 575/600	7 1/2 20 20  	 30 40 75 75				

<sup>--</sup> No approval

<sup>2)</sup> FLA = Full Load Amps/motor full load current.

<sup>3)</sup> Corresponds to "short-circuit breaking capacity" according to UL/CSA.

<sup>1)</sup> hp rating = Power rating in horse power (maximum motor rating).

<sup>2)</sup> FLA = Full Load Amps/motor full load current.

<sup>3)</sup> Corresponds to "short-circuit breaking capacity" according to UL.

#### SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

General data

#### 3RV10 motor starter protectors as "Self-Protected Combination Motor Controllers (Type E)"

UL 508/UL 60947-4-1 approval demands 1-inch clearance and 2-inch creepage distance at line side for "Self-Protected Combination Motor Controller Type E".

Therefore, 3RV10 motor starter protectors in size S3 are approved according to UL 508/UL 60947-4-1 in combination with the 3RT1946-4GA07 terminal block listed below.

CSA does not require these extended clearances and creepage distances. According to CSA, these terminal blocks can be omitted when the device is used as a "Self-Protected Combination Motor Controller".

The 3RV10 motor starter protectors are approved as "Self-Protected Combination Motor Controllers" under the following file numbers:

- UL File No. E156943, CCN: NKJH
- CSA Master Contract 165071, Product Class: 3211 08

Motor starter		hp rating <sup>1)</sup>	for FLA <sup>2)</sup>	Rated	Up to 240 V	AC	Up to 480 Y	/277 V AC	Up to 600 Y	/347 V AC
protectors		max.		current I <sub>n</sub>	UL	CSA	UL	CSA	UL	CSA
					$I_{\rm bc}^{3)}$	$I_{bc}^{3)}$	$I_{bc}^{3)}$	$I_{\rm bc}^{(3)}$	$I_{\rm bc}^{(3)}$	$I_{bc}^{3)}$
Type	V	Single- phase	Three- phase	Α	kA	kA	kA	kA	kA	kA
Size S3										
3RV1041 + 3RT194	l6-4GA07 <sup>4)</sup>			16 75	65 65	65 65	65 65	65 65	30	30
FLA <sup>2)</sup> max.	115	10		90; 100	00	00	00	00		
100 A, 480 V 75 A, 600 V NEMA size 3	200 230 460 575/600	20 20 	30 40 75 75							

<sup>--</sup> No approval

#### 3RV1742 motor starter protectors as "Circuit Breakers"

These motor starter protectors are approved as circuit breakers according to UL 489 and CSA 22.2 No. 5. They can be used therefore as upstream short-circuit protective devices for "Manual Motor Controllers" and "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations".

The 3RV1742 motor starter protectors are approved as "Circuit Breakers" under the following file numbers:

- UL File No. E235044, CCN: DIVQ
- CSA Master Contract 165071, Product Class: 1432 01

Circuit breakers	Rated current In	240 V AC		480 Y/277 V	AC	480 V AC		600 Y/347 V	AC
Туре	А	UL I <sub>bc</sub> <sup>1)</sup> kA	CSA I <sub>bc</sub> <sup>1)</sup> kA	UL I <sub>bc</sub> <sup>1)</sup> kA	CSA $I_{\rm bc}^{-1)}$ kA	UL I <sub>bc</sub> <sup>1)</sup> kA	CSA I <sub>bc</sub> <sup>1)</sup> kA	UL I <sub>bc</sub> <sup>1)</sup> kA	CSA I <sub>bc</sub> <sup>1)</sup> kA
Size S3									
3RV1742	10 30 35 60 70	65 65 65	65 65 65	65 65 65	65 65 65	65  	65  	20 20 10	20 20 10

<sup>--</sup> No approval

<sup>1)</sup> hp rating = Power rating in horse power (maximum motor rating).

<sup>2)</sup> FLA = Full Load Amps/motor full load current.

<sup>3)</sup> Corresponds to "short-circuit breaking capacity" according to UL/CSA.

<sup>4)</sup> Not required for CSA.

<sup>1)</sup> Corresponds to "short-circuit breaking capacity" according to UL.

# SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

# General data

General data					
General data					
Туре			3RV1611 <sup>1)</sup>	3RV1.4.	3RV1742
Size			S00	S3	S3
Dimensions (W x H x D)		mm	45 x 90 x 70	70 x 165 x 169	70 x 168 x 169
	W				
Standards	· · · · · · · · · · · · · · · · · · ·				
• IEC 60947-1, EN 60947-1 (VDE 0660 Part 1	00)		Yes		
<ul> <li>IEC 60947-2, EN 60947-2 (VDE 0660 Part 1</li> </ul>			Yes		
<ul> <li>IEC 60947-4-1, EN 60947-4-1 (VDE 0660 P</li> <li>UL 508/UL 60947-4-1, CSA C22.2 No.14/C</li> </ul>			Yes Yes		No No
• UL 489, CSA C22.2 No. 5	SA 60947-4-1		No		Yes
Number of poles			3		100
•		Α	12	100	70
Max. rated current I <sub>n max</sub> (= max. rated operational current I <sub>e</sub> )		А	12	100	70
Permissible ambient temperature					
Storage/transport		°C	-50 +80		
Operation		°C	-20 +70 (current redu	ction above +60 °C)	
Permissible rated current at inside temper	ature of control cabinet				
• +60 °C		%	100		
• +70 °C		%	87		
Permissible rated current at ambient temp (applies for motor starter protector inside					
• +35 °C	cholosule)	%	100		
• +60 °C		%	87		
Rated operational voltage U <sub>e</sub>					
Acc. to IEC		V AC	690 (with molded-plastic	enclosure 500 V)	
Acc. to UL/CSA		V AC	600		
Rated frequency		Hz	50/60		
Rated insulation voltage U <sub>i</sub>		V	690		
Rated impulse withstand voltage <i>U</i> imp		kV	6		
Utilization category					
<ul> <li>IEC 60947-2 (motor starter protector/circuit</li> </ul>	breaker)		A		
• IEC 60947-4-1 (motor starter)			AC-3		
Trip class CLASS	Acc. to IEC 60947-4-1		10	10/20	
DC short-circuit breaking capacity (time co	enstant t = 5 ms)		40		
<ul> <li>1 conducting path 150 V DC</li> <li>2 conducting paths in series 300 V DC</li> </ul>		kA kA	10 10		
3 conducting paths in series 450 V DC		kA	10		
Power loss P <sub>v</sub> for each motor starter	<i>I</i> <sub>n</sub> : 16 63 A	W		20	
protector/circuit breaker	n. 10 00 / (	**		20	
Dependent on the rated current $I_{n}$					
(upper setting range)	1 . 7F I 00 A	14/		00	
p P	I <sub>n</sub> : 75 and 90 A I <sub>n</sub> : 100 A	W		30 38	
Rper conducting path = 72 2	I <sub>n</sub> : 10 A	W			8
1 ×3	<i>I</i> <sub>n</sub> : 10 A <i>I</i> <sub>n</sub> : 15 35 A	W			12
	I <sub>n</sub> : 40 70 A	W			21
Shock resistance	Acc. to IEC 60068-2-27	g/ms	25/11 (square and sine	oulse)	
Degree of protection	Acc. to IEC 60529		IP20 (IP00 terminal com	,	
Touch protection	Acc. to EN 50274		Finger-safe for vertical c		
Temperature compensation	Acc. to IEC 60947-4-1	°C	-20 +60		
Phase failure sensitivity	Acc. to IEC 60947-4-1			2DV/124 motor starter	No
rnase ianure sensitivity	AUU. 10 1EU 100947-4-1		Yes (does not apply for 3 protectors)	DITY 134 HIOTOI STAFTEF	INU
Explosion protection – Safe operation of n	notors with		Yes, for 3RV10 (CLASS	10)	No
"increased safety" type of protection			.55, 101 0117 10 (01/100	,	
EC type test certificate number according to			DMT 02 ATEX F 001 😥	II (2) GD,	
directive 94/9/EC (ATEX)			DMT 02 ATEX F 001 N1	(₺) II (2) GD	
Isolating function	Acc. to IEC 60947-2		Yes		
Main and EMERGENCY-STOP switch characteristics (with corresponding	Acc. to DIN EN 60204-1		Yes		
characteristics (with corresponding accessories)					
Protective separation between main and	Acc. to IEC 60947-1				
auxiliary circuits, required for	, .50. to 120 000+1-1				
PELV applications					
• Up to 400 V +10 %	ant)		Yes		
<ul> <li>Up to 415 V +5 % (higher voltages on requ</li> </ul>	est)		Yes		1
			Any, acc. to IEC 60447 s	tart command "I" right-ha	and side or top
Permissible mounting position			· · · · ·	F0.000	
Permissible mounting position Mechanical endurance	<u> </u>	ng cycles	100 000	50 000	
Permissible mounting position	<u> </u>	ng cycles ng cycles	100 000	50 000 25 000	

 $<sup>^{\</sup>rm 1)}$  "Technical Specifications" for 3RV1611 voltage transformer circuit breakers, see page 7/60.

For short-circuit breaking capacity  $I_{\rm CU}$ ,  $I_{\rm CS}$  see Reference Manual "Protection Equipment – Circuit Breakers · Molded Case Circuit Breakers" http://support.automation.siemens.com/WW/view/en/65032586.

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

General data

Conductor cross-sections of main circuit			
Туре		3RV1611 <sup>4)</sup>	3RV1.4./ 3RV1742
Connection type		Screw terminals	Screw terminals with box terminal
Terminal screw		Pozidriv size 2	4 mm Allen screw
Prescribed tightening torque	Nm	0.8 1.2	4 6
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected			
Solid or stranded	mm <sup>2</sup>	2 x (0.5 1.5) <sup>5)</sup> , 2 x (0.75 2.5) <sup>5)</sup>	2 x (2.5 16) <sup>5)</sup> , 2 x (10 50) <sup>5)</sup> , 1 x (10 70) <sup>5)</sup>
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	2 x (0.5 1.5) <sup>5)</sup> 2 x (0.75 2.5) <sup>5)</sup>	2 x (2.5 35) <sup>5)</sup> , 1 x (2.5 50) <sup>5)</sup>
AWG cables, solid or stranded	AWG	2 x (18 14)	2 × (10 1/0) <sup>5)</sup> , 1 × (10 2/0) <sup>5)</sup>
Ribbon cable conductors (Number x Width x Thickness)	mm		2 x (6 x 9 x 0.8)
Removable box terminals <sup>1)</sup>			
With copper bars <sup>2)</sup>			18 x 10
With cable lugs <sup>3)</sup>			up to 2 x 70
0 0 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		4) == + + + + + + + + + + + + + + + + + +	001/40 11 1 / 1 11 1

- Cable lug and busbar connection possible after removing the box terminals.
   Technical Specifications" for 3RV16 voltage transformer circuit breakers, see page 7/60.
- 2) If bars larger than 12 mm x 10 mm are connected, a 3RT1946-4EA1 cover is needed to comply with the phase clearance.

  5) If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

  6) If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

  7) When connecting conductors which are larger than 25 mm², the 3RT1946-4EA1 cover must be used to keep the phase clearance.

Rated data of the auxiliary switches an	d signaling switches				
Type 3RV19		Lateral auxiliary switch with 1 NO + 1 NC, 2 NO, 2 NC, 2 NO + 2 NC;	Transverse auxiliary switches with 1 CO	1 NO + 1 NC, 2 NO	
		Signaling switches			
Max. Rated voltage					
• Acc. to NEMA (UL)	V AC	600		250	
• Acc. to NEMA (CSA)	V AC	600		250	
Uninterrupted current	А	10	5	2.5	
Switching capacity		A600 Q300	B600 R300	C300 R300	

SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

# General data

#### Voltage transformer circuit breakers

Size	General data				
Size	Туре		3RV1611-1AG14	3RV1611-1CG14	3RV1611-1DG14
Bated current In Ambient temperature         Ambient temperature         C -50 +80         400         45 × 90 × 70         46 × 90         40 × 90         40 × 90         40 × 90         40 × 90         40 × 90         40 × 90         40 × 90         40 × 90         40	Size		S00	S00	S00
Ambient temperature         °C -50 +80           • During storage/transport         °C -20 +60 (up to +70°C is possible with current reduction)           • During operation         °C -20 +60 (up to +70°C is possible with current reduction)           Rated operational voltage U <sub>0</sub> V 400           Rated insulation voltage U <sub>1</sub> V 690           Short-circuit breaking capacity I <sub>cu</sub> at 400 V AC         kA 50           Set value of the thermal overload release         A 1.4 2.5 3         3           Response value of the instantaneous overcurrent release         A 6±20 % 10.5±20 % 20±20 %         20±20 %           Tripping time of the instantaneous overcurrent release         ms Approx. 6 at 12 A Approx. 6 at 20 A Approx. 6 at	ᅱ  ̄	mm	45 x 90 x 70	45 x 90 x 70	45 x 90 x 70
• During storage/transport       °C       -50 +80         • During operation       °C       -20 +60 (up to +70°C is possible with current reduction)         Rated operational voltage U <sub>e</sub> V       400         Rated frequency       Hz       16.66 60         Rated insulation voltage U <sub>1</sub> V       690         Short-circuit breaking capacity I <sub>cu</sub> at 400 V AC       kA       50         Set value of the thermal overload release       A       1.4       2.5       3         Response value of the instantaneous overcurrent release       A       6±20 %       10.5±20 %       20±20 %         Tripping time of the instantaneous overcurrent release       ms       Approx. 6 at 12 A       Approx. 6 at 20 A       Approx. 6 at 12 A         Internal resistance       In cold state       Ω       > 0.25±6.5 %       Secondary       5         Shock resistance acc. to IEC 60068-2-27       g/ms       15       15         Degree of protection acc. to IEC 60529       IP20       Touch protection acc. to EN 50274       Finger-safe for vertical contact from the front         Endurance       Mechanical       Operating cycles       10 000         • Mechanical       Operating cycles       10 000         • Electrical       Operating cycles       10 000	Rated current I <sub>n</sub>	A	1.4	2.5	3
• During operation         °C         −20 +60 (up to +70°C is possible with current reduction)           Rated operational voltage U <sub>e</sub> V         400           Rated frequency         Hz         16.66 60           Rated insulation voltage U <sub>i</sub> V         690           Short-circuit breaking capacity I <sub>cu</sub> at 400 V AC         kA         50           Set value of the thermal overload release         A         1.4         2.5         3           Response value of the instantaneous overcurrent release         A         6 ± 20 %         10.5 ± 20 %         20 ± 20 %           Tripping time of the instantaneous overcurrent release         ms         Approx. 6 at 12 A         Approx. 6 at 20 A         Approx. 6 at 12 A         Approx. 6 at 20 A         Approx. 6 at 20 A         Approx. 6 at 12 A         Approx. 6 at 20 A         Approx. 6 at 12 A         Approx. 6 at 20 A         Approx. 6 at 12 A         Approx. 6 at 20 A         Approx. 6 at 12 A         Approx. 6 at 20 A         Approx. 6 at 12 A         Approx. 6 at 20 A         Approx. 6 at 20 A         Approx. 6 at 12 A         Approx. 6 at 20 A         Approx. 6 at 12 A         Approx. 6 at 20 A         Approx. 6 at 12 A         Approx. 6 at 20 A         Approx. 6 at 12 A         Approx. 6 at 20 A         Approx. 6 at 12 A         Approx. 6 at 20 A         Approx. 6 at 20 A         Approx. 6 at 20 A         Appr	Ambient temperature				
Rated operational voltage Ue   V   400	During storage/transport	°C	-50 +80		
Rated frequency	During operation	°C	-20 +60 (up to +7	0°C is possible with curr	ent reduction)
Rated insulation voltage $U_1$ V 690  Short-circuit breaking capacity $I_{cu}$ at 400 V AC kA 50  Set value of the thermal overload release A 1.4 2.5 3  Response value of the instantaneous overcurrent release A 6 $\pm$ 20 % 10.5 $\pm$ 20 % 20 $\pm$ 20 % Tripping time of the instantaneous overcurrent release ms Approx. 6 at 12 A Approx. 6 at 20 A Approx. 6 at 10 Approx. 6 at	Rated operational voltage U <sub>e</sub>	V	400		
Short-circuit breaking capacity $I_{\text{cu}}$ at 400 V AC	Rated frequency	Hz	16.66 60		
Set value of the thermal overload release         A         1.4         2.5         3           Response value of the instantaneous overcurrent release         A         6±20 %         10.5±20 %         20±20 %           Tripping time of the instantaneous overcurrent release         ms         Approx. 6 at 12 A         Approx. 6 at 20 A         Approx. 6 at 10 A         Approx. 6 at 20 A         Approx. 6	Rated insulation voltage $U_{\rm i}$	V	690		
Response value of the instantaneous overcurrent release       A $6 \pm 20 \%$ $10.5 \pm 20 \%$ $20 \pm 20 \%$ Tripping time of the instantaneous overcurrent release       ms       Approx. 6 at 12 A       Approx. 6 at 20 A <td>Short-circuit breaking capacity I<sub>cu</sub> at 400 V AC</td> <td>kA</td> <td>50</td> <td></td> <td></td>	Short-circuit breaking capacity I <sub>cu</sub> at 400 V AC	kA	50		
Tripping time of the instantaneous overcurrent release ms Approx. 6 at 12 A Approx. 6 at 20 A Approx. 6 at 10 A Approx. 6 at 20 Appro	Set value of the thermal overload release	А	1.4	2.5	3
Internal resistance $\Omega$ $> 0.25 \pm 6.5\%$ • In cold state $\Omega$ $> 0.30 \pm 6.5\%$ • In heated state $\Omega$ $> 0.30 \pm 6.5\%$ Shock resistance acc. to IEC 60068-2-27 $g/ms$ 15         Degree of protection acc. to IEC 60529       IP20         Touch protection acc. to EN 50274       Finger-safe for vertical contact from the front         Endurance       • Mechanical       Operating cycles       10 000         • Electrical       Operating cycles       10 000	Response value of the instantaneous overcurrent relea-	se A	6 ± 20 %	10.5 ± 20 %	20 ± 20 %
• In cold state $\Omega > 0.25 \pm 6.5 \%$ • In heated state $\Omega > 0.30 \pm 6.5 \%$ Shock resistance acc. to IEC 60068-2-27 $g/ms$ 15  Degree of protection acc. to IEC 60529 IP20  Touch protection acc. to EN 50274 Finger-safe for vertical contact from the front  Endurance • Mechanical Operating cycles 10 000 • Electrical Operating cycles 10 000	Tripping time of the instantaneous overcurrent release	ms	Approx. 6 at 12 A	Approx. 6 at 20 A	Approx. 6 at 40 A
• In heated state         Ω         > 0.30 ± 6.5 %           Shock resistance acc. to IEC 60068-2-27         g/ms         15           Degree of protection acc. to IEC 60529         IP20           Touch protection acc. to EN 50274         Finger-safe for vertical contact from the front           Endurance         • Mechanical         Operating cycles         10 000           • Electrical         Operating cycles         10 000	Internal resistance				
Shock resistance acc. to IEC 60068-2-27  Degree of protection acc. to IEC 60529  Touch protection acc. to EN 50274  Endurance  Mechanical  Operating cycles  Operating cycles  Operating cycles  10 000	• In cold state	Ω	$> 0.25 \pm 6.5 \%$		
Degree of protection acc. to IEC 60529  Touch protection acc. to EN 50274  Endurance  Mechanical  Operating cycles  Degree of protection acc. to IEC 60529  IP20  Finger-safe for vertical contact from the front  10 000  Degree of protection acc. to IEC 60529  Finger-safe for vertical contact from the front  10 000  10 000	In heated state	Ω	$> 0.30 \pm 6.5$ %		
Touch protection acc. to EN 50274  Endurance  Mechanical Operating cycles Electrical Operating cycles 10 000	Shock resistance acc. to IEC 60068-2-27	g/ms	15		
Endurance  Mechanical Operating cycles 10 000  Electrical Operating cycles 10 000	Degree of protection acc. to IEC 60529		IP20		
<ul> <li>Mechanical</li> <li>Electrical</li> <li>Operating cycles</li> <li>Operating cycles</li> <li>10 000</li> <li>10 000</li> </ul>	Touch protection acc. to EN 50274		Finger-safe for vertic	al contact from the front	
Electrical Operating cycles 10 000	Endurance				
	Mechanical	Operating cycles	10 000		
	Electrical	Operating cycles	10 000		
Permissible mounting position Any	Permissible mounting position		Any		

Туре			3RV1611-1AG14	3RV1611-1CG14	3RV1611-1DG14
Conductor cross-sections, main	circuit, 1 or 2 conductors				
Connection type			Screw termina	ls	
Terminal screw			Pozidriv size 2		
Conductor cross-sections (min./max.) connected	, 1 or 2 conductors can be				
Solid or stranded		$\text{mm}^2$	2 x (0.5 1.5) <sup>1)</sup> , 2 x	(0.75 2.5) <sup>1)</sup> , max. 4	
• Finely stranded with end sleeve (DIN 4	16228-1)	$\text{mm}^2$	2 x (0.5 1.5) <sup>1)</sup> , 2 x	(0.75 2.5) <sup>1)</sup>	
Auxiliary switches for blocking the	he distance protection				
With defined lateral assignment for bl	ocking distance protection		1 CO (for use as 1 N	O or 1 NC)	
Rated operational voltage U <sub>e</sub>	Alternating voltage	V	125		
Rated operational current I <sub>e</sub> /AC-14	at $U_{\rm e}$ = 125 V	Α	0.1		
Rated operational voltage U <sub>e</sub>	Direct voltage L/R 200 ms	V	60		
Rated operational current I <sub>e</sub> /DC-13	at $U_e = 60 \text{ V}$	Α	0.3		
Minimum load capacity		V mA	5 1		
Short-circuit protection for auxili	ary circuit				
Melting fuses operational class gG A			10		
Miniature circuit breakers C characteristic A			6 (prospective short-	circuit current < 0.4 kA)	

Auxiliary switches for other signaling purposes
For technical specifications, see the next page.

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

General data

#### Mountable accessories

Front transverse auxiliary switches				
		Switching capacity for different voltages		
		1 CO	1 NO + 1 NC, 2 NO	
Rated operational current I <sub>e</sub>				
<ul> <li>At AC-15, alternating voltage</li> </ul>				
- 24 V	Α	4	2	
- 230 V	A	3	0.5	
<ul> <li>At AC-12 = I<sub>th</sub>, alternating voltage</li> </ul>				
- 24 V	Α	10	2.5	
- 230 V	Α	10	2.5	
<ul> <li>At DC-13, direct voltage L/R 200 ms</li> </ul>				
- 24 V	Α	1	1	
- 48 V	A		0.3	
- 60 V	Α		0.15	
- 110 V	Α	0.22		
- 220 V	A	0.1		
Minimum load capacity	V	17		
• •	mA	1		

Front transverse solid-state com	patible auxiliary switches		
			Switching capacity for different voltages
			1 CO
Rated operational voltage U <sub>e</sub>	Alternating voltage	V	125
Rated operational current I <sub>e</sub> /AC-14	at $U_{\rm e}$ = 125 V	Α	0.1
Rated operational voltage U <sub>e</sub>	Direct voltage L/R 200 ms	V	60
Rated operational current I <sub>e</sub> /DC-13	at $U_{\rm e} = 60 \text{ V}$	Α	0.3
Minimum load capacity		V	5
		mA	1

Lateral auxiliary switches with signaling switch		
		Switching capacity for different voltages: Lateral auxiliary switch with 1 NO + 1 NC, 2 NO, 2 NC, 2 NO + 2 NC Signaling switch
Rated operational current I <sub>e</sub>		
<ul> <li>At AC-15, alternating voltage</li> <li>24 V</li> <li>230 V</li> <li>400 V</li> <li>690 V</li> </ul>	A A A	6 4 3 1
At AC-12 = I <sub>th</sub> , alternating voltage     24 V     230 V     400 V     690 V	A A A	10 10 10 10
<ul> <li>At DC, direct voltage L/R 200 ms</li> <li>24 V</li> <li>110 V</li> <li>220 V</li> <li>440 V</li> </ul>	A A A	2 0.5 0.25 0.1
Minimum load capacity	V mA	17 1

Auxiliary releases			
		Undervoltage releases	Shunt releases
Power consumption			
<ul><li>During pick-up</li><li>AC voltages</li><li>DC voltages</li></ul>	VA/W W	20.2/13 20	20.2/13 13 80
<ul><li>During uninterrupted duty</li><li>AC voltages</li><li>DC voltages</li></ul>	VA/W W	7.2/2.4 2.1	-
Response voltage			
Tripping	V	0.35 0.7 x <i>U</i> <sub>s</sub>	0.7 1.1 x <i>U</i> <sub>s</sub>
• Pick-up	V	0.85 1.1 x <i>U</i> <sub>s</sub>	
Opening time maximum	ms	20	

# SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

# General data

Short-circuit protection for auxiliary and control circuits		
Melting fuses operational class gG	А	10
Miniature circuit breakers C characteristic	Α	6 (prospective short-circuit current < 0.4 kA)

Conductor and control in a smill and a small circuits		
Conductor cross-sections for auxiliary and control circuits		
Connection type		Screw terminals
Terminal screw		Pozidriv size 2
Prescribed tightening torque	Nm	0.8 1.2
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded		
• Finely stranded with end sleeve (DIN 46228-1)	$mm^2$	2 x (0.5 1.5) <sup>1)</sup> / 2 x (0.75 2.5) <sup>1)</sup>
AWG cables	AWG	2 x (18 14)
Connection type		Spring-type terminals <sup>2)3)</sup>
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded	$mm^2$	2 x (0.25 2.5)
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	2 x (0.25 1.5)
• Finely stranded without end sleeve	$\text{mm}^2$	2 x (0.25 2.5)
AWG cables, solid or stranded	AWG	2 x (24 14)
Max. external diameter of the conductor insulation	mm	3.6

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

<sup>2)</sup> With conductor cross-sections ≤ 1 mm², an "insulation stop" must be used; see Chapter 3 "Controls – Contactors and Contactor Assemblies". → "Accessories".

<sup>3)</sup> Corresponding opening tool 3RA2908-1A, see "Accessories", page 7/76.

# **Motor Starter Protectors/Circuit Breakers** SIRIUS 3RV1 Motor Starter Protectors up to 100 A

For motor protection

# Selection and ordering data

#### CLASS 10, without auxiliary switches

	Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Setting range for thermal overload release		Short-circuit breaking capacity at 400 V AC	DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
	$I_{n}$		<u>G</u>	<i>I</i> >	$I_{ m CU}$		Article No.	Price per PU			
	Α	kW	A	A	kA						
Size S3											
,	40	18.5	28 40	520	50	<b>&gt;</b>	3RV1041-4FA10		1	1 unit	41E
775	50 63	22 30	36 50 45 63	650 819	50 50	<b>&gt;</b>	3RV1041-4HA10 3RV1041-4JA10		1 1	1 unit 1 unit	41E 41E
	75 <sup>2)</sup>	37	57 75	975	50	<b>—</b>	3RV1041-4KA10		1	1 unit	41E
	90 <sup>2)</sup>	45	70 90	1 170	50		3RV1041-4KA10		1	1 unit	41E
9	100 <sup>2)</sup>	45	80 100	1 235	50	•	3RV1041-4MA10		1	1 unit	41E
3RV1041-4LA10											
Size S3, with i	ncreased	d switching	capacity								
	16	7.5	11 16	208	100	<b>&gt;</b>	3RV1042-4AA10		1	1 unit	41E
777	20 25	7.5 11	14 20 18 25	260 325	100 100	<b>&gt;</b>	3RV1042-4BA10 3RV1042-4DA10		1	1 unit 1 unit	41E 41E
	32	15	22 32	416	100	•	3RV1042-4EA10		i	1 unit	41E
	40	18.5	28 40	520	100	<b>&gt;</b>	3RV1042-4FA10		1	1 unit	41E
1	50	22	36 50	650	100		3RV1042-4HA10		1	1 unit	41E
	63	30	45 63	819	100	<u> </u>	3RV1042-4JA10		1	1 unit	41E
	75 <sup>2)</sup> 90 <sup>2)</sup>	37 45	57 75 70 90	975 1 170	100 100	<b>&gt;</b>	3RV1042-4KA10 3RV1042-4LA10		1 1	1 unit 1 unit	41E 41E
22	100 <sup>2)</sup>	45	80 100	1 235	100	•	3RV1042-4MA10		i	1 unit	41E
3RV1042-4JA10											

#### CLASS 20, without auxiliary switches

40 18.5 50 22 63 30 75 <sup>2</sup> ) 37 90 <sup>2</sup> ) 45	capacity							
90 <sup>2)</sup> 45	36 50	520 650 819	100 100 100	Α	3RV1042-4FB10 3RV1042-4HB10 3RV1042-4JB10	1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
100 <sup>2</sup> ) 45	57 75 70 90 80 100	975 1 170 1 235	100 100 100		3RV1042-4KB10 3RV1042-4LB10 3RV1042-4MB10	1 1 1	1 unit 1 unit 1 unit	41E 41E 41E

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/70 onwards).

Multi-unit/reusable packaging available on request.

 $<sup>^{\</sup>rm 1)}$  Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

<sup>&</sup>lt;sup>2)</sup> For the use of 3RV104. motor starter protectors with an energy-efficient IE3 motor we recommend using a contactor for normal switching duty, see also page 7/53.

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Motor Starter Protectors up to 100 A

For motor protection with overload relay function

#### Selection and ordering data

#### CLASS 10, with overload relay function (automatic RESET), without auxiliary switches

	Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking capacity at 400 V AC	DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
	I <sub>n</sub>		<u>द</u>	[	$I_{ extsf{CU}}$		Article No.	Price per PU			
	A	kW	A 2)	A	kA						
Size S3, with it	ncrease	d switching	capacity <sup>2</sup>								
	16 20 25 32	7.5 7.5 11 15	11 16 14 20 18 25 22 32	208 260 325 416	100 100 100 100	A A A	3RV1142-4AA10 3RV1142-4BA10 3RV1142-4DA10 3RV1142-4EA10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
6	40 50 63	18.5 22 30	28 40 36 50 45 63	520 650 819	100 100 100	A A A	3RV1142-4FA10 3RV1142-4HA10 3RV1142-4JA10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
3RV1142-4AA10	75 <sup>3)</sup> 90 <sup>3)</sup> 100 <sup>3)</sup>	37 45 45	57 75 70 90 80 100	975 1 170 1 235	100 100 100	A A A	3RV1142-4KA10 3RV1142-4LA10 3RV1142-4MA10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/70 onwards).

 $<sup>^{2)}\,</sup>$  Accessories (auxiliary releases) for mounting on the right cannot be used.

<sup>&</sup>lt;sup>3)</sup> For the use of 3RV1142 motor starter protectors with an energy-efficient IE3 motor we recommend using a contactor for normal switching duty, see also page 7/53.

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Motor Starter Protectors up to 100 A

For starter combinations

# Selection and ordering data

#### Without auxiliary switches

	Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Thermal overload release <sup>2)</sup>	Instantaneous overcurrent releases	Short-circuit breaking capacity at 400 V AC	DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
	$I_{N}$		<u>द</u>	<i>I</i> >	$I_{\mathrm{CU}}$		Article No.	Price per PU			
0: 00	А	kW	Α	Α	kA						
Size S3											
775	40 50 63	18.5 22 30	Without Without Without	520 650 819	50 50 50	A A A	3RV1341-4FC10 3RV1341-4HC10 3RV1341-4JC10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
•	75 <sup>3)</sup> 90 <sup>3)</sup> 100 <sup>3)</sup>	37 45 45	Without Without Without	975 1 170 1 235	50 50 50	A A A	3RV1341-4KC10 3RV1341-4LC10 3RV1341-4MC10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
3RV1341-4JC10											
Size S3, with in	ncrease	d switching	capacity								
975	16 20 25 32	7.5 7.5 11 15	Without Without Without	208 260 325 416	100 100 100 100	A A A	3RV1342-4AC10 3RV1342-4BC10 3RV1342-4DC10 3RV1342-4EC10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
•	40 50 63	18.5 22 30	Without Without Without	520 650 819	100 100 100	A A A	3RV1342-4FC10 3RV1342-4HC10 3RV1342-4JC10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
3RV1342-4JC10	75 <sup>3)</sup> 90 <sup>3)</sup> 100 <sup>3)</sup>	37 45 45	Without Without Without	975 1 170 1 235	100 100 100	A A A	3RV1342-4KC10 3RV1342-4LC10 3RV1342-4MC10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/70 onwards).

Multi-unit/reusable packaging available on request.

<sup>&</sup>lt;sup>2)</sup> For overload protection of the motors, appropriate overload relays must be used


<sup>3)</sup> For the use of 3RV134. motor starter protectors with an energy-efficient IE3 motor we recommend using a contactor for normal switching duty, see also page 7/53.

SIRIUS 3RV1 Motor Starter Protectors up to 100 A

# For fuse monitoring

# Selection and ordering data

#### Without auxiliary switches



NIoto.

Multi-unit/reusable packaging available on request.

The auxiliary switch required for signaling must be ordered separately.

#### Accessories

	Version	Contacts	DT	Screw terminals  Article No.	Price	PU (UNIT, SET, M)	PS*	PG
Mountable au	xiliary switches (essential accessories)				per PU			
3RV1901-1E	Transverse auxiliary switches With screw terminals, mountable on front	1 NO + 1 NC	<b>&gt;</b>	3RV1901-1E		1	1 unit	41E
3RV1901-1A	Lateral auxiliary switches With screw terminals, mountable on the left	1 NO + 1 NC	•	3RV1901-1A		1	1 unit	41E

Additional auxiliary switches and other accessories, see "Accessories" page 7/70 onwards.

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Circuit Breakers up to 100 A

For system protection according to UL 489/CSA C22.2 No. 5

# Selection and ordering data

# Without auxiliary switches

Circuit breakers for system protection and non-motor loads according to UL/CSA

		Thermal overload releases (non-adjustable)	Instantaneous overcurrent release	Short-circuit break capacity at 480 Y/277 V AC <sup>2)</sup>	Ü	DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
	$I_{n}^{1)}$	<u> </u>	[	$I_{ m bc}$	$I_{ m bc}$		Article No.	Price per PU			
	Α	A	Α	kA	kA						
Size S3											
	10 15	10 15	150 225	65 65	65 65	B B	3RV1742-5AD10 3RV1742-5BD10		1 1	1 unit 1 unit	41E 41E
p	20 25	20 25	260 325	65 65	65 65	ВВ	3RV1742-5CD10 3RV1742-5DD10		1	1 unit 1 unit	41E 41E
The state of the s	30 35	30 35	390 455	65 65	65 	B B	3RV1742-5ED10 3RV1742-5FD10		1 1	1 unit 1 unit	41E 41E
	40 45	40 45	520 585	65 65		ВВ	3RV1742-5GD10 3RV1742-5HD10		1	1 unit 1 unit	41E 41E
Eleie	50	50	650	65		В	3RV1742-5JD10		1	1 unit	41E
3RV1742-5FD10	60 70	60 70	780 910	65 65		B B	3RV1742-5LD10 3RV1742-5QD10		1 1	1 unit 1 unit	41E 41E

Rated value 100 % according to UL 489 and IEC 60947-2 ("100 % rated breaker").

Transverse auxiliary switches must not be mounted, lateral auxiliary switches can be ordered separately (see "Accessories" page 7/70 onwards).


<sup>&</sup>lt;sup>2)</sup> Values for 600 Y/347 V AC, see page 7/57.

SIRIUS 3RV1 Motor Starter Protectors up to 100 A

# For distance protection

#### Selection and ordering data

#### Voltage transformer motor starter protectors with auxiliary switches (1 CO)



#### Accessories

	Version	Contacts	DT	Screw terminals	<b>(1)</b>	PU (UNIT, SET, M)	PS*	PG
			_	Article No.	Price per PU			
Mountable au	xiliary switches for other signaling pur	poses						
3RV1901-1A	Lateral auxiliary switches With screw terminals, mountable on the left	1 NO + 1 NC	•	3RV1901-1A		1	1 unit	41E

Additional auxiliary switches and other accessories, see "Accessories" page 7/70 onwards.

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A Accessories

Mountable accessories

# Overview

#### Mounting location and function

The 3RV1 motor starter protectors/circuit breakers have three main contact elements. In order to achieve maximum flexibility, auxiliary switches, signaling switches, auxiliary releases and isolator modules can be supplied separately.

These components are easily fitted to the switches without the use of any tools according to requirements.

Overview graphic, see page 7/51.

Front side Notes:  A maximum of four auxiliary contacts with auxiliary switches can be mounted on each motor starter protector.  Transverse auxiliary switches must not be used for the 3RV1742 circuit breakers.	Transverse auxiliary switches, solid-state compatible transverse auxiliary switches  1 NO + 1 NC or 2 NO or 1 CO	An auxiliary switch block can be inserted transversely on the front. The overall width of the motor starter protectors remains unchanged.				
Notes:     A maximum of four auxiliary contacts with auxiliary switches can be mounted on each motor starter protector/circuit breakers.     Lateral auxiliary switches (two contacts) and signaling switches can be mounted separately or together.     The signaling switch cannot be used for the 3RV1742 circuit breakers.	Lateral auxiliary switches (2 contacts) 1 NO + 1 NC or 2 NO or 2 NC	One of the three lateral auxiliary switches can be mounted on the left side per motor starter protector/circuit breaker. The contacts of the auxiliary switch close and open together with the main contacts of the motor starter protector/circuit breaker.  The width of the lateral auxiliary switch with two contacts is 9 mm.				
	Lateral auxiliary switches (4 contacts) 2 NO + 2 NC	One lateral auxiliary switch with four contacts can be mounted on the left side per motor starter protector/circuit breaker. The contacts of the auxiliary switch close and open together with the main contacts of the motor starter protector/circuit breaker.  The width of the lateral auxiliary switch with four contacts is 18 mm.				
	Signaling switches Tripping 1 NO + 1 NC Short circuit 1 NO + 1 NC	One signaling switch can be mounted on the left side of each motor starter protector.  The signaling switch has two contact systems.  One contact system always signals tripping irrespective of whether this was caused by a short circuit, an overload or an auxiliary release. The other contact system only switches in the event of a short circuit. There is no signaling as a result of switching off with the actuator.				
		In order to be able to switch on the motor starter protector again after a sh circuit, the signaling switch must be reset manually after the error cause h been eliminated.  The overall width of the signaling switch is 18 mm.				
Right-hand side	Auxiliary releases					
Notes:  • One auxiliary release can be mounted per motor starter protector/circuit breaker.	Shunt releases	For remote-controlled tripping of the motor starter protector/circuit breaker. The release coil should only be energized for short periods (see circuit diagrams).				
Accessories cannot be mounted at the right-hand side of the 3RV11 motor starter.	or					
right-hand side of the 3RV11 motor starte protectors for motor protection with overload relay function.	Undervoltage releases	Trips the motor starter protector/circuit breaker when the voltage is interrupted and prevents the motor from being restarted accidentally when the voltage is restored. Used for remote-controlled tripping of the motor starter protector/circuit breaker.				
		Particularly suitable for EMERGENCY-STOP disconnection by way of corresponding EMERGENCY-STOP pushbuttons according to DIN EN 60204-1.				
	or					
	Undervoltage releases with leading auxiliary contacts 2 NO	Function and use as for the undervoltage release without leading auxiliary contacts, but with the following additional function: the auxiliary contacts will open in switch position OFF to deenergize the coil of the undervoltage release, thus interrupting energy consumption. In the "tripped" position, these auxiliary contacts are not guaranteed to open. The leading contacts permit the motor starter protector/circuit breaker to reclose.  The overall width of the auxiliary release is 18 mm.				
		The everal wather the advinary release to 10 min.				

For a complete overview of which accessories can be used for the various motor starter protectors, see page 7/3.

# SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A Accessories

# Mountable accessories

#### Selection and ordering data Version Contacts For motor starter DT Screw terminals PS\* PG **(+)** (UNIT, protectors/ SET, M) circuit breakers Price Article No. per PU Size Auxiliary switches<sup>1)</sup> Transverse auxiliary switches 1 CO S00, S3 3RV1901-1D 41E With screw terminals, 1 NO + 1 NC 3RV1901-1E 1 unit 41E 00 00 mountable on front 2 NO 3RV1901-1F 1 unit 41E 3RV1901-1E 3RV1901-1G 41F Electronic compatible 1 CO S00, S3 Α 1 unit transverse auxiliary switches 0 0 0 With screw terminals. front mountable, 3RV1901-1G for operation in dusty atmosphere and in solid-state circuits with low operating currents Covers for transverse auxiliary S00, S3 $\triangleright$ 3RV1901-0H 1 10 units 41F switches 3RV1901-0H Lateral auxiliary switches 1 NO + 1 NC S00, S3 3RV1901-1A 41E 3RV1901-1B 3RV1901-1C 41E 41E With screw terminals, 2 NO 1 unit 2 NC mountable on the left 1 unit 2 NO + 2 NC 41E Α 3RV1901-1J 1 unit 3RV1901-1A 3RV1901-1J

<sup>1)</sup> Each motor starter protector can be fitted with one transverse and one lateral auxiliary switch. The lateral auxiliary switch with 2 NO + 2 NC is used without a transverse auxiliary switch. Transverse auxiliary switches must not be used for the 3RV1742 circuit breakers.

	Version	Contacts	For motor starter protectors/ circuit breakers	DT	Spring-type terminals	<u> </u>	PU (UNIT, SET, M)	PS*	PG
			Size		Article No.	Price per PU			
Auxiliary swit	tches <sup>1)</sup>								
3RV1901-2E	<b>Transverse auxiliary switches</b> With spring-type terminals, mountable on the front	1 NO + 1 NC 2 NO	S00, S3	•	3RV1901-2E 3RV1901-2F		1 1	1 unit 1 unit	41E 41E
3RV1901-2A	Lateral auxiliary switches With spring-type terminals, mountable on the left	1 NO + 1 NC 2 NO 2 NC	S00, S3	<b>* * *</b>	3RV1901-2A 3RV1901-2B 3RV1901-2C		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E

<sup>1)</sup> Each motor starter protector can be fitted with one transverse and one lateral auxiliary switch. Transverse auxiliary switches must not be used for the 3RV1742 circuit breakers.

# SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A Accessories

# Mountable accessories

	Version	For motor starter protectors	DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG	
			Size		Article No.	Price per PU			
Signaling swi	itches <sup>1)</sup>								
3RV1921-1M	Signaling switches One signaling switch can be mounted on the left per motor starter protector.	Separate tripped and short-circuit alarms, 1 NO + 1 NC each	S3	•	3RV1921-1M		1	1 unit	41E
1) This accessory	y cannot be used for the	e 3RV1742 circuit breakers.							

	Rated control supply voltage $U_{\rm S}$					For motor starter	DT	Screw terminals		PU	PS*	PG
	AC /	AC 60 Hz	AC	AC/DC 50/60 Hz,	DC	protectors/ circuit breakers	DI	Screw terminals	<b>+</b>	(UNIT, SET, M)	P5"	PG
	30 112	00112	100 % ON period <sup>1)</sup>	DC 5 s ON period <sup>2)</sup>								
	V	V	V	V	V	Size		Article No.	Price per PU			
Auxiliary relea	ases <sup>3)</sup>											
Administration		voltago	releases									
0		voitage	releases		0.4	00		0D1//000 / 4 D /			a 9	445
	 24				24	S3 S3	A A	3RV1902-1AB4 3RV1902-1AB0		1	1 unit 1 unit	41E 41E
<b>6</b> 00	110	120				S3	A	3RV1902-1AB0		1	1 unit	41E
100		208				S3	Α	3RV1902-1AM1		1	1 unit	41E
0	230	240				S3	<b>&gt;</b>	3RV1902-1AP0		1	1 unit	41E
3RV1902-1DP0	400	440				S3	<b>&gt;</b>	3RV1902-1AV0		1	1 unit	41E
3RV 1902-1DP0	415	480				S3	Α	3RV1902-1AV1		1	1 unit	41E
	500	600				S3	Α	3RV1902-1AS0		1	1 unit	41E
Undervoltage releases with leading auxiliary contacts 2 NO												
	230	240				S3	Α	3RV1922-1CP0		1	1 unit	41E
	400	440				S3	Α	3RV1922-1CV0		1	1 unit	41E
	415	480				S3	Α	3RV1922-1CV1		1	1 unit	41E
	Shunt releases											
			20 24	20 70		S3	<b>&gt;</b>	3RV1902-1DB0		1	1 unit	41E
			90 110	70 190		S3	Α	3RV1902-1DF0		1	1 unit	41E
			210 240 350 415	190 330 330 500		S3 S3	A	3RV1902-1DP0 3RV1902-1DV0		1	1 unit 1 unit	41E 41E
			500 415	500		S3	A	3RV1902-1DV0 3RV1902-1DS0		1	1 unit	41E 41E
			000	000		00					· arm	/ I L

 $<sup>^{1)}</sup>$  The voltage range is valid for 100 % (infinite) ON period. The response voltage lies at 0.9 of the lower limit of the voltage range.

<sup>2)</sup> The voltage range is valid for 5 s ON period at AC 50/60Hz and DC. The response voltage lies at 0.85 of the lower limit of the voltage range.

<sup>3)</sup> One auxiliary release can be mounted on the right per motor starter protector (does not apply to 3RV11 motor starter protectors with overload relay function).

# SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

Accessories

#### **Busbar accessories**

#### Overview

#### 8US busbar adapters for 40 mm and 60 mm systems

The motor starter protectors/circuit breakers are mounted directly with the aid of busbar adapters on busbar systems with 40 mm and 60 mm center-to-center clearance in order to save space and to reduce infeed times and costs. Busbar adapters for busbar systems with 40 mm center-to-center clearance are suitable for copper busbars with a width of 12 mm to 15 mm, while those with 60 mm center-to-center clearance are suitable for copper busbars with a width of 12 mm to 30 mm. The busbars can be 4 to 5 mm or 10 mm thick.

The motor starter protectors/circuit breakers are snapped onto the adapter and connected on the line side. This prepared unit is then plugged directly onto the busbar system, and is thus connected both mechanically and electrically at the same time. For further busbar adapters for snap-mounting direct-on-line starters and reversing starters as well as additional accessories such as line terminals and outgoing terminals, flat copper profile, etc., see Catalog LV 10 "Low-Voltage Power Distribution and Electrical Installation Technology".



SIRIUS load feeders with busbar adapters snapped onto busbars

#### Selection and ordering data

#### 8US busbar adapters





8US1111-4SM00

8US1211-4TR00

For motor starter protectors	Rated current	Connecting cable	Adapter length	Adapter width	Rated voltage	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Size	Α	AWG	mm	mm	V						
Busbar adapters	s for 40 mm sy	stems									
For flat copper profi Width: 12 mm and 1 Thickness: 5 mm and	5 mm	DIN 46433									
S3 S3	100 100	4 4	182 182	70 72	400 <sup>1)</sup> 415 690 <sup>2)</sup>	<b>&gt;</b>	8US1111-4SM00 8US1011-4TM00		1 1	1 unit 1 unit	140 140
Busbar adapters	s for 60 mm sy	stems									
For flat copper profit Width: 12 mm and 3 Thickness: 5 mm and also for T and doub	30 mm ad 10 mm										
S3 S3 S3 <sup>3)</sup>	100 100 70 <sup>4)</sup>	4 4 4	182 182 215	70 72 72	400 <sup>1)</sup> 415 690 <sup>2)</sup> 600 <sup>4)</sup>	A A	8US1111-4SM00 8US1211-4TM00 8US1211-4TR00		1 1 1	1 unit 1 unit 1 unit	140 140 140

- 1) At rated voltage
  - ≤ 400 V: short-circuit breaking capacity 50 kA, > 400 to 460 V: short-circuit breaking capacity 25 kA.
- 2) Short-circuit breaking capacity 415/500/525 V AC:

  - Up to  $I_{\rm n}=25$  A: max. 30 kA Up to  $I_{\rm n}=90$  A: max. 16 kA Up to  $I_{\rm n}=100$  A: max. 6 kA

  - Short-circuit breaking capacity 690 V AC:
  - Max. 12 kA
- 3) This busbar adapter is approved specially for 3RV1742 circuit breakers for applications according to UL/CSA.
- 4) Values according to UL/CSA
   Rated current: 70 A at 600 V AC;
  - Short-circuit breaking capacity 480 V AC: 65 kA, up to  $I_n = 30$  A; 480 Y/277 V AC: 65 kA, 600 Y/347 V AC: 20 kA

For additional busbar adapters, see Catalog LV 10 "Low-Voltage Power Distribution and Electrical Installation Technology".


SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A Accessories

Rotary operating mechanisms


#### Overview

#### Door-coupling rotary operating mechanisms

Motor starter protectors/circuit breakers with a rotary operating mechanism can be mounted in a control cabinet and operated externally by means of a door-coupling rotary operating mechanism. When the cabinet door with motor starter protector/circuit breaker is closed, the operating mechanism is coupled. When the motor starter protector/circuit breaker closes, the coupling is locked which prevents the door from being opened unintentionally. This interlock can be defeated by the maintenance personnel. In the OPEN position, the rotary operating mechanism can be secured against reclosing with up to three padlocks. Inadvertent opening of the door is not possible in this case either.



SIRIUS 3RV1926-0K door-coupling rotary operating mechanism



SIRIUS 3RV2946-2B door-coupling rotary operating mechanism for arduous conditions

#### Remote motorized operating mechanisms

3RV1 motor starter protectors/circuit breakers are manually operated controls. They automatically trip in case of an overload or short circuit. Intentional remote-controlled tripping is possible by means of a shunt release or an undervoltage release. Reclosing is only possible directly at the motor starter protector/circuit breaker.

The remote motorized operating mechanism allows the motor starter protectors/circuit breakers to be opened and closed by electrical commands. This enables a load or an installation to be isolated from the network or reconnected to it from an operator panel.


If the motor starter protector/circuit breaker is tripped as a result of overload or short circuit, it will be in tripped position. For reclosing, the remote motorized operating mechanism must first be set manually or electrically to the 0 position (electrically by means of the Open command). Then it can be reclosed.

The remote motorized operating mechanism is available for motor starter protectors/circuit breakers in size S3 for control voltages of 230 V AC and 24 V DC. The motor starter protector/circuit breaker is fitted into the remote motorized operating mechanism as shown in the drawing.

In the "MANUAL" position, the motor starter protector/circuit breaker in the remote motorized operating mechanism can continue to be switched manually on site. In the "AUTOMATIC" position, the motor starter protector/circuit breaker is switched by means of electrical commands. The switching command must be applied for a minimum of 100 ms. The remote motorized operating mechanism closes the motor starter protector/circuit breaker after a maximum of 1 s. On voltage failure during the switching operation it is ensured that the motor starter protector/circuit breaker remains in the "OPEN" or "CLOSED" position. In the "MANUAL" and "OFF" position, the remote motorized operating mechanism can be locked with a padlock.

#### RESET function

The RESET button on the motorized operating mechanism serves to reset any 3RV1921-1M signaling switch that might be installed.



SIRIUS 3RV1946-3A.. remote motorized operating mechanism

SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A Accessories

#### **Rotary operating mechanisms**

#### Technical specifications

Remote motorized operating mechanisms		
Туре		3RV1946
	W VA	48 170
Operating range		0.85 1.1 x U <sub>s</sub>
Minimum command duration at $U_{s}$	S	0.1
Max. command duration		Unlimited (uninterrupted operation)
Max. total break time, remote-controlled	S	2
Ready to reclose after approx.	S	2.5
Switching frequency	1/h	25
Internal back-up fuse • 230 V AC • 24 V DC	A A	0.8 1.6
Connection type of control cables		Plug-in connectors with screw terminals
Shock resistance acc. to IEC 60068-2-27	g/ms	25/11 (square and sine pulse)

#### Selection and ordering data

Version	Color of actuator	Version of extension shaft	For motor starter protectors/ circuit breakers	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		mm	Size						

#### Door-coupling rotary operating mechanisms

3RV2926-0B

The door-coupling rotary operating mechanisms consist of a knob, a coupling driver and a 130/330 mm long extension shaft (6 mm x 6 mm).

The door-coupling rotary operating mechanisms are designed to degree of protection IP64. The door locking device prevents accidental opening of the control cabinet door in the ON position of the motor starter protector/circuit breaker. The OFF position can be locked with up to 3 padlocks.

Door-coupling rotary operating mechanisms	Black	130 330	S3 S3	•	3RV2926-0B 3RV2926-0K	1	1 unit 1 unit	41E 41E
EMERGENCY STOP door- coupling rotary operating mechanisms	Red/yellow	130 330	S3 S3	<b>*</b>	3RV2926-0C 3RV2926-0L	1	1 unit 1 unit	41E 41E

#### operating mechanisms for arduous conditions Door-coupling rotary



3RV2946-2B

The door-coupling rotary operating mechanisms consist of a knob, a coupling driver, an extension shaft of 300 mm in length (8 mm x 8 mm), a spacer and two metal brackets, into which the motor starter protector/circuit breaker is inserted.

The door-coupling rotary operating mechanisms are designed to degree of protection IP65. The door interlocking reliably prevents opening of the control cabinet door in the ON position of the motor starter protector/circuit breaker. The OFF position can be locked with up to three padlocks.

Laterally mountable auxiliary releases and two-pole auxiliary switches can be used.

The door-coupling rotary operating mechanisms thus meet the requirements for isolating functions according to IEC 60947-2.

Door-coupling rotary operating mechanisms	Gray	300	S3	<b>&gt;</b>	3RV2946-2B	1	1 unit	41E
EMERGENCY STOP door- coupling rotary operating mechanisms	Red/yellow	300	\$3	•	3RV2946-2C	1	1 unit	41E

Version	Rated control supply voltage $U_{\rm S}$	For motor starter protectors/ circuit breakers	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		Size						

## Remote motorized operating mechanisms



Remote motorized operating mechanisms AC 50/60 Hz, 230 V 24 V DC

3RV1946-3AP0 3RV1946-3AB4

1 unit 41E 1 unit

41E

SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A Accessories


**Mounting accessories** 

## Overview

# Terminal blocks for "Self-Protected Combination Motor Controllers (Type E)" according to UL 508/UL 60947-4-1

The 3RV10 motor starter protector/circuit breakers in size S3 are approved according to UL 508/UL 60947-4-1 as "Self-Protected Combination Motor Controllers" (Type E).

This requires increased clearance and creepage distances (1 inch and 2 inches respectively) at the input side of the device, which are achieved by replacing the standard box terminal with the 3RT1946-4GA07 terminal block.



Terminal block (Type E) SIRIUS 3RT1946-4GA07

According to CSA, the terminal blocks can be omitted when the device is used as a "Self-Protected Combination Motor Controller" (Type E).

## Selection and ordering data

#### Accessories

Accessories								
	Version	For motor starter protectors/ circuit breakers	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		Size						
Covers								
4	Terminal covers for box terminals Additional touch protection to be fitted at the box terminals (2 units mountable per device)	S3	•	3RT1946-4EA2		1	1 unit	41B
	Terminal covers For cable lug and busbar connection for maintaining the required voltage clearances and as touch protection if box terminal is removed (2 units can be mounted per motor starter protector/circuit breaker)	S3	В	3RT1946-4EA1		1	1 unit	41B
3RV1 (size S3) with 3RT1946-4EA1 (left)	Scale covers	S3	<b>&gt;</b>	3RV1908-0P		100	10 units	41E
3RV1908-0P (right)	Sealable, for covering the set current scale							
Fixing accessories								
	Push-in lugs For screwing the motor starter protector onto mounting plates	S00	А	3RB1900-0B		100	10 units	41F
测∦ 3RB1900-0B	For each motor starter protector, two units are required.							
	Self-Protected Combination Motor Control	lers (Type	E)"					
2011040 40407	Note: UL 508/UL 60947-4-1 approval demands 1-inch cle 2-inch creepage distance for "Combination Motor type E". The following terminal blocks must be use in 3RV10 motor starter protector size S3.	Controllers						
3RT1946-4GA07	The terminal blocks are not required for use accord	ding to CSA.						
	With size S3, these terminal blocks cannot be used combination with a transverse auxiliary switch.	d in						
	<b>Terminal block type E</b> for extended clearance and creepage distances (1 and 2 inch)	S3	В	3RT1946-4GA07		1	1 unit	41B
Auxiliary terminals, 3	-pole							
3RT1946-4F	For connection of auxiliary and control cables to the main conductor connections (for one side)	S3	В	3RT1946-4F		1	1 unit	41B

SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

# Accessories

# Mounting accessories Link modules

	Actuating voltage of contactor	Size Contactors	protect		DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
						Article No.	Price per PU			
Link modules from m	otor starter protec	tor/circuit breal	ker to cor	itactor						
	For mechanical and starter protector/circuterminals									
	Single-unit packagi	ng								
de de	AC	S3	S3		<b>&gt;</b>	3RA1941-1AA00		1	1 unit	41B
/	DC	S3	S3		<b>&gt;</b>	3RA1941-1BA00		1	1 unit	41B
	Multi-unit packaging	9								
3BA1941-1AA00	AC	S3	S3		<b>&gt;</b>	3RA1941-1A		1	5 units	41B
311A 134 1-1AA00	DC	S3	S3		<b>&gt;</b>	3RA1941-1B		1	5 units	41B
Miscellaneous acces	sories									
	Version	Size	Color	For motor starter protectors/ circuit breakers	DT	Spring-type terminals		PU (UNIT, SET, M)	PS*	PG
						Article No.	Price			
				Size			per PU			
Tools for opening spr	ring-type terminals	;								
3RA2908-1A	Screwdrivers For all SIRIUS devices with spring-type terminals	Length approx. 200 mm, 3.0 mm x 0.5 mm	Titanium gray/ black, partially insulated	S3	Α	3RA2908-1A		1	1 unit	41B


SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A Accessories

Front plates

# Overview

## Front plates

Motor starter protectors are frequently required to be actuated in any enclosure. Front plates equipped with a rotary operating mechanism for 3RV1.4. motor starter protectors/circuit breakers are available for this purpose.



Front plate for size S3

## Selection and ordering data

	Version	Degree of protection	For motor starter protectors Size	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Front plates									
	Molded-plastic front plates with rotary operating mechanism, lockable in 0 position	IP55 (front side)	S3	•	3RV1923-4B		1	1 unit	41E
	For actuation of 3RV1 motor starter protectors in any enclosure								
3RV1923-4B	Molded-plastic front plates with EMERGENCY-STOP rotary operating mechanism, red/yellow, lockable in 0 position	IP55 (front side)	S3	Α	3RV1923-4E		1	1 unit	41E
	EMERGENCY-STOP actuation of 3RV1 motor starter protectors in any enclosure								
	Version	Rated control supply voltage $U_s$	For motor starter protectors Size	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Indicator lights		V	Size						
3RV1903-5B	Indicator lights For all enclosures and front plates  • With LED lamp for versions 110 120 V, with glow lamp for versions 220 500 V  • With colored lenses red, green, yellow, orange and clear	110 120 220 240 380 415 480 500	S3	CCCC	3RV1903-5B 3RV1903-5C 3RV1903-5E 3RV1903-5G		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E

SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

#### General data

#### Overview



SIRIUS 3RV1063-7AL10 molded case motor starter protector

The 3RV10 and 3RV13 molded case motor starter protectors for up to 800 A are compact, current-limiting motor starter protectors which can be used above all in motor feeders for special voltages of 440 V, 480 V, 550 V and 690 V. They are used for switching and protecting three-phase motors and other loads with rated currents up to 800 A.

#### Note:

For motor feeders above 100 A and at 400 V and 500 V, the 3VL molded case circuit breakers must be used, see Catalog LV 10 "Low-Voltage Power Distribution and Electrical Installation Technology".

#### Type of construction

The molded case motor starter protectors are available in 4 widths:

- 3RV1353 width 90 mm, max. rated current 32 A, at 550 V AC suitable for three-phase motors up to 22 kW
- 3RV1.6. width 105 mm, max. rated current 250 A, at 690 V AC suitable for three-phase motors up to 160 kW
- 3RV1.7. width 140 mm, max. rated current 630 A, at 690 V AC suitable for three-phase motors up to 315 kW
- 3RV1.83 width 210 mm, max. rated current 800 A, at 690 V AC suitable for three-phase motors up to 500 kW

The 3RV1 molded case motor starter protectors for up to 800 A can be mounted in horizontal, vertical or lying arrangement directly on a mounting plate or mounting rail. Their rated data are adversely affected as the result.

The phase barriers for better insulation between the phases are included in the scope of supply, and it is essential to use them.

The motor starter protectors can be supplied through top and bottom terminals without impairing their function, enabling them to be installed in any type of switchgear without any further steps.

#### Connection methods

The 3RV1 molded case motor starter protectors for up to 800 A are suitable solely for screw connection.

**(1)** 

Screw terminals

The terminals are indicated in the corresponding tables by the symbols shown on orange backgrounds.

#### Article No. scheme

Dinit of the Auticle No.	1 - 4 O 1	441-	E4L	CHI-	741-		OHL	OHL	4 041-	4 4 4 1 -	4 04-		4.041-	4 441-	4 544	4.04-	
Digit of the Article No.	1st - 3rd	4th	อเท	6th	7th		8th	9th	Tuth	Hitn	12th		I3th	14th	15th	Ioth	
						-						-					
Molded case motor starter protectors	3 R V																
SIRIUS 1st generation		1															
Type of motor starter protector																	
Size																	
Breaking capacity																	
Setting range for overload release																	
Trip class (CLASS)																	
Connection methods																	
With or without auxiliary switch																	
Special versions																	
Example	3 R V	1	0	6	3	-	7	Α	L	1	0						

#### Note:

The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

General data

#### Benefits

- High short-circuit breaking capacity in the feeder
- Optimum usability in motor feeders for the special voltages 440 V, 480 V, 550 V and 690 V
- Compact design

- The releases are available both in purely magnetic (up to 32 A) and in solid-state versions (100 A to 800 A)
- Available for motor or starter protection (short-circuit protection alone)

#### Application

#### Operating conditions

The 3RV1 molded case motor starter protectors for up to 800 A can be operated at ambient temperatures between -25 °C and +70 °C. They can be used according to IEC 60721-2-1 in the most difficult environmental conditions with a hot and damp climate

Since operational currents, starting currents and current peaks are different even for motors with identical power ratings due to the inrush current, the motor ratings in the selection tables are only guide values. The specific rated and start up data of the motor to be protected is always paramount to the choice of the most suitable molded case motor starter protectors.

The 3RV1 molded case motor starter protectors up to 800 A have not been tested for use with frequency converters. The possibility of premature tripping in such applications cannot therefore be ruled out.

#### Possible uses

The 3RV1 molded case motor starter protectors for up to 800 A are suitable as switching and protection devices for motors. The following versions are available:

- For motor protection;
  - the overload and short-circuit releases are designed for optimized protection and direct-on-line starting of induction squirrel-cage motors. The motor starter protectors have an electronic release which not only provides short-circuit and overload protection but is also sensitive to phase failure and phase unbalance and offers protection in the event of rotor blockage.
- For starter combinations;

these molded case motor starter protectors are used for short-circuit protection in combinations of circuit breaker, motor contactor and overload relay. They are equipped with a purely magnetic release (up to 32 A) or a solid-state release (100 A to 800 A).

#### Standards and specifications

The electronic releases for motor protection comply with IEC 60947-4-1. Isolating features are also compliant with IEC 60947-2.

The 3RV1 molded case motor starter protectors comply in addition with IEC 60068-2-6 (shock and vibration strength) and are certified for the specifications of the most important marine classification societies:

- RINA
- Det Norske Veritas
- Bureau Veritas
- Lloyds Register of Shipping
- Germanischer Lloyd
- American Bureau of Shipping

## SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

## General data

## Technical specifications

General data										
Туре		3RV1063	3RV1073	3RV1083	3RV1353	3RV1363	3RV1364	3RV1373	3RV1374	3RV138
Dimensions										
• W = 1	mm	105	140	210	90	105	105	140	140	210
• H	mm	205	205	268	130	205	205	205	205	268
<u> </u>	mm	139	139	159	102	139	139	139	139	159
Standard Mater metastics			7-2, EN 609	147-2						
Motor protection		✓ 								
Starter combinations	^		400	000	<b>√</b>	050		400,000		000 000
Rated current I <sub>n</sub>	Α	160	400	630	160	250		400, 630		630, 800
Number of poles		3								
Rated operational voltage $U_e$ 50 60 Hz AC		690								
Rated impulse withstand voltage U <sub>imp</sub>	V	8								
Rated insulation voltage U <sub>i</sub>	V	1 000			800	1 000				
Test voltage at industrial frequency for 1 min	V	3 500			3 000	3 500				
Rated ultimate short-circuit breaking capacity $I_{\rm cu}$										
• At 220/230 V AC, 50 60 Hz	kA	200			120	200				
• At 380/415 V AC, 50 60 Hz	kA	120		100	85	120	200	120	200	100
• At 440 V AC, 50 60 Hz	kA	100		80	75	100	180	100	180	80
• At 500 V AC, 50 60 Hz	kA	85		65	50	85	150	85	150	65
• At 550 V AC, 50 60 Hz	kA				35					
• At 690 V AC, 50 60 Hz	kA	70		30	10	70	80	70	80	30
Rated service short-circuit breaking capacity $I_{cs}$ (% of $I_{cu}$ )							_		_	
• At 220/230 V AC, 50 60 Hz	%	100		75	100					75
• At 380/415 V AC, 50 60 Hz	%	100		75		100				75
• At 440 V AC, 50 60 Hz	%	100		75		100				75
• At 500 V AC, 50 60 Hz	%	100		75		100		100 <sup>1)</sup> /75 <sup>2)</sup>	100	75
• At 690 V AC, 50 60 Hz	%	100		75		100		100 <sup>1)</sup> / 50 <sup>2)</sup>	100	75
Rated short-circuit making capacity (415 V)	kA	264		220	187	264	440	264	440	220
Break time (415 V at $I_{CU}$ )	ms	5	6	7	3	5		6		7
Category (IEC 60947-2)		A	B (400 A),		A			B (400 A),		В
Isolating features		1	A (630 A)					A (630 A)		
Trip class CLASS		10A, 10, 2	20. 30							
Releases		. , , .	,							
Magnetic type					1					
Electronic (motor protection)		1			3)					
Electronic (starter combinations)						1				
Permissible ambient temperature						•				
Operation	°C	-25 +70	) <sup>4)</sup>							
• Storage	°C	-40 +70								
Mechanical endurance		10 170								
Operating cycles		20 000			25 000	20 000				
Operating cycles     Operating cycles per hour		240	120		240	20 000		120		
Electrical endurance		240	120		240			120		
Operating cycles		8 000	7 000	5 000	8 000			7 000		5 000
<ul> <li>Operating cycles</li> <li>Operating cycles per hour (415 V AC)</li> </ul>							60			
Operating cycles per nour (415 v AC)      Has this function.		120	60					lded case n		

<sup>✓</sup> Has this function

<sup>--</sup> Does not have this function

<sup>1)</sup> Value applies for 3RV1373-7GN10 molded case motor starter protectors.

 $<sup>^{2)}\,</sup>$  Value applies for 3RV1373-7JN10 molded case motor starter protectors.

<sup>3)</sup> For overload protection of the motors, appropriate overload relays must be used.

<sup>4)</sup> From 50 °C, please note derating, see "Reference Manual "Protection Equipment – Circuit Breakers · Molded Case Circuit Breakers", http://support.automation.siemens.com/WW/view/en/35681600.

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

Pront-secessible standard terminals	Main circuit terminals						
Front-accessible standard terminals	Туре		3RV1353	3RV1.6.	3RV1.7.		3RV1383-7KN10
Busbars   Cable lug   Number   Unit(s)   11	OBBIO OBSIN					3111/303-70110	
Number   Unit(s)   11	Front-accessible standard terminals						
Dimensions	_						
M		Unit(s)	11			2	
D			00	0.5	0.5		50
• H         mm         7.5         9.5         11         12           Lock hasp diameter         mm         6.5         8.5         10.5         7           Front-extended terminals           Busbars           Number         Unit(s)         1         2           Dimensions         • W         mm         20         30         40         50           • W         mm         8.5         10         11         • W         14           Cable lug           Number         Unit(s)         1         2         2           Dimensions         ***         ***         ***         ***           Womber         Mm 8.5         10         11         ***         ***           **** **         ***				25 8			50
Pront-extended terminals   Busbars   Substance   Sub	• H	mm	7.5	9.5	11	12	
Number   N		mm	6.5	8.5	10.5	7	
Number   N							
Dimensions         N         mm         20         30         40         50           D         mm         4         10         7         5         5           Lock hasp diameter         mm         8.5         10         11         1           Cable lug           Number         Unil(s)         1         2         2           Dimensions           *W         mm         20         30         40         50           Lock hasp diameter         mm         8.5         10         11         **         14           Front-extended cable terminals for copper cable           Busbars, flexible           Number         Unil(s)         1         =         -		Linit/a\	1		0		
M		Unit(S)	1		2		
D		mm	20		30	40	50
Cable lug   Number	• D		4		7	5	5
Number   N		mm	8.5	10	11		14
Dimensions   W	_	1.1-:4/-)	4		0		
• W o		Unit(s)	1		2		
• Lock hasp diameter		mm	20		30	40	50
Number   Unit(s)   1				10		40	
Number       Unit(s)       1							
Dimensions W x D x N         • W       mm       13       15.5       24          • D       mm       0.5       0.8       1          • N (= number of laminations)       mm       10           Cable lug, flexible         Number       Unit(s)       1 or 2           Dimensions              • For 1 unit       mm²       1 70       2.5 120       16 240            Cable lug, rigid       Number       Unit(s)       1       1 or 2           Dimensions  -	Busbars, flexible						
• W	Number	Unit(s)	1				
• D							
N (= number of laminations)       mm       10          Cable lug, flexible       Number       Unit(s)       1 or 2          Dimensions            • For 1 unit       mm² 1 70 2.5 120 2.5 95 16 150          • For 2 units       mm² 1 50 2.5 95 16 150          Cable lug, rigid       Number       Unit(s)       1       1 or 2          Dimensions              • For 1 unit - For 2 units (for outside mounting)       mm²        120 240          • For 2 units (for outside mounting)        120 240           • For 2 units (for outside mounting)        120 240           • For 2 units (for outside mounting)        2            • Por 2 units (for outside mounting)        2                           <							
Number       Unit(s)       1 or 2          Dimensions       • For 1 unit       mm² 1 70 2.5 120 16 240       • For 2 units          • For 2 units       mm² 1 50 2.5 95 16 150       • Cable lug, rigid         Number       Unit(s)       1       1 or 2          Dimensions       • For 1 unit • For 2 units (for outside mounting)       mm² 1 95 2.5 185 16 300 120 240       • For 2 units (for outside mounting)          Rear terminals         Busbars         Number       Unit(s)       1       2         Dimensions       • W       mm 20 30 40 50       50 50         • D       mm 4 1 10 7 7 5       5	=			0.0	'		
Dimensions         • For 1 unit       mm² 1 70 2.5 120 2.5 95 16 240	Cable lug, flexible						
• For 1 unit	Number	Unit(s)	1 or 2				
◆ For 2 units       mm²       1 50       2.5 95       16 150          Cable lug, rigid         Number       Unit(s)       1       1 or 2          Dimensions       • For 1 unit       mm²       1 95       2.5 185       16 300          • For 2 units (for outside mounting)       mm²        120 240          Rear terminals         Busbars         Number       Unit(s)       1       2         Dimensions         • W       mm       20       30       40       50         • D       mm       4       10       7       5	Dimensions	_					
Cable lug, rigid       Number     Unit(s)     1     1 or 2        Dimensions          • For 1 unit     mm² 2     1 95 2.5 185 16 300 120 240 120							
Number       Unit(s)       1       1 or 2          Dimensions       • For 1 unit       mm² and 2		111111-	1 30	2.0 90	10 130	-	
Dimensions  • For 1 unit • For 2 units (for outside mounting)  Rear terminals  Busbars  Number  Unit(s) 1  • W • D • D • D • D • Mm • D • Mm • D • Mm • D • Mm		(Init(s)	1		1 or 2		
<ul> <li>For 1 unit</li></ul>		01111(0)			. 01 2		
Rear terminals       Busbars       Number     Unit(s)     1     2       Dimensions       • W     mm     20     30     40     50       • D     mm     4     10     7     5		$\text{mm}^2$	1 95	2.5 185	16 300		
Busbars       Number     Unit(s)     1     2       Dimensions       • W     mm     20     30     40     50       • D     mm     4     10     7     5	For 2 units (for outside mounting)	mm <sup>2</sup>			120 240		
Number     Unit(s)     1     2       Dimensions       • W     mm     20     30     40     50       • D     mm     4     10     7     5							
Dimensions       • W     mm     20     30     40     50       • D     mm     4     10     7     5							
• W mm 20 30 40 50 • D mm 4 10 7 5		Unit(s)	1		2		
• D mm 4 10 7 5		no.u-	20		20	40	50
• Lock hasp diameter mm 8.5 11 14				10	30 7	40 5	50
	Lock hasp diameter				11	14	

SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

Auxiliary switches		
Туре		3RV1991-1.A0
Rated operational current I <sub>e</sub>		
• At 250 V AC/DC		
<ul> <li>At AC-14 (utilization category according to IEC 60947-5-1)</li> <li>Control supply voltage 125 V</li> <li>Control supply voltage 250 V</li> </ul>	A A	6 5
<ul> <li>At DC-13 (utilization category according to IEC 60947-5-1)</li> <li>Control supply voltage 125 V</li> <li>Control supply voltage 250 V</li> </ul>	A A	0.3 0.15
• At 24 V DC		
- Control supply voltage 24 V	mA	≥ 0.75
- Control supply voltage 5 V	mA	≥1


Auxiliary releases					
		Power cons	umption during p	oick-up	
Molded case motor starter protectors	3RV1353		3RV1.6., 3R	V1.7., 3RV1.83	
Version		AC	DC	AC	DC
Undervoltage releases		3RV1952-1A	0	3RV1982-1A	A.0
• 24 30 V AC/DC • 110 127 V AC/110 125 V DC • 220 240 V AC/220 250 V DC		1.5 VA 2 VA 2.5 VA	1.5 W 2 W 2.5 W	6 VA 6 VA 6 VA	150 W 150 W 150 W
Opening times	ms	15	15	≤ 25	≤ 15
Shunt releases		3RV1952-1E	.0	3RV1982-1E	.0
24 30 V AC/DC     110 127 V AC/110 125 V DC     220 240 V AC/220 250 V DC		50 VA 50 VA 50 VA	50 W 50 W 50 W	150 VA 150 VA 150 VA	150 W 150 W 150 W
Opening times	ms	15	15	15	15

## Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

For motor protection

## Selection and ordering data

#### CLASS 10A, 10, 20, 30; without auxiliary switch



## With electronic releases



Standard switching capacity,	adjustable short-circuit and overload release, 7	TU 4
------------------------------	--	------

Otarra	ara switterining ou	paony, adjustusie si	ioni omouni	and overn	da reiease, ro 4			
100	40 100	600 1 300	120	D	3RV1063-7AL10	1	1 unit	41E
160	64 160	960 2 080	120	D	3RV1063-7CL10	1	1 unit	41E
200	80 200	1 200 2 600	120	D	3RV1063-7DL10	1	1 unit	41E
400	160 400	2 400 5 200	120	D	3RV1073-7GL10	1	1 unit	41E
630	252 630	3 780 8 190	100	D	3RV1083-7JL10	1	1 unit	41E

TU = trip unit (release)


Further accessories can be ordered separately (see "Accessories" page 7/85 onwards).

SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

## For starter combinations

### Selection and ordering data

## Without auxiliary switches



#### With magnetic releases



3RV1353-6.P10

Stand	ard switching	i capacity, non-a	adjustable snort-ci	rcuit relea	ise, IU 1					
1	Without	13	85	D	3RV1353-6AP10	1	1 unit	41E		
1.6	Without	21	85	D	3RV1353-6BP10	1	1 unit	41E		
2	Without	26	85	D	3RV1353-6CP10	1	1 unit	41E		
3.2	Without	42	85	D	3RV1353-6DP10	1	1 unit	41E		
4	Without	52	85	D	3RV1353-6EP10	1	1 unit	41E		
5	Without	65	85	D	3RV1353-6FP10	1	1 unit	41E		
6.5	Without	85	85	D	3RV1353-6GP10	1	1 unit	41E		
8.5	Without	111	85	D	3RV1353-6HP10	1	1 unit	41E		
12.5	Without	163	85	D	3RV1353-6JP10	1	1 unit	41E		
Standard switching capacity, adjustable short-circuit release, TU 2										

20	Without	120 240	85	D	3RV1353-6LM10	1	1 unit	41E
32	Without	192 384	85	D	3RV1353-6MM10	1	1 unit	41E
With electronic rel	eases							



3RV13..-7.N10

Standa	rd switchin	g capacity,	adjusta	ble short-circuit	release, 1	TU 3
100	Without	100	1 000	120	D	3RV1363-7AN10

100	Without	100 1 000	120	D	3RV1363-7AN10	1	1 unit	41E
160	Without	160 1 600	120	D	3RV1363-7CN10	1	1 unit	41E
250	Without	250 2 500	120	D	3RV1363-7EN10	1	1 unit	41E
400	Without	400 4 000	120	D	3RV1373-7GN10	1	1 unit	41E
630	Without	630 6 300	120	D	3RV1373-7JN10	1	1 unit	41E
630	Without	630 6 300	100	D	3RV1383-7JN10	1	1 unit	41E
800	Without	800 8 000	100	D	3RV1383-7KN10	1	1 unit	41E
Increa	sed switching	g capacity, adjustab	le short-circ	uit release,	TU 3	_		

800	vvitnout	800 8 000	100	D	3HV1383-7KN10	1	1 unit	41E
Increa	sed switching	g capacity, adjustabl	le short-circ	uit release,	TU 3			
100 160 250	Without Without Without	100 1 000 160 1 600 250 2 500	200 200 200	D D D	3RV1364-7AN10 3RV1364-7CN10 3RV1364-7EN10	1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
400	Without	400 4 000	200	D	3RV1374-7GN10	1	1 unit	41E

TU = trip unit (release)

Further accessories can be ordered separately (see "Accessories" page 7/85 onwards).

#### More information

#### Manual

Configuration Manual "SIRIUS Configuration - Selection Data for Fuseless Load Feeders", see

http://support.automation.siemens.com/WW/view/en/68115040.

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A Accessories

# Mountable accessories

Selection and ord	ering data									
	Туре	Version		For molded case motor starter protectors	DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
						Article No.	Price per PU			
Auxiliary switches	3						<u> </u>			
57/17/100	Auxiliary switches for front mounting	1 signaling sv + 1 tripped si (250 V AC/DC	ignal	3RV1353, 3RV1.6.	D	3RV1991-1AA0		1	1 unit	41E
		3 signaling sv + 1 tripped si (250 V AC/D0		3RV1.83	D	3RV1991-1BA0		1	1 unit	41E
		3 signaling switches Off-On + 1 tripped signal (24 V DC)			D	3RV1991-1CA0		1	1 unit	41E
3RV1991-1AA0	Connection cables for auxiliary switches	Length 2 m, 6	6-pole	3RV1353, 3RV1.6.	D	3RV1991-1FA0		1	1 unit	41E
				3RV1.83						
	Туре	Rated control voltage $U_s$	l supply DC	For molded case motor starter protectors	DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
		50/60 Hz		ļa: atau atau a		Article No.	Price			
		V	V				per PU			
Auxiliary releases	Undervoltage	24 30	24 30	3RV1353	D	3RV1952-1AA0		1	1 unit	41E
3 3 3 3 3	releases for front mounting	110 127 220 240	110 125 220 250		D D	3RV1952-1AD0 3RV1952-1AE0		1 1	1 unit 1 unit	41E 41E
		24 30 110 127 220 240	24 30 110 125 220 250	3RV1.6.  3RV1.83	D D	3RV1982-1AA0 3RV1982-1AD0 3RV1982-1AF0		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
3RV1952-1AA0										
60/11/10	Shunt releases for front mounting	24 30 110 127 220 240	24 30 110 125 220 250	3RV1353	D D D	3RV1952-1EA0 3RV1952-1ED0 3RV1952-1EF0		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
		24 30 110 127 220 240	24 30 110 125 220 250	3RV1.6.  3RV1.83	D D D	3RV1982-1EA0 3RV1982-1ED0 3RV1982-1EF0		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
3RV1952-1EA0	Connection cables	Length 2 m,		3RV1353,	D	3RV1992-1FA0		1	1 unit	41E
	for undervoltage and shunt releases	6-pole		3RV1.6.  3RV1.83						

3RV1.83

SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A Accessories

Rotary operating mechanisms, mounting accessories

Selection and orde	ring data								
	Version		For molded case motor starter protectors	DT	Screw terminals	<b>(1)</b>	PU (UNIT, SET, M)	PS*	PG
					Article No.	Price per PU			
Rotary operating m	echanisms								
	Lever-type	With adjustable distance, with lock/door interlocking	3RV1353	D	3RV1956-0BA0		1	1 unit	41E
Train of the	rotary operating mechanisms	(padlocks are not included in scope of supply)	3RV1.6., 3RV1.7. 3RV1.83	D D	3RV1976-0BA0 3RV1986-0BA0		1	1 unit 1 unit	41E 41E
3RV19.6-0BA0									
14000 00858	Motorized operating mechanisms	With stored energy mechanism, 220 250 V AC/DC	3RV1.6., 3RV1.7. 3RV1.83	D D	3RV1976-3AP3 3RV1986-3AP3		1	1 unit 1 unit	41E 41E
3RV19.6-3AP3									
Connections									
3RV1975-1CA0	Connections	Front-extended (1 set = 6 units)	3RV1353 3RV1.6. 3RV1.7. 3RV1.83-7J.10 3RV1.83-7KN10	D D D D	3RV1955-1AA0 3RV1965-1BA0 3RV1975-1CA0 3RV1985-1DA0 3RV1985-1EA0		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E
3RV1955-3AA0		Rear (1 set = 3 units)	3RV1353 3RV1.6. 3RV1.7. 3RV1.83	D D D	3RV1955-3AA0 3RV1965-3AA0 3RV1975-3AA0 3RV1985-3AA0		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E
3RV1955-3AA0 3RV1975-2AA0	Cable terminals	Front-extended (1 set = 6 units)	3RV1353 3RV1.6. 3RV1.7-7G.10 3RV1.73-7JN10	D D D	3RV1955-2AA0 3RV1965-2BA0 3RV1975-2CA0 3RV1975-2DA0		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E

## General data

## Overview



				ecces.			
Features	3RU21	3RU11	3RB30/3RB31	3RB20/3RB21	3RB22/3RB23	3RB24	Benefits
General data							
Sizes	S00 S2	S3	S00 S2	S3 S12	S00 S12	S00 S12	<ul> <li>Are coordinated with the dimensions, connections and technical characteristics of the other devices in the SIRIUS modular system (contactors, etc.,)</li> </ul>
							<ul> <li>Permit the mounting of slim and compact load feeders in widths of 45 mm (S00, S0), 55 mm (S2), 70 mm (S3), 120 mm (S6) and 145 mm (S10/S12); this does not include the current measuring modules for the 3RB22 to 3RB24 evaluation modules sizes S00 to S3</li> </ul>
							Simplify configuration
Seamless current range	0.11 80 A	18 100 A	0.1 80 A	12.5 630 A	0.3 630 A (up to 820 A) <sup>1)</sup>	0.3 630 A (up to 820 A) <sup>1)</sup>	<ul> <li>Allows easy and consistent configuration with one series of overload relays (for small to large loads)</li> </ul>
Protection fun	ctions						
Tripping due to overload	✓	✓	✓	✓	✓	✓	Provides optimum inverse-time delayed protection of loads against excessive temperature rises due to overload
Tripping due to phase unbalance	✓	<b>/</b>	✓	✓	1	/	<ul> <li>Provides optimum inverse-time delayed protection of loads against excessive temperature rises due to phase unbalance</li> </ul>
Tripping due to phase failure	✓	✓	✓	✓	✓	✓	Minimizes heating of three-phase motors during phase failure
Protection of single-phase loads	✓	✓			✓	✓	Enables the protection of single-phase loads
Tripping in the event of overheating by integrated	2)	2)	2)	2)	1	1	Provides optimum temperature-dependent protection of loads against excessive temperature rises e.g. for stator-critical motors or in the event of insufficient coolant flow, contamination of the motor surface or for long starting or braking operations
thermistor motor protection							Eliminates the need for additional special equipment     Source space in the central achiest.
function							Saves space in the control cabinet     Paduses wiring outloy and costs
Tripping			,	/	/	/	<ul> <li>Reduces wiring outlay and costs</li> <li>Provides optimum protection of loads</li> </ul>
in the event of a ground fault			(only 3RB31)	(only 3RB21)	•	•	against high-resistance short circuits or ground faults due to moisture, condensed water, damage to the insulation material, etc.
internal ground- fault detection							Eliminates the need for additional special equipment
(activatable)							Saves space in the control cabinet
							<ul> <li>Reduces wiring outlay and costs</li> </ul>

- ✓ Available
- -- Not available

- 1) Motor currents up to 820 A can be recorded and evaluated by a current measuring module, e.g. 3RB2906-2BG1 (0.3 to 3 A), in combination with a 3UF1868-3GA00 (820 A/1 A) series transformer.

  3UF18 transformers, see Chapter 10, "Monitoring and Control Devices" → "SIMOCODE 3UF Motor Management and Control Devices".
- 2) The SIRIUS 3RN thermistor motor protection devices can be used to provide additional temperature-dependent protection.



	AND AND WITH	00	STATE OF THE PARTY	mennen -	****	000000	
Features	3RU21	3RU11	3RB30/3RB31	3RB20/3RB21	3RB22/3RB23	3RB24	Benefits
Features							
RESET function	✓	✓	✓	✓	✓	✓	Allows manual or automatic resetting of the device
Remote RESET function	(by means of separate module)	(by means of separate module)	(only with 3RB31 and external auxiliary voltage 24 V DC)	(only with 3RB21 and external auxiliary voltage 24 V DC)	(electrically via external button)	(electrically with button or via IO-Link)	Allows the remote resetting of the device
TEST function for auxiliary contacts	✓	✓	✓	✓	✓	✓	Allows easy checking of the function and wiring
TEST function for electronics			✓	✓	✓	✓	Allows checking of the electronics
Status display	✓	✓	✓	✓	✓	✓	<ul> <li>Displays the current operating state</li> </ul>
Large current adjustment button	✓	✓	✓	✓	✓	✓	Makes it easier to set the relay exactly to the correct current value
Integrated auxiliary contacts (1 NO + 1 NC)	✓	<b>/</b>	✓	✓	<b>✓</b> (2 ×)		Allows the load to be switched off if necessary     Can be used to output signals
Integrated auxiliary contacts (1 CO and 1 NO in series)						✓	Enables the controlling of contactors directly from the higher-level control system through IO-Link
IO-Link connection						✓	<ul><li>Reduction of wiring in the control cabinet</li><li>Enables communication</li></ul>
Connection of optional hand- held device						✓	Enables local operation
Communication	on capability t	hrough IO-Li	nk				
Full starter functionality through IO-Link						✓	Enables in combination with the SIRIUS 3RT contactors the assembly of communication-capable motor starters (direct-on-line, reversing and wye-delta starting)
Reading out of diagnostics functions						✓	<ul> <li>Enables the reading out of diagnostics information such as overload, open circuit, ground fault, etc.</li> </ul>
Reading out of current values						✓	Enables the reading out of current values and their direct processing in the higher- level control system
Reading out all set parameters						✓	Enables the reading out of all set parameters, e.g. for plant documentation

- ✓ Available
- -- Not available



	14-18-71	100			***		
Features	3RU21	3RU11	3RB30/3RB31	3RB20/3RB21	3RB22/3RB23	3RB24	Benefits
Design of load	feeders						
Short-circuit strength up to 100 kA at 690 V (in conjunction with the corre- sponding fuses or the corre- sponding motor starter protector)	<b>/</b>	/	/	/	/	<b>/</b>	Provides optimum protection of the loads and operating personnel in the event of short circuits due to insulation faults or faulty switching operations
Electrical and mechanical matching to 3RT contactors	1	1	1	1	<b>√</b> <sup>1)</sup>	<b>√</b> <sup>1)</sup>	Simplifies configuration     Reduces wiring outlay and costs     Enables stand-alone installation as well as space-saving direct mounting
Straight- through trans- formers for main circuit <sup>2</sup> ) (in this case the cables are routed through the feed-through openings of the overload relay and connected directly to the box terminals of the contactor)	-		<b>(</b> S2)	(S3 S6)	(S00 S6)	(S00 S6)	<ul> <li>Reduces the contact resistance (only one point of contact)</li> <li>Saves wiring costs (easy, no need for tools, and fast)</li> <li>Saves material costs</li> <li>Reduces installation costs</li> </ul>
Spring-type connection system for main circuit <sup>2)</sup>	(S00, S0)		(S00, S0)				<ul> <li>Enables fast connections</li> <li>Permits vibration-resistant connections</li> <li>Enables maintenance-free connections</li> </ul>
Spring-type connection system for auxiliary circuits <sup>2)</sup>	✓	✓	✓	✓	✓	✓	<ul> <li>Enables fast connections</li> <li>Permits vibration-resistant connections</li> <li>Enables maintenance-free connections</li> </ul>
Ring terminal lug connection system for main and auxiliary circuits <sup>2)</sup>	(S00, S0)						<ul> <li>Enables fast connections</li> <li>Permits vibration-resistant connections</li> <li>Enables maintenance-free connections</li> </ul>
Full starter functionality through IO-Link						<b>√</b>	<ul> <li>Enables in combination with the SIRIUS 3RT contactors the assembly of communication-capable motor starters (direct-on-line, reversing and wye-delta starting)</li> </ul>
Starter function						✓	Integration of feeders via IO-Link in the control system up to 630 A or 820 A

<sup>✓</sup> Available

<sup>--</sup> Not available

<sup>1)</sup> Exception: up to size S3, only stand-alone installation is possible.2) Alternatively available for screw terminals.



	2/11 2/12 2/13	00	STOCKE !		****	000000	
Features	3RU21	3RU11	3RB30/3RB31	3RB20/3RB21	3RB22/3RB23	3RB24	Benefits
Other features	;						
Temperature compensation	/	/	,	/	,	<i>,</i>	Allows the use of the relays at high temperatures without derating Prevents premature tripping Allows compact installation of the control cabinet without distance between the devices/load feeders Simplifies configuration Enables space to be saved in the control cabinet
Very high long- term stability	✓	✓	✓	✓	✓	<b>√</b>	Provides safe protection for the loads even after years of use in severe operating conditions
Wide setting ranges			<b>✓</b> (1:4)	<b>✓</b> (1:4)	(1:10)	(1:10)	<ul> <li>Minimize the configuration outlay and costs</li> <li>Minimize storage overheads, storage costs, tied-up capital</li> </ul>
Fixed trip class	CLASS 10, CLASS 10A	CLASS 10	3RB30: CLASS 10E or CLASS 20E	3RB20: CLASS 10 or CLASS 20			Optimum motor protection for standard starts
Trip classes adjustable on the device CLASS 5E, 10E, 20E, 30E			3RB31: ✔	3RB21: ✓	,	,	Enables solutions for very fast starting motors requiring special protection (e.g. Ex motors)     Enables heavy starting solutions     Reduces the number of variants     Minimizes the configuring outlay and costs     Minimizes storage overhead, storage costs, and tied-up capital
Low power loss			/	,	/	<b>V</b>	Reduces energy consumption and energy costs (up 98 % less energy is used than for thermal overload relays)  Minimizes temperature rises of the contactor and control cabinet – in some cases this may eliminate the need for controlgear cabinet cooling  Direct mounting to contactor saves space, even for high motor currents (i.e. no heat decoupling is required)
Internal power supply	1)	1)	✓	1			Eliminates the need for configuration and connecting an additional control circuit
Supplied from an external voltage through IO-Link						✓	Eliminates the need for configuration and connecting an additional control circuit

<sup>✓</sup> Available

<sup>--</sup> Not available

SIRIUS 3RU11 and 3RU21 thermal overload relays use a bimetal contactor and therefore do not require a control supply voltage.

# General data



Features	3RU21	3RU11	3RB30/3RB31	3RB20/3RB21	3RB22/3RB23	3RB24	Benefits
Other charact	eristics (conti	inued)					
Overload warning					✓	✓	<ul> <li>Indicates imminent tripping of the relay directly on the device due to overload, phase unbalance or phase failure through flickering of the LEDs or in the case of the 3RB24 as a signal through IO-Link</li> </ul>
							• Allows the imminent tripping of the relay to be signaled
							<ul> <li>Allows measures to be taken in time in the event of inverse-time delayed overloading of the load for an extended period over the current limit</li> </ul>
							<ul> <li>Eliminates the need for an additional device</li> </ul>
							Saves space in the control cabinet
							<ul> <li>Reduces wiring outlay and costs</li> </ul>
Analog output					✓	✓	<ul> <li>Allows the output of an analog output signal for actuating moving-coil instru- ments, feeding programmable logic controllers or transfer to bus systems</li> </ul>
							Eliminates the need for an additional measuring transducer and signal converter

- ✓ Available
- -- Not available

Saves space in the control cabinetReduces wiring outlay and costs

## General data

#### Overview of overload relays - matching contactors

Overload			Contactors	(type, size, rating	in kW)					
relays		range	3RT201.	3RT202.	3RT203.	3RT104.	3RT105.	3RT106.	3RT107.	3TF68/3TF69
			S00	S0	S2	S3	S6	S10	S12	S14
Type		Α	3/4/5.5/7.5	5.5/7.5/11/15/18.5	15/18.5/22/ 30/37	30/37/45	55/75/90	110/132/160	200/250	375/450

#### 

3RU21

# SIRIUS 3RU11 thermal overload relays 3RU114 Integrated 18 ... 100 -- -- -- -- -- -- -- -- -- -- --



3RU11

SIRIUS 3RB30	) electroni	c overload	l relays <sup>1)</sup>						
	3RB301	Integrated	0.1 16	✓			 	 	
	3RB302	Integrated	0.1 40		✓		 	 	
	3RB303	Integrated	12.5 80			✓	 	 	

3RB30

SIRIUS 3RB31		Integrated		✓			 	 	
	3RB312	Integrated	0.1 40		✓		 	 	
	3RB313	Integrated	12.5 80			✓	 	 	

SIRIUS 3RB20	electronic	c overload	l relays <sup>1)</sup>						
	3RB204	Integrated	12.5 100	 	 ✓				
	3RB205	Integrated	50 200	 	 	✓			
	3RB206	Integrated	55 630	 	 		✓	✓	✓
	3RB201 + 3UF18	Integrated	630 820	 	 				✓

3RB20 SIRIUS 3RB2

21	electronic	overload	l relays <sup>1)</sup>						
	3RB214	Integrated	12.5 100	 	 ✓				
	3RB215	Integrated	50 200	 	 	✓			
ı	3RB216	Integrated	55 630	 	 		✓	✓	✓
	3RB211 +	Integrated	630 820	 	 				✓

3RB21

- ✓ Can be used
- -- Cannot be used

 "Technical specifications" for the use of overload relays with trip class ≥ CLASS 20 can be found in "Short-circuit protection with fuses for motor feeders",

see Configuration Manuals

- "SIRIUS Configuration Selection data for Fuseless Load Feeders", http://support.automation.siemens.com/WW/view/en/68115040.
- "Configuring SIRIUS Innovations Selection data for Fuseless and Fused Load Feeders",

http://support.automation.siemens.com/WW/view/en/50250599.

## General data

#### Overview of overload relays - matching contactors (continued)

Overload	Current	Current	Contactors	s (type, size, rating	in kW)					
relays	measur- ing module	range	3RT201.	3RT202.	3RT203.	3RT104.	3RT105.	3RT106.	3RT107.	3TF68/3TF69
			S00	S0	S2	S3	S6	S10	S12	S14
Type		Α	3/4/5.5/7.5	5.5/7.5/11/15/18.5	15/18.5/22/ 30/37	30/37/45	55/75/90	110/132/160	200/250	375/450

	.,,,,,		, .			00/01					
SIRIUS 3RB22	to 3RB24	electroni	c overload	relays <sup>1)</sup>							
		3RB2906	0.3 25	✓	✓						
600000	3RB2283/	3RB2906	10 100	✓	✓	✓	✓				
000000	3RB2383/		20 200		✓	✓	✓	✓			
	3RB2483+	3RB2966	63 630						✓	✓	1
3RB22, 3RB23			630 820						-		

- ✓ Can be used
- -- Cannot be used

"Technical Specifications" for the use of overload relays with trip class
 ≥ CLASS 20 can be found in "Short-circuit protection with fuses for motor feeders".

see Configuration Manuals

- "SIRIUS Configuration Selection Data for Fuseless Load Feeders", http://support.automation.siemens.com/WW/view/en/68115040
- "Configuring SIRIUS Innovations Selection Data for Fuseless and Fused Load Feeders",
- http://support.automation.siemens.com/WW/view/en/50250599.

#### **General data**

#### Connection methods

## 3RU2 thermal overload relays

- Sizes S00 and S0:
  - Main and auxiliary circuit: Either screw terminals, spring-type terminals or ring terminal lug connections
- Size S2
  - Main circuit: Screw terminals with box terminal
  - Auxiliary circuit: Either screw or spring-type terminals

#### 3RU1 thermal overload relays

- Size S3:
  - Main circuit: Screw terminals
  - Auxiliary circuit: Either screw or spring-type terminals

#### 3RB3 electronic overload relays

- Sizes S00 and S0:
  - Main and auxiliary circuit: Either screw or spring-type terminals
- Size S2:
  - Main circuit: Screw terminals with box terminal or as straight-through transformer
  - Auxiliary circuit: Either screw or spring-type terminals

#### 3RB2 electronic overload relays

3RB20 and 3RB21 overload relays:

- Size S3:
  - Main circuit: Screw terminals with box terminal or as straight-through transformer
  - Auxiliary circuit: Either screw or spring-type terminals
- Size S6:
  - Main circuit: With busbar connection or as straight-through transformer
  - Auxiliary circuit: Either screw or spring-type terminals
- Sizes S10/S12:
  - Main circuit: With busbar connection
  - Auxiliary circuit: Either screw or spring-type terminals

#### 3RB22 to 3RB24 evaluation modules:

• Screw or spring-type terminals

## 3RB29 current measuring modules:


- Up to size S3: Straight-through transformers
- As from size S6:
  - Main circuit: With busbar connection
  - Auxiliary circuit: Either screw or spring-type terminals

- Screw terminals
- Spring-type terminals
- Ring terminal lug connections
- Busbar connections
- Straight-through transformers

The various terminals and straight-through transformers are indicated in the corresponding tables by the symbols shown on orange backgrounds.

3RU2 up to 80 A for standard applications

#### Overview



- 1 Switch position indicator and TEST function of the wiring: Indicates a trip and enables the wiring test.
- Motor current setting: Setting the device to the rated motor current is easy with the large rotary knob.
- Connecting terminals:
   Depending on the device version, the connecting terminals for screw, spring-type or ring terminal lug connection are configured for the main and auxiliary circuit.
- (4) STOP button: If the STOP button is pressed, the NC contact is opened. This switches off the contactor downstream. The NC contact is closed again when the button is released.
- (5) Selector switch for manual/automatic RESET and RESET button: With this switch you can choose between manual and automatic RESET. A device set to manual RESET can be reset locally by pressing the RESET button. A remote RESET is possible using the RESET modules (accessories), which are independent of size.
- (6) Connection for mounting onto contactors: Optimally adapted in electrical, mechanical and design terms to the contactors. The overload relay can be connected directly to the contactor using these pins. Stand-alone installation is possible as an alternative (in conjunction with a terminal bracket for stand-alone installation).

A sealable transparent cover can be optionally mounted (accessory). It secures the motor current setting against adjustment.

The 3RU21 thermal overload relays up to 80 A have been designed for inverse-time delayed protection of loads with normal starting (for "Function", see manual "SIRIUS Innovations – SIRIUS 3RU2/3RB3 Overload Relays", http://support.automation.siemens.com/WW/view/en/60298164) against excessive temperature rises due to overload or phase failure.

An overload or phase failure results in an increase of the motor current beyond the set rated motor current. Via heating elements, this current rise heats up the bimetal strips inside the device which then bend and as a result trigger the auxiliary contacts by means of a tripping mechanism. The auxiliary contacts then switch off the load by means of a contactor. The break time depends on the ratio between the tripping current and current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Curves" http://support.automation.siemens.com/WW/view/en/34291410/134300).

The "tripped" status is signaled by means of a switch position indicator. Resetting takes place either manually or automatically after a recovery time has elapsed (for "Function", see manual "SIRIUS Innovations – SIRIUS 3RU2/3RB3 Overload Relays", http://support.automation.siemens.com/WW/view/en/60298164).

The 3RU2 thermal overload relays are suitable for operation with frequency converters. Please follow the instructions in the manual "SIRIUS Innovations – 3RU2/3RB3 Overload Relays", see http://support.automation.siemens.com/WW/view/en/60298164.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

3RU11 overload relays for currents over 80 A in size S3, see page 7/111 onwards.

#### Use in hazardous areas

The 3RU21 thermal overload relays are suitable for the protection of motors with "Flameproof enclosure d" or "Increased safety e" types of protection.

EC type test certificate for Category (2) G/D exists. It has the number DMT 98 ATEX G001.

SIRIUS 3RU2136-4.B0 thermal overload relay

#### Article No. scheme

Digit of the Article No.	1st - 3rd	4th	5th	6th	7th		8th	9th	10th	11th
						_				
Thermal overload relays	3 R U									
SIRIUS 2nd generation		2								
Device series										
Size, rated operational current and power										
Setting range of the overload release										
Connection methods										
Installation type										
Example	3 R U	2	1	1	6	_	0	Α	В	0

#### Note:

The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

## 3RU2 up to 80 A for standard applications

#### Benefits

The most important features and benefits of the 3RU21 thermal overload relays are listed in the overview table (see "General Data", page 7/87 onwards).

#### Application

#### Industries

The 3RU21 thermal overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed protection of their electrical loads (e.g. motors) under normal starting conditions (CLASS 10, 10A).

#### Application

The 3RU21 thermal overload relays have been designed for the protection of three-phase and single-phase AC and DC motors.

#### Note:

For the use of 3RU21 thermal overload relays in conjunction with highly energy-efficient IE3 motors, please read the information on dimensioning and configuration,

see "Configuration Manual for SIRIUS Controls with IE3 Motors", http://support.automation.siemens.com/WW/view/en/94770820

More information, see page 3.

If single-phase AC or DC loads are to be protected by the 3RU21 thermal overload relays, all three bimetal strips must be heated. For this purpose, all main current paths of the relay must be connected in series.

#### Ambient conditions

The 3RU21 thermal overload relays have temperature compensation according to IEC 60947-4-1 for the temperature range of -40 to +60 °C. For temperatures from +60 to +70 °C, the upper set value of the setting range must be reduced by the factor listed in the table below.

#### Technical specifications

The following technical information is intended to provide an initial overview of the various types of device and functions.

Detailed information, see

- Manual "SIRIUS Innovations SIRIUS 3RU2/3RB3 Overload Relavs".
- http://support.automation.siemens.com/WW/view/en/60298164
- or specific information on a particular article number via the product data sheet,

http://support.automation.siemens.com/WW/view/en/34291410/133200

				,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
Туре		3RU2116	3RU2126	3RU2136
Sizef 🔟 📗		S00	S0	S2
Dimensions (W x H x D) (overload relay with stand-alone installation support)		45 00 00	45 07 05	55 405 447
Screw terminals     Spring-type terminals	mm mm	45 x 89 x 80 45 x 102 x 79	45 x 97 x 95 45 x 114 x 95	55 x 105 x 117 55 x 105 x 117
General data				
Trips in the event of		Overload and phase failure	е	
Trip class acc. to IEC 60947-4-1	Class	10		10, 10A
Phase failure sensitivity		Yes		
Overload warning		No		
Reset and recovery				
Reset options after tripping		Manual, Automatic and Re (Remote RESET in combin	mote RESET ation with the corresponding	g accessories)
<ul> <li>Recovery time</li> <li>For automatic RESET</li> <li>For manual RESET</li> <li>For remote RESET</li> </ul>	min. min. min.	Depends on the strength of	of the tripping current and cl of the tripping current and cl of the tripping current and cl	naracteristic
Features				
Display of operating state on device		Yes, by means of TEST fun	action/switch position indica	tor slide
TEST function		Yes		
RESET button		Yes		
STOP button		Yes		
Protection and operation of motors with "Increased safety e" and "Flameproof enclosure d" types of protection				
EC type test certificate number according to directive 94/9/EC (ATEX)		DMT 98 ATEX G 001 ( II see http://support.automation.sieme	(2) GD ens.com/WW/view/en/47205444	On request

# 3RU2 up to 80 A for standard applications

T		0DU0446	ODUI040C	00110400
Туре		3RU2116	3RU2126	3RU2136
Size 1		S00	S0	S2
Dimensions (W x H x D) (overload relay with stand-alone installation				
support)				
<ul><li>Screw terminals</li><li>Spring-type terminals</li></ul>	mm mm	45 x 89 x 80 45 x 102 x 79	45 x 97 x 95 45 x 114 x 95	55 x 105 x 117 55 x 105 x 117
General data (continued)				
Ambient temperature				
Storage/transport	°C	-55 +80		
Operation	°C	-40 +70		
Temperature compensation	°C	Up to +60		
Permissible rated current at				
- Temperature inside control cabinet 60 °C	%	100 (over +60 °C current r	reduction is not required)	
- Temperature inside control cabinet 70 °C	%	87		
Repeat terminals				
Coil repeat terminals		Yes	Not required	
Auxiliary contact repeat terminal		Yes	Not required	
Degree of protection acc. to IEC 60529		IP20		
Touch protection acc. to IEC 61140		F: ( /		
Screw terminals and spring-type terminals		Finger-safe for vertical cor		
Ring terminal lug connections	-	Finger-safe only with optio		
Shock resistance with sine acc. to IEC 60068-2-27	<i>g</i> /ms	15/11 (auxiliary contacts 9	95/96 and 97/98: 8 <i>g</i> /11 ms)	
Electromagnetic compatibility (EMC)		NI I I		
Interference immunity     Facility of interference immunity		Not relevant		
Emitted interference	0/	Not relevant		
Resistance to extreme climates – air humidity	%	90		
Dimensions		<ul><li>http://support.automation</li><li>Product data sheet,</li></ul>	ee ons – SIRIUS 3RU2/3RB3 C n.siemens.com/WW/view/er emens.com/WW/view/en/34291	n/60298164
Installation altitude above sea level	m	Up to 2 000; above this or	request	
Mounting position		The diagrams show the percontactors and stand-alon area, a setting correction of	ermissible mounting position to installation. For mounting of 10 % must be implemented.	position in the hatched
		Stand-alone installation:		
		0° I <sub>e</sub> X	45° 0° 45° 1,1	
			90° NSB0_01364	
		<i>I</i> <sub>e</sub> x 1,1		
		Contactor + overload relay	,	
		0° 22,5°	0° ~ <del>~~ ~~</del> 22,5°	
			\ <del>  \                                 </del>	
		( - 5		
		135° 135°	NSB0 01363a	
		I <sub>e</sub> x 1,1		
Type of mounting			stand-alone installation with nounting onto TH 35 standar	
		Technical specifications of	f the terminal supports, see	manual
			US 3RU2/3RB3 Overload Rosiemens.com/WW/view/en/6	
		p.//odpport.adiomation.	3.30110.00111/ <b>VV VV</b> / V10VV/611/0	33230101.)

# SIRIUS 3RU2 Thermal Overload Relays

# 3RU2 up to 80 A for standard applications

Туре		3RU2116	3RU2126	3RU2136
Size		S00	SO	S2
Main circuit				
Rated insulation voltage U <sub>i</sub>	V	690		
(pollution degree 3)				
Rated impulse withstand voltage $U_{\rm imp}$	kV	6		
Rated operational voltage U <sub>e</sub>	V	690		
Type of current				
Direct current		Yes		
Alternating current		Yes, frequency range up		
Current setting	Α	0.11 0.16	1.8 2.5	11 16
	Α	up to 11 16	up to 34 40	up to 70 80
Power loss per unit (max.)	W	4.1 6.3	6.2 7.5	8 14
Short-circuit protection				
With fuse without contactor		See "Selection and orderi	ing data" on pages 7/100 7/	/102
With fuse and contactor			vith Fuses/Motor Starter Prote	
		see Configuration Manua	I "Configuring SIRIUS Innovati	
		Fuseless and Fused Load	d Feeders" siemens.com/WW/view/en/50	0250500
Protective separation between main and auxiliary current		http://support.automation		JE00000.
paths				
acc. to IEC 60947-1				
<ul> <li>Screw terminals or ring terminal lug connections</li> </ul>	V	440	690: Setting ranges ≤ 25 A	690
Spring-type terminals	V	440	440: Setting ranges > 25 A	690
Conductor cross-sections of main circuit				
Connection type		Screw terminals		
Terminal screw		M3, Pozidriv size 2	M4, Pozidriv size 2	M6, Pozidriv size 2
Operating devices	mm	Ø 5 6	Ø 5 6	Ø 5 6
Prescribed tightening torque	Nm	0.8 1.2	2 2.5	3 4.5
Conductor cross-sections (min./max.),	1 4111	0.0 1.2	Z Z.0	0 1.0
1 or 2 conductors can be connected				
Solid or stranded	$mm^2$	2 x (0.5 1.5) <sup>1)</sup> ,	2 x (1 2.5) <sup>1)</sup> ,	2 x (2.5 35) <sup>1)</sup> , 1 x (2.5 50) <sup>1)</sup>
		2 x (0.75 2.5) <sup>1)</sup> , max. 2 x 4	2 x (2.5 10) <sup>1</sup> )	1 x (2.5 50) <sup>1)</sup>
• Finally atranded with and classys (DIN 46229 1)	mm <sup>2</sup>	2 x (0.5 1.5) <sup>1)</sup> ,	2 x (1 2.5) <sup>1)</sup>	2 x (1 25) <sup>1)</sup>
Finely stranded with end sleeve (DIN 46228-1)	111111	2 x (0.75 2.5) <sup>1</sup> )	2 x (1 2.5) <sup>7</sup> , 2 x (2.5 6) <sup>1)</sup> ;	1 x (1 35) <sup>1)</sup>
		(3 3 7	max. 1 x 10	(,
<ul> <li>AWG cables, solid or stranded</li> </ul>	AWG	2 x (20 16) <sup>1)</sup> ,	2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup>	2 x (18 2) <sup>1)</sup> , 1 x (18 1) <sup>1)</sup>
		2 x (18 14) <sup>1)</sup> , 2 x 12	2 x (14 8) <sup>1</sup> /	1 x (18 1) ''
Connection type		○ Spring-type termin	nals	
Operating devices	mm	3.0 x 0.5 and 3.5 x 0.5		
Conductor cross-sections (min./max.), 1 conductor can be connected				
Solid or stranded	mm <sup>2</sup>	1 x (0.5 4)	1 x (1 10)	
	mm <sup>2</sup>	1 x (0.5 4)	· · · · · · · · · · · · · · · · · · ·	
Finely stranded with and alegae (DIN 46338.1)	mm <sup>2</sup>		1 x (1 6)	
Finely stranded with end sleeve (DIN 46228-1)      AWC applies political stranded		1 x (0.5 2.5)	1 x (1 6)	
AWG cables, solid or stranded	AWG	1 x (20 12)	1 x (18 8)	
Connection type		Ring terminal lug	connections	
Terminal screw		M3, Pozidriv size 2	M4, Pozidriv size 2	
Operating devices	mm	Ø 5 6	Ø 5 6	
Prescribed tightening torque	Nm	0.8 1.2	2 2.5	
Usable ring terminal lugs  →d <sub>3</sub> →	mm	$d_2 = min. 3.2,$	$d_2 = min. 4.3,$	
DIN 46234 without insulation sleeve		$d_3 = \text{max. } 7.5$	$d_3 = \text{max. } 12.2$	
DIN 46225 without insulation sleeve				
DIN 46237 with insulation sleeve				
• JIS C2805 Type R without insulation				
• JIS C2805 Type RAV with insulation sleeve				
• JIS C2805 Type RAP with insulation sleeve				
1)				

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

# 3RU2 up to 80 A for standard applications

Туре		3RU2116	3RU2126	3RU2136
Size		S00	S0	S2
Auxiliary circuit				
Number of NO contacts		1		
Number of NC contacts		1		
Auxiliary contacts – assignment		1 NO for the signal "tripp	ed"; 1 NC for disconnecting	ig the contactor
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	690		
Rated impulse withstand voltage $U_{\rm imp}$	kV	6		
Contact rating of the auxiliary contacts				
• NC, NO contact with alternating current AC-15, rated operational current $I_{\rm e}$ at $U_{\rm e}$ :				
- 24 V - 120 V	A A	3		
- 125 V	A	3		
- 230 V	Α	2		
- 400 V - 600 V	A A	1 0.75		
- 690 V	A	0.75		
• NC contact, NO contact with direct current DC-13, rated operational				
current $I_{ m e}$ at $U_{ m e}$ :				
- 24 V - 110 V	A A	1 0.22		
- 125 V	A	0.22		
- 220 V	Α	0.11		
Contact reliability (suitability for PLC control; 17 V, 5 mA)		Yes		
Short-circuit protection				
With fuse     Operational class gG	Α	6		
- Quick	A	10		
With miniature circuit breaker (C characteristic)	Α	6 (up to $I_k \le 0.5 \text{ kA}$ ; $U \le 2$	260 V)	
Reliable operational voltage for protective separation between	V	440	·	
auxiliary current paths acc. to IEC 60947-1				
CSA, UL, UR rated data				
Auxiliary circuit – switching capacity		B600, R300		
Conductor cross-sections for auxiliary circuit				
Connection type		Screw terminals		
		Screw terminals  M3, Pozidriv size 2		
Connection type	mm	₩		
Connection type  Terminal screw  Operating devices  Prescribed tightening torque	mm Nm	M3, Pozidriv size 2		
Connection type  Terminal screw  Operating devices  Prescribed tightening torque  Conductor cross-sections (min./max.),		M3, Pozidriv size 2 Ø 5 6		
Connection type  Terminal screw  Operating devices  Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected	Nm	M3, Pozidriv size 2 Ø 5 6 0.8 1.2	5 25(1)	
Connection type  Terminal screw  Operating devices  Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  • Solid or stranded	Nm	M3, Pozidriv size 2 Ø 5 6 0.8 1.2 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7	· · · · · · · · · · · · · · · · · · ·	
Connection type  Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1)	Nm mm <sup>2</sup> mm <sup>2</sup>	M3, Pozidriv size 2 Ø 5 6 0.8 1.2 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7	5 2.5) <sup>1)</sup>	
Connection type  Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded	Nm	M3, Pozidriv size 2 Ø 5 6 0.8 1.2 2 × (0.5 1.5) <sup>1)</sup> , 2 × (0.7 2 × (0.5 1.5) <sup>1)</sup> , 2 × (0.7 2 × (20 16) <sup>1)</sup> , 2 × (18	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup>	
Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type	mm <sup>2</sup> mm <sup>2</sup> AWG	M3, Pozidriv size 2 Ø 5 6 0.8 1.2 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18 Spring-type termin	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup>	
Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type Operating devices	Nm mm <sup>2</sup> mm <sup>2</sup>	M3, Pozidriv size 2 Ø 5 6 0.8 1.2 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18 Spring-type terming	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup>	
Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type	mm <sup>2</sup> mm <sup>2</sup> AWG	M3, Pozidriv size 2 Ø 5 6 0.8 1.2 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18 Spring-type termin	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup>	
Connection type  Terminal screw  Operating devices  Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  • Solid or stranded  • Finely stranded with end sleeve (DIN 46228-1)  • AWG cables, solid or stranded  Connection type  Operating devices  Conductor cross-sections (min./max.),	Nm  mm² mm² AWG	M3, Pozidriv size 2 Ø 5 6 0.8 1.2 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18  Spring-type terminals  3.0 x 0.5 and 3.5 x 0.5	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup>	
Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type Operating devices Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded	Mm  mm² mm² AWG  mm  mm²	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7  2 x (0.5 1.6) <sup>1)</sup> , 2 x (18  Spring-type terming  3.0 x 0.5 and 3.5 x 0.5	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup>	
Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type Operating devices Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded without end sleeve	mm² mm² AWG	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18  Spring-type terming 3.0 x 0.5 and 3.5 x 0.5  2 x (0.5 2.5) 2 x (0.5 2.5)	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup>	
Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type Operating devices Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded	mm² mm² AWG	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18  Spring-type terming 3.0 x 0.5 and 3.5 x 0.5  2 x (0.5 2.5) 2 x (0.5 2.5) 2 x (0.5 1.5)	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup>	
Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type Operating devices Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded without end sleeve • Finely stranded with end sleeve (DIN 46228-1)	mm² mm² AWG	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18  Spring-type termin  3.0 x 0.5 and 3.5 x 0.5  2 x (0.5 2.5) 2 x (0.5 2.5) 2 x (0.5 1.5) 2 x (0.5 1.5) 2 x (20 14)	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup> nals	
Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type Operating devices Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded without end sleeve • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type	mm² mm² AWG	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 × (0.5 1.5) <sup>1)</sup> , 2 × (0.7 2 × (0.5 1.5) <sup>1)</sup> , 2 × (0.7 2 × (20 16) <sup>1)</sup> , 2 × (18  Spring-type termin  3.0 × 0.5 and 3.5 × 0.5  2 × (0.5 2.5) 2 × (0.5 2.5) 2 × (0.5 1.5) 2 × (20 14)  Ring terminal lug	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup> nals	
Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type Operating devices Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded without end sleeve • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type Terminal screw	mm² mm² AWG mm mm² mm² AWG	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18  Spring-type termin  3.0 x 0.5 and 3.5 x 0.5  2 x (0.5 2.5) 2 x (0.5 2.5) 2 x (0.5 1.5) 2 x (20 14)  Ring terminal lug  M3, Pozidriv size 2	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup> nals	
Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type Operating devices Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded without end sleeve • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type Terminal screw Operating devices	mm² mm² AWG mm mm² mm² AWG	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 × (0.5 1.5) <sup>1)</sup> , 2 × (0.7 2 × (0.5 1.5) <sup>1)</sup> , 2 × (0.7 2 × (20 16) <sup>1)</sup> , 2 × (18  Spring-type termin  3.0 × 0.5 and 3.5 × 0.5  2 × (0.5 2.5) 2 × (0.5 2.5) 2 × (0.5 1.5) 2 × (20 14)  Ring terminal lug  M3, Pozidriv size 2  Ø 5 6	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup> nals	
Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type  Operating devices Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded without end sleeve • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type  Terminal screw Operating devices Prescribed tightening torque	mm² mm² AWG mm mm² mm² AWG	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18  Spring-type terming 3.0 x 0.5 and 3.5 x 0.5  2 x (0.5 2.5) 2 x (0.5 2.5) 2 x (0.5 1.5) 2 x (20 14)  Ring terminal lug  M3, Pozidriv size 2  Ø 5 6  0.8 1.2	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup> nals	
Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type Operating devices Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded without end sleeve • Finely stranded without end sleeve • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type  Terminal screw Operating devices Prescribed tightening torque Usable ring terminal lugs	mm² mm² AWG mm mm² mm² AWG	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18  Spring-type termin  3.0 x 0.5 and 3.5 x 0.5  2 x (0.5 2.5) 2 x (0.5 2.5) 2 x (0.5 1.5) 2 x (20 14)  Ring terminal lug  M3, Pozidriv size 2  Ø 5 6  0.8 1.2 d <sub>2</sub> = min. 3.2,	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup> nals	
Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type  Operating devices Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded without end sleeve • Finely stranded without end sleeve • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type  Terminal screw Operating devices Prescribed tightening torque Usable ring terminal lugs • DIN 46234 without insulation sleeve	mm² mm² AWG mm mm² mm² AWG	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18  Spring-type terming 3.0 x 0.5 and 3.5 x 0.5  2 x (0.5 2.5) 2 x (0.5 2.5) 2 x (0.5 1.5) 2 x (20 14)  Ring terminal lug  M3, Pozidriv size 2  Ø 5 6  0.8 1.2	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup> nals	
Terminal screw  Operating devices  Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  • Solid or stranded  • Finely stranded with end sleeve (DIN 46228-1)  • AWG cables, solid or stranded  Connection type  Operating devices  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  • Solid or stranded  • Finely stranded without end sleeve  • Finely stranded without end sleeve  • Finely stranded with end sleeve (DIN 46228-1)  • AWG cables, solid or stranded  Connection type  Terminal screw  Operating devices  Prescribed tightening torque  Usable ring terminal lugs  • DIN 46234 without insulation sleeve  • DIN 46225 without insulation sleeve	mm² mm² AWG mm mm² mm² AWG	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18  Spring-type termin  3.0 x 0.5 and 3.5 x 0.5  2 x (0.5 2.5) 2 x (0.5 2.5) 2 x (0.5 1.5) 2 x (20 14)  Ring terminal lug  M3, Pozidriv size 2  Ø 5 6  0.8 1.2 d <sub>2</sub> = min. 3.2,	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup> nals	
Terminal screw  Operating devices  Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  • Solid or stranded  • Finely stranded with end sleeve (DIN 46228-1)  • AWG cables, solid or stranded  Connection type  Operating devices  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  • Solid or stranded  • Finely stranded without end sleeve  • Finely stranded with end sleeve (DIN 46228-1)  • AWG cables, solid or stranded  Connection type  Terminal screw  Operating devices  Prescribed tightening torque  Usable ring terminal lugs  • DIN 46234 without insulation sleeve  • DIN 46237 with insulation sleeve  • DIN 46237 with insulation sleeve	mm² mm² AWG mm mm² mm² AWG	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18  Spring-type termin  3.0 x 0.5 and 3.5 x 0.5  2 x (0.5 2.5) 2 x (0.5 2.5) 2 x (0.5 1.5) 2 x (20 14)  Ring terminal lug  M3, Pozidriv size 2  Ø 5 6  0.8 1.2 d <sub>2</sub> = min. 3.2,	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup> nals	
Terminal screw  Operating devices  Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  • Solid or stranded  • Finely stranded with end sleeve (DIN 46228-1)  • AWG cables, solid or stranded  Connection type  Operating devices  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  • Solid or stranded  • Finely stranded without end sleeve  • Finely stranded with end sleeve (DIN 46228-1)  • AWG cables, solid or stranded  Connection type  Terminal screw  Operating devices  Prescribed tightening torque  Usable ring terminal lugs  • DIN 46234 without insulation sleeve  • DIN 46237 with insulation sleeve  • JIS C2805 Type R without insulation sleeve	mm² mm² AWG mm mm² mm² AWG	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18  Spring-type termin  3.0 x 0.5 and 3.5 x 0.5  2 x (0.5 2.5) 2 x (0.5 2.5) 2 x (0.5 1.5) 2 x (20 14)  Ring terminal lug  M3, Pozidriv size 2  Ø 5 6  0.8 1.2 d <sub>2</sub> = min. 3.2,	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup> nals	
Terminal screw  Operating devices  Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  • Solid or stranded  • Finely stranded with end sleeve (DIN 46228-1)  • AWG cables, solid or stranded  Connection type  Operating devices  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  • Solid or stranded  • Finely stranded without end sleeve  • Finely stranded with end sleeve (DIN 46228-1)  • AWG cables, solid or stranded  Connection type  Terminal screw  Operating devices  Prescribed tightening torque  Usable ring terminal lugs  • DIN 46234 without insulation sleeve  • DIN 46237 with insulation sleeve  • JIS C2805 Type R without insulation sleeve	mm² mm² AWG mm mm² mm² AWG	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18  Spring-type termin  3.0 x 0.5 and 3.5 x 0.5  2 x (0.5 2.5) 2 x (0.5 2.5) 2 x (0.5 1.5) 2 x (20 14)  Ring terminal lug  M3, Pozidriv size 2  Ø 5 6  0.8 1.2 d <sub>2</sub> = min. 3.2,	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup> nals	
Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type  Operating devices Conductor cross-sections (min./max.), 1 or 2 conductors can be connected • Solid or stranded • Finely stranded without end sleeve • Finely stranded with end sleeve (DIN 46228-1) • AWG cables, solid or stranded Connection type  Terminal screw Operating devices Prescribed tightening torque Usable ring terminal lugs • DIN 46234 without insulation sleeve • DIN 46237 with insulation sleeve • JIS C2805 Type R without insulation	mm² mm² AWG mm mm² mm² AWG	M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.7 2 x (20 16) <sup>1)</sup> , 2 x (18  Spring-type termin  3.0 x 0.5 and 3.5 x 0.5  2 x (0.5 2.5) 2 x (0.5 2.5) 2 x (0.5 1.5) 2 x (20 14)  Ring terminal lug  M3, Pozidriv size 2  Ø 5 6  0.8 1.2 d <sub>2</sub> = min. 3.2,	5 2.5) <sup>1)</sup> . 14) <sup>1)</sup> nals	

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## SIRIUS 3RU2 Thermal Overload Relays

## 3RU2 up to 80 A for standard applications


#### Selection and ordering data

## 3RU21 thermal overload relays for mounting onto contactor<sup>1)</sup>, sizes S00 and S0, CLASS 10

Features and technical specifications:

- Connection method Main and auxiliary circuit: Either screw terminals, spring-type terminals or ring terminal lug connections<sup>27</sup>
- Overload and phase failure protection
- Auxiliary contacts 1 NO + 1 NC
- Manual and automatic RESET
- · Switch position indicator

- TEST function
- STOP button
- Sealable covers (optional accessory)
- Terminal covers for devices with ring terminal lug connection (optional accessory)











3RU2116-4AB0

3RU2116-4AC0

3RU2126-4FB0

3RU2126-4AC0

Size contactor	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>3)</sup>	DT	Screw terminals	4	DT	Spring-type terminals	
	Class	А	А		Article No.	Price per PU		Article No.	Price per PU
Size S0	0								
S00	10 10 10 10 10 10 10 10	0.11 0.16 0.14 0.2 0.18 0.25 0.22 0.32 0.28 0.4 0.35 0.5 0.45 0.63	0.5 1 1 1.6 2 2	<b>* * * * *</b>	3RU2116-0AB0 3RU2116-0BB0 3RU2116-0CB0 3RU2116-0DB0 3RU2116-0BB0 3RU2116-0FB0 3RU2116-0GB0		B B B B B B B	3RU2116-0AC0 3RU2116-0BC0 3RU2116-0C0 3RU2116-0DC0 3RU2116-0EC0 3RU2116-0FC0 3RU2116-0GC0	
	10 10 10 10 10	0.55 0.8 0.7 1 0.9 1.25 1.1 1.6 1.4 2	4 4 4 6 6	<b>*</b>	3RU2116-0HB0 3RU2116-0JB0 3RU2116-0KB0 3RU2116-1AB0 3RU2116-1BB0		B B B B	3RU2116-0HC0 3RU2116-0JC0 3RU2116-0KC0 3RU2116-1AC0 3RU2116-1BC0	
	10 10 10 10	1.8 2.5 2.2 3.2 2.8 4 3.5 5	10 10 16 20	* * * *	3RU2116-1CB0 3RU2116-1DB0 3RU2116-1EB0 3RU2116-1FB0		B B B	3RU2116-1CC0 3RU2116-1DC0 3RU2116-1EC0 3RU2116-1FC0	
	10 10 10 10	4.5 6.3 5.5 8 7 10 9 12.5	20 25 35 35	<b>* * *</b>	3RU2116-1GB0 3RU2116-1HB0 3RU2116-1JB0 3RU2116-1KB0		B B B	3RU2116-1GC0 3RU2116-1HC0 3RU2116-1JC0 3RU2116-1KC0	
01 00	10	11 16	40	<u> </u>	3RU2116-4AB0		В	3RU2116-4AC0	
Size S0	10 10 10 10	1.8 2.5 2.2 3.2 2.8 4 3.5 5	10 10 16 20	<b>&gt;</b>	3RU2126-1CB0 3RU2126-1DB0 3RU2126-1EB0 3RU2126-1FB0		B B B	3RU2126-1CC0 3RU2126-1DC0 3RU2126-1EC0 3RU2126-1FC0	
	10 10 10 10	4.5 6.3 5.5 8 7 10 9 12.5	20 25 35 35	* * *	3RU2126-1GB0 3RU2126-1HB0 3RU2126-1JB0 3RU2126-1KB0		B B B	3RU2126-1GC0 3RU2126-1HC0 3RU2126-1JC0 3RU2126-1KC0	
	10 10 10 10	11 16 14 20 17 22 20 25	40 50 63 63	<b>* * *</b>	3RU2126-4AB0 3RU2126-4BB0 3RU2126-4CB0 3RU2126-4DB0		<b>A A A</b>	3RU2126-4AC0 3RU2126-4BC0 3RU2126-4CC0 3RU2126-4DC0	
	10 10 10 10	23 28 27 32 30 36 34 40	63 80 80 80	<b>A</b>	3RU2126-4NB0 3RU2126-4EB0 3RU2126-4PB0 3RU2126-4FB0		<b>A A A</b>	3RU2126-4NC0 3RU2126-4EC0 3RU2126-4PC0 3RU2126-4FC0	

With the suitable terminal supports (see "Accessories", page 7/103), the 3RU2 overload relays for mounting on contactors can also be installed as stand-alone units.

Overload relays in size S2, see page 7/101.

<sup>&</sup>lt;sup>2)</sup> When ordering the ring terminal lug version, the Article No. must be changed in the 10th digit to "J": e.g. 3RU2116-0AJ0.

<sup>3)</sup> Maximum protection by fuse only for overload relay, type of coordination "2". Fuse values in connection with contactors, see Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders' http://support.automation.siemens.com/WW/view/en/50250599.

## **Overload Relays** SIRIUS 3RU2 Thermal Overload Relays

## 3RU2 up to 80 A for standard applications

## 3RU21 thermal overload relays for mounting onto contactor<sup>1)</sup>, size S2, CLASS 10

Features and technical specifications:

- Connection methods
  - Main circuit: Screw terminals with box terminal
  - Auxiliary circuit: Either screw or spring-type terminals
- Overload and phase failure protection
- Auxiliary contacts 1 NO + 1 NC
- Manual and automatic RESET

- Switch position indicator
- TEST function
- STOP button
- Sealable covers (optional accessory)

PU(UNIT, SET, M) = 1PS\* PG = 1 unit = 41F





Trip class

3RU2136-4.D0

Size contactor	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>2)</sup>	DT	Screw terminals	<b>+</b>	DT	Spring-type terminals (on auxiliary current side)	8
	Class	A	A		Article No.	Price per PU		Article No.	Price per PU
Size S2									
S2	10 10 10 10	11 16 14 20 18 25 22 32	50 N 63 N	EW > EW > EW >	3RU2136-4AB0 3RU2136-4BB0 3RU2136-4DB0 3RU2136-4EB0		X X X	3RU2136-4AD0 3RU2136-4BD0 3RU2136-4DD0 3RU2136-4ED0	
	10 10 10 10 10	28 40 36 45 40 50 47 57 54 65	100 N 100 N 100 N	EW > EW > EW > EW >	3RU2136-4FB0 3RU2136-4GB0 3RU2136-4HB0 3RU2136-4QB0 3RU2136-4JB0		X X X X	3RU2136-4FD0 3RU2136-4GD0 3RU2136-4HD0 3RU2136-4QD0 3RU2136-4JD0	
	10A 10A	62 73 70 80		EW ► EW ►	3RU2136-4KB0 3RU2136-4RB0		X X	3RU2136-4KD0 3RU2136-4RD0	

coordination "2". Fuse values in connection with contactors, see

Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders", http://support.automation.siemens.com/WW/view/en/50250599.

<sup>70 ... 80</sup> With the suitable terminal supports (see "Accessories", page 7/103), the 3RU2 overload relays for mounting on contactors can also be installed as stand-alone units.

<sup>2)</sup> Maximum protection by fuse only for overload relay, type of

## SIRIUS 3RU2 Thermal Overload Relays

## 3RU2 up to 80 A for standard applications

#### 3RU21 thermal overload relays for stand-alone installation, sizes S00 to S2, CLASS 10

Features and technical specifications:

- Connection methods
- Sizes S00 and S0:
  - Main and auxiliary circuit: Either screw or spring-type terminals
- Size S2:
- Main circuit: Screw terminals with box terminal, main circuit: Either screw or spring-type terminals
- Auxiliary contacts 1 NO + 1 NC
- Manual and automatic RESET

- Switch position indicator
- TEST function
- STOP button
- Sealable covers (optional accessory)

PU(UNIT, SET, M) = 1PS\* = 1 unit PG = 41F



3RU2116-4AC1



3RU2136-4.B1



3RU2126-4FB1



3RU2126-4FC1



3RU2136-4.D1

Size contactor	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>2)</sup>	DT	Screw terminals	<b>+</b>	Spring-type terminals	
	Class	A	A		Article No.	Price per PU	Article No.	Price per PU
Size S00								
S00	10 10 10 10	0.11 0.16 0.14 0.2 0.18 0.25 0.22 0.32	0.5 1 1 1.6	B B B	3RU2116-0AB1 3RU2116-0BB1 3RU2116-0CB1 3RU2116-0DB1	B B B	3RU2116-0BC1 3RU2116-0CC1	
	10 10 10 10	0.28 0.4 0.35 0.5 0.45 0.63 0.55 0.8	2 2 2 4	B B B	3RU2116-0EB1 3RU2116-0FB1 3RU2116-0GB1 3RU2116-0HB1	B B B	3RU2116-0FC1 3RU2116-0GC1	
	10 10 10 10	0.7 1 0.9 1.25 1.1 1.6 1.4 2	4 4 6 6	B B B	3RU2116-0JB1 3RU2116-0KB1 3RU2116-1AB1 3RU2116-1BB1	B B B B	3RU2116-0KC1 3RU2116-1AC1	
	10 10 10 10	1.8 2.5 2.2 3.2 2.8 4 3.5 5	10 10 16 20	B B B	3RU2116-1CB1 3RU2116-1DB1 3RU2116-1EB1 3RU2116-1FB1	B B B B	3RU2116-1DC1 3RU2116-1EC1	
	10 10 10 10	4.5 6.3 5.5 8 7 10 9 12.5	20 25 35 35	B B B	3RU2116-1GB1 3RU2116-1HB1 3RU2116-1JB1 3RU2116-1KB1	B B B	3RU2116-1HC1 3RU2116-1JC1	
	10	11 16	40	В	3RU2116-4AB1	В	3RU2116-4AC1	
Size S0								
S0	10 10 10	14 20 17 22 20 25	50 63 63	B B B	3RU2126-4BB1 3RU2126-4CB1 3RU2126-4DB1	B B B	3RU2126-4CC1	
	10 10 10 10	23 28 27 32 30 36 34 40	63 80 80 80	B B B	3RU2126-4NB1 3RU2126-4EB1 3RU2126-4PB1 3RU2126-4FB1	B B B B	3RU2126-4EC1 3RU2126-4PC1	
Size S2								
S2	10 10 10	22 32 28 40 36 45	80 NEV 80 NEV 100 NEV	<b>V</b> ▶	3RU2136-4EB1 3RU2136-4FB1 3RU2136-4GB1	<b>&gt;</b>	3RU2136-4FD1	
	10 10 10	40 50 47 57 54 65	100 NEV 100 NEV 125 NEV	<b>V</b> ►	3RU2136-4HB1 3RU2136-4QB1 3RU2136-4JB1	<b>*</b>	3RU2136-4QD1 3RU2136-4JD1	
	10A 10A	62 73 70 80	160 <b>NEV</b>		3RU2136-4KB1 3RU2136-4RB1	<b>*</b>		

 $<sup>^{\</sup>rm 1)}$  Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

<sup>2)</sup> Maximum protection by fuse only for overload relay, type of coordination "2". Fuse values in connection with contactors, see Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders", http://support.automation.siemens.com/WW/view/en/50250599.

Accessories

## Overview

#### Overload relays for standard applications

The following optional accessories are available for the 3RU21 thermal overload relays:

- Size-specific terminal support for stand-alone installation, in sizes S00 and S0 also with spring-type terminals
- Mechanical RESET (for all sizes)

- Cable release for resetting devices which are difficult to access (for all sizes)
- Electrical remote RESET module in three voltage variants (for all sizes)
- Sealable cover (for all sizes)
- Terminal covers for devices with screw terminals (box terminals) and ring terminal lug connections

## Selection and ordering data

	Version	Size	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Terminal supports for	or stand-alone installation							
	Terminal supports for overload relays with screw terminals			Screw terminals	<b>(1)</b>			
000	For separate mounting of the overload relays;	S00	▶	3RU2916-3AA01		1	1 unit	41F
	screw and snap-on mounting onto standard	S0	<b>&gt;</b>	3RU2926-3AA01		1	1 unit	41F
1111	mounting rail	S2 🛚	<i>VEW</i> A	3RU2936-3AA01		1	1 unit	41F
3RU2916-3AA01	Terminal supports for overload relays with spring-type terminals			Spring-type terminals	<u></u>			
	For separate mounting of the overload relays;	S00	В	3RU2916-3AC01		1	1 unit	41F
6.6.6	screw and snap-on mounting onto standard mounting rail	S0	В	3RU2926-3AC01		1	1 unit	41F



3RU2936-3AA01



3RU2916-3AC01



3RU2926-3AC01

Mechanical RESET	
and the same of th	Resetting plungers, holders and f
<b>/</b> **	Pushbuttons with extended strok (12 mm), IP65, Ø 22 mm
	Extension plungers For compensation of the distance b pushbutton and the unlatching butter
3RU2900-1A with pushbutton and extension plunger	

Resetting plungers, holders and formers	S00 S2	<b>&gt;</b>	3RU2900-1A	1	1 unit	41F
Pushbuttons with extended stroke (12 mm), IP65, Ø 22 mm	S00 S2	В	3SB3000-0EA11	1	1 unit	41J
Extension plungers For compensation of the distance between the pushbutton and the unlatching button of the relay	S00 S2	A	3SX1335	1	1 unit	41J

# Accessories

	Version	Size	D	Т	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Cable releases with	holder for RESET								
.ai	For Ø 6.5 mm holes in the control panel;								
<b>P</b>	max. control panel thickness 8 mm • Length 400 mm	S00	S2 <b>&gt;</b>		3RU2900-1B		1	1 unit	41F
	• Length 600 mm	S00			3RU2900-1C		1	1 unit	41F
3RU2900-1.									
Modules for remote	RESET. electrical								
1.1.1	Operating range 0.85 $1.1 \times U_s$ ,								
Name of the last o	power consumption AC 80 VA, DC 70 W, ON period 0.2 4 s,								
7	switching frequency 60/h	000	CO A		3RU1900-2AB71			4 unit	415
200	• 24 30 V AC/DC • 110 127 V AC/DC	S00			3RU1900-2AB71 3RU1900-2AF71		1	1 unit 1 unit	41F 41F
3RU1900-2A.71	• 220 250 V AC/DC	S00			3RU1900-2AM71		1	1 unit	41F
Sealable covers									
H H	For covering the setting knobs	S00	S2 ►		3RV2908-0P		100	10 units	41E
3RV2908-0P									
Terminal covers									
444	Covers for devices with screw terminals (box terminals)				Screw terminals	<b>(1)</b>			
-1-1-	Additional touch protection for fastening								
	to the box terminals  • Main current level	S2 N	<i>IEW</i> B		3RT2936-4EA2		1	1 unit	41B
3RT2936-4EA2		32 1			01112300 4EA2		'	1 dilit	
KKKKY	Covers for devices with ring terminal lug connection				Ring terminal lug connection	<b>(</b>			
	(ensure finger-safety)								
3RU2916-3BJ21	Main current level     Cover between contactor and overload relay	S00	С		3RU2916-3BJ21		1	10 units	41F
\$ 100 m m	for direct mounting of the overload relay	S0	C		3RU2926-3BJ21		i	10 units	41F
	- Cover for overload relay on load side	S00 S0	C B		3RU2916-3BJ20 3RV2928-4AA00		1 1	10 units 1 unit	41F 41E
3RU2926-3BJ21	Auxiliary current level	S00, S0			3RT2916-4EA13			10 units	41B
12 12 12									
3RU2916-3BJ20									
LILL									
3RV2928-4AA00									
HICK									
3RT2916-4EA13									

Accessories

#### General accessories

	Version	Size	Color	For overload relays	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Tools for opening	spring-type termin	als								
						Spring-type terminals	$\stackrel{\circ}{\square}$			
3RA2908-1A	Screwdrivers For all SIRIUS devices with spring-type terminals	Length approx. 200 mm, 3.0 mm x 0.5 mm	Titanium gray/ black, partially insulated	Main and auxiliary circuit connection: 3RU2	Α	3RA2908-1A		1	1 unit	41B
Blank labels										
96.27 10 00 00 00 00 00 00 00 00 00 00 00 00	Unit labeling plates <sup>1)</sup> for SIRIUS devices	20 mm x 7 mm	Pastel turquoise	3RU2	D	3RT1900-1SB20		100	340 units	41B
3RT2900-1SB20		20 mm x 7 mm	Titanium gray	3RU2	D	3RT2900-1SB20		100	340 units	41B

PC labeling system for individual inscription of unit labeling plates available from: murrplastik Systemtechnik GmbH (see Chapter 16, "Appendix" → "External Partners").

## More information

#### Manuals

- System Manual "SIRIUS Innovations System Overview" http://support.automation.siemens.com/WW/view/en/60311318
- Manual "SIRIUS Innovations SIRIUS 3RU2/3RB3 Overload Relays"
- http://support.automation.siemens.com/WW/view/en/60298164

## SIRIUS 3RU1 Thermal Overload Relays


## 3RU11 up to 100 A for standard applications

#### Overview

#### Note:

The 3RU11 devices (sizes S00/S0 to S3) can be found

- in the Catalog Add-On IC 10 AO · 2015 at the Information and Download Center
- in the interactive catalog CA 01
- in the Industry Mall



- Switch position indicator and TEST function of the wiring: Indicates a trip and enables the wiring test.
- ② Motor current setting: Setting the device to the rated motor current is easy with the large rotary knob.
- (3) Transparent, sealable cover: Secures the motor current setting and the TEST function against adjustment.
- Connecting terminals:
   The generously sized terminals permit connection of two conductors with different cross-sections for main and auxiliary circuits. The auxiliary circuit can be connected with screw terminals and alternatively with spring-type terminals.
- (5) STOP button: If the STOP button is pressed, the NC contact is opened. This switches off the contactor downstream. The NC contact is closed again when the button is released.
- (6) Selector switch for manual/automatic RESET and RESET button: With this switch you can choose between manual and automatic RESET. A device set to manual RESET can be reset locally by pressing the RESET button. A remote RESET is possible using the RESET modules (accessories), which are independent of size.
- (7) Connection for mounting onto contactors:
  Optimally adapted in electrical, mechanical and design terms to the contactors. These connecting pins can be used for direct mounting of the overload relay to the contactor. Stand-alone installation is possible as an alternative (partly in conjunction with a terminal support for stand-alone installation).

"Protection Equipment – 3RU1, 3RB2 Overload Relays, http://support.automation.siemens.com/WW/view/en/35681830) against excessive temperature rises due to overload or phase failure.

An overload or phase failure results in an increase of the motor current beyond the set rated motor current. Via heating ele-

The 3RU11 thermal overload relays up to 100 A have been designed for inverse-time delayed protection of loads with

normal starting ("Function", see Reference Manual

An overload or phase failure results in an increase of the motor current beyond the set rated motor current. Via heating elements, this current rise heats up the bimetal strips inside the device which then bend and as a result trigger the auxiliary contacts by means of a tripping mechanism. The auxiliary contacts then switch off the load by means of a contactor. The break time depends on the ratio between the tripping current and current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Curves" http://support.automation.siemens.com/WW/view/en/20356133/134300).

The "tripped" status is signaled by means of a switch position indicator. Resetting takes place either manually or automatically after a recovery time has elapsed ("Function", see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays" http://support.automation.siemens.com/WW/view/en/35681830).

The 3RU11 thermal overload relays are suitable for operation with frequency converters. Please follow the instructions in the Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", see

http://support.automation.siemens.com/WW/view/en/35681830.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials.

They comply with all important worldwide standards and approvals.

3RU21 overload relays in sizes S00 to S2, see page 7/100 onwards.

#### Use in hazardous areas

The 3RU11 thermal overload relays are suitable for the protection of motors with "Flameproof enclosure d" or "Increased safety e" types of protection.

EC type test certificate for Category (2) G/D exists. It has the number DMT 98 ATEX G001.

SIRIUS 3RU1146-1HB0 thermal overload relay

#### Article No. scheme

Digit of the Article No.	1st - 3rd	4th	5th	6th	7th		8th	9th	10th	11th
						-				
Thermal overload relays	3 R U									
SIRIUS 1st generation		1								
Device series										
Size, rated operational current and power										
Setting range of the overload release										
Connection methods										
Installation type										
Example	3 R U	1	1	4	6	_	4	D	В	0

#### Note:

The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

3RU11 up to 100 A for standard applications

## Benefits

The most important features and benefits of the 3RU11 thermal overload relays are listed in the overview table (see "General Data", page 7/87 onwards).

#### Application

#### Industries

The 3RU11 thermal overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed protection of their electrical loads (e.g. motors) under normal starting conditions (CLASS 10).

#### **Application**

The 3RU11 thermal overload relays have been designed for the protection of three-phase and single-phase AC and DC motors.

If single-phase AC or DC loads are to be protected by the 3RU11 thermal overload relays, all three bimetal strips must be heated. For this purpose, all main current paths of the relay must be connected in series.

#### **Ambient conditions**

The 3RU11 thermal overload relays have temperature compensation in accordance with IEC 60947-4-1 for the temperature range of -20 to +60  $^{\circ}$ C. For temperatures from +60 to +70  $^{\circ}$ C, the upper set value of the setting range must be reduced by the factor listed in the table below.

## Technical specifications

Repeat terminals
• Coil repeat terminals

• Auxiliary contact repeat terminal

The following technical information is intended to provide an initial overview of the various types of device and functions.

Detailed information, see

Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays",

http://support.automation.siemens.com/WW/view/en/35681830

		http://support.automation.siemens.com/WW/view/en/35681830
Type Size Dimensions (W x H x D) (overload relay with stand-alone installation support)	mm	<b>3RU1146</b> S3 70 x 120 x 140
General data		
Trips in the event of		Overload and phase failure
Trip class acc. to IEC 60947-4-1	CLASS	10
Phase failure sensitivity		Yes
Overload warning		No
Reset and recovery  Reset options after tripping		Manual, Automatic and Remote RESET (Remote RESET in combination with the corresponding accessories)
<ul> <li>Recovery time</li> <li>For automatic RESET</li> <li>For manual RESET</li> <li>For remote RESET</li> </ul>	min. min. min.	Depends on the strength of the tripping current and characteristic Depends on the strength of the tripping current and characteristic Depends on the strength of the tripping current and characteristic
Features		
Display of operating state on device		Yes, by means of TEST function/switch position indicator slide
TEST function		Yes
RESET button		Yes
STOP button		Yes
Protection and operation of motors with "Increased safety e" and "Flameproof enclosure d" types of protection		
EC type test certificate number according to directive 94/9/EC (ATEX)		DMT 98 ATEX G 001  II (2) GD, see http://support.automation.siemens.com/WW/view/en/5355912
Ambient temperature		
Storage/transport	°C	-55 +80
Operation	°C	-20 +70
Temperature compensation	°C	up to 60
<ul> <li>Permissible rated current at</li> <li>Temperature inside control cabinet 60 °C</li> <li>Temperature inside control cabinet 70 °C</li> </ul>	%	100 (over +60 °C current reduction is not required) 87

Not required

Not required

# SIRIUS 3RU1 Thermal Overload Relays

# 3RU11 up to 100 A for standard applications

Туре		3RU1146
Size		\$3
Dimensions (W x H x D) (overload relay with stand-alone installation	■	70 x 120 x 140
support)	w o	
General data (continued)	,	
Degree of protection acc. to IEC 60529		IP20 (terminal compartment: IP00 degree of protection)
Touch protection acc. to IEC 61140		Finger-safe for vertical contact from the front
Shock resistance with sine acc. to IEC 60068-2-27	g/ms	8/10
Electromagnetic compatibility (EMC)		
Interference immunity		Not relevant
Emitted interference		Not relevant
Resistance to extreme climates – air humidity	%	100
Dimensions		"Dimensional drawings", see
		Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681830
Installation altitude above sea level	m	Up to 2 000; above this on request
Mounting position		The diagrams show the permissible mounting positions for mounting onto contactors and stand-alone installation. For mounting position in the hatched area, a setting correction of 10 % must be implemented.  Stand-alone installation:
		135°
		Contactor + overload relay: $ \begin{array}{ccccccccccccccccccccccccccccccccccc$
Type of mounting		Direct mounting/stand alone installation with terminal support

Type of mounting

Direct mounting/stand-alone installation with terminal support (For screw and snap-on mounting onto TH 35 standard mounting rail; size S3 also for TH 75 standard mounting rail. For technical specifications of the terminal supports, see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681830.)

# Overload Relays SIRIUS 3RU1 Thermal Overload Relays

### 3RU11 up to 100 A for standard applications

Туре		3RU1146
Size		S3
Main circuit		
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	1 000
Rated impulse withstand voltage $U_{imp}$	kV	8
Rated operational voltage $U_{\rm e}$	V	1 000
Type of current		
Direct current		Yes
Alternating current		Yes, frequency range up to 400 Hz
Current setting	А	18 25 up to 80 100
Power loss per unit (max.)	W	10 16.5
Short-circuit protection		
With fuse without contactor		See "Selection and ordering data" on page 7/111
With fuse and contactor		See Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681830 → "Technical Specifications" → "Short-circuit protection with fuses/motor starter protectors for motor feeders".
Protective separation between main and auxiliary current paths acc. to IEC 60947-1	V	690
Conductor cross-section of the main circuit		
Connection type		Screw terminals with box terminal
Terminal screw		M8, 4 mm Allen screw
Operating devices	mm	4 mm Allen screw
Prescribed tightening torque	Nm	4 6
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
• Solid	mm <sup>2</sup>	2 x (2.5 16)
<ul> <li>Finely stranded with end sleeve (DIN 46228-1)</li> </ul>	mm <sup>2</sup>	2 x (2.5 35) <sup>1)</sup> , 1 x (2.5 50) <sup>1)</sup>
Stranded	mm <sup>2</sup>	2 x (10 50) <sup>1)</sup> , 1 x (10 70) <sup>1)</sup>
<ul> <li>AWG cables, solid or stranded</li> </ul>	AWG	2 x (10 1/0) <sup>1)</sup> , 1 x (10 2/0) <sup>1)</sup>
Ribbon cable conductors (Number x Width x Thickness)	mm	2 x (6 x 9 x 0.8)
Connection type		Busbar connection <sup>2)</sup>
Terminal screw		M6 x 20
Prescribed tightening torque	Nm	46
Conductor cross-sections (min./max.)	0	
Finely stranded with cable lug	mm <sup>2</sup>	2 x 70
Stranded with cable lug	mm <sup>2</sup>	3 x 70
<ul> <li>AWG cables, solid or stranded, with cable lug</li> </ul>	AWG	2/0
<ul> <li>With connecting bars (max. width)</li> </ul>	mm	12

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

<sup>2)</sup> The box terminal is removable. Rail and cable lug connections are possible if the box terminal is removed.

# Overload Relays SIRIUS 3RU1 Thermal Overload Relays

### 3RU11 up to 100 A for standard applications

T		0DU4440
Type		3RU1146
Size  Auxiliary circuit		S3
Number of NO contacts		1
Number of NC contacts		1
Auxiliary contacts – assignment		1 NO for the signal "tripped";
Adminity contacts assignment		1 NC for disconnecting the contactor
Rated insulation voltage $U_i$ (pollution degree 3)	V	690
Rated impulse withstand voltage $U_{\rm imp}$	kV	6
Contact rating of the auxiliary contacts		
<ul> <li>NC contact with alternating current AC-14/AC-15, rated operational current I<sub>e</sub> at U<sub>e</sub>:</li> </ul>		
- 24 V	Α	4
- 120 V	A	4
- 125 V - 230 V	A A	4 3
- 400 V	Α	2
- 600 V - 690 V	A A	0.6 0.5
NO contact with alternating current AC-14/AC-15,	A	0.3
rated operational current $I_{\rm e}$ at $U_{\rm e}$ :		
- 24 V	A	3
- 120 V - 125 V	A A	3 3
- 230 V	Α	2
- 400 V - 600 V	A A	1 0.6
- 600 V - 690 V	A	0.5
NC contact, NO contact with direct current DC-13,		
rated operational current $I_{\rm e}$ at $U_{\rm e}$ :	۸	
- 24 V - 60 V	A A	1 On request
- 110 V	Α	0.22
- 125 V - 220 V	A A	0.22 0.11
	A	6
<ul> <li>Conventional thermal current I<sub>th</sub></li> <li>Contact reliability (suitability for PLC control; 17 V, 5 mA)</li> </ul>	А	
		Yes
Short-circuit protection  • With fuse		
- Operational class gG	Α	6
- Quick	Α	10
With miniature circuit breaker (C characteristic)	А	6 <sup>1)</sup>
Protective separation between auxiliary current paths acc. to IEC 60947-1	V	440
CSA, UL, UR rated data		
Auxiliary circuit – switching capacity		B600, R300
Conductor cross-sections of the auxiliary circuit		
Connection type		Screw terminals
Terminal screw		M3, Pozidriv size 2
Operating devices	mm	Ø56
Prescribed tightening torque	Nm	0.8 1.2
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
• Solid	$\text{mm}^2$	2 x (0.5 1.5) <sup>2)</sup> , 2 x (0.75 2.5) <sup>2)</sup>
Finely stranded without end sleeve	$\rm mm^2$	-
• Finely stranded with end sleeve (DIN 46228-1)	$\rm mm^2$	2 x (0.5 1.5) <sup>2)</sup> , 2 x (0.75 2.5) <sup>2)</sup>
• Stranded	$\text{mm}^2$	2 x (0.5 1.5) <sup>2)</sup> , 2 x (0.75 2.5) <sup>2)</sup>
AWG cables, solid or stranded	AWG	2 x (18 14)
Connection type		Spring-type terminals
Operating devices		
Operating devices	mm	3.0 x 0.5 and 3.5 x 0.5
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected	m=2	2.4.(0.5
Solid or stranded     Finally stranded without and alexage	mm <sup>2</sup>	2 x (0.5 2.5)
Finely stranded without end sleeve     Finely stranded with and sleeve (DIN 46228.1)	mm <sup>2</sup>	2 x (0.5 2.5)
Finely stranded with end sleeve (DIN 46228-1)  ANC pables, called an attended.	mm <sup>2</sup>	2 x (0.5 1.5)
AWG cables, solid or stranded  1) I.L. I. T. 10.5   A. 1.000   V. 10.5    1. T. 1	AWG	2 x (20 14)
1) Up to $I_{\rm k} \le 0.5$ kA; $\le 260$ V.		

If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

### **Overload Relays** SIRIUS 3RU1 Thermal Overload Relays

3RU11 up to 100 A for standard applications

### Selection and ordering data

Features and technical specifications:

- · Connection methods
  - Main circuit: Screw terminals
  - Auxiliary circuit: Either screw or spring-type terminals
- Tripping class CLASS 10
- Overload and phase failure protection
- Auxiliary contacts 1 NO + 1 NC

- Manual and automatic RESET
- Switch position indicator
- TEST function
- STOP button
- Integrated sealable cover

### 3RU11 thermal overload relays with screw terminals on the auxiliary current side, CLASS 10

	Size contactor	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>1)</sup>	DT	Screw terminals (on auxiliary current side)	<b></b>	PU (UNIT, SET, M)	PS*	PG
		CLASS	A	А		Article No.	Price per PU			
Size S3										
	For mou	nting onto d	contactor <sup>2)</sup>							
	S3	10 10	18 25 22 32	63 80	<b>&gt;</b>	3RU1146-4DB0 3RU1146-4EB0		1 1	1 unit 1 unit	41F 41F
3000		10 10 10 10	28 40 36 50 45 63 57 75	80 125 125 160	<b>* * * *</b>	3RU1146-4FB0 3RU1146-4HB0 3RU1146-4JB0 3RU1146-4KB0		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41F 41F 41F 41F
3RU1146B0		10 10	70 90 80 100 <sup>3)</sup>	160 200	<b>&gt;</b>	3RU1146-4LB0 3RU1146-4MB0		1 1	1 unit 1 unit	41F 41F
	For stan	d-alone inst	allation							
0 0 0	S3	10 10 10 10	45 63 57 75 70 90 80 100 <sup>3)</sup>	125 160 160 200	<b>* * *</b>	3RU1146-4JB1 3RU1146-4KB1 3RU1146-4LB1 3RU1146-4MB1		1 1 1	1 unit 1 unit 1 unit 1 unit	41F 41F 41F 41F
3RU1146-4JB1										

- 2) With the appropriate terminal supports (see "Accessories", page 7/112), the 3RU11 overload relays for mounting onto contactors can also be installed as stand-alone units.
- $^{3)}$  For overload relays > 100 A, see 3RB2 electronic overload relays, page 7/130 onwards.

### 3RU11 thermal overload relays with screw terminals, CLASS 10

	Size contactor	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG 1)	DT	Spring-type terminals (on auxiliary current side)	***	PU (UNIT, SET, M)	PS*	PG
		CLASS	A	A		Article No.	Price per PU			
Size S3 <sup>2)</sup>										
	For mou	nting onto	contactor <sup>3)</sup>			_				
	S3	10 10 10 10	18 25 22 32 28 40 36 50	63 80 80 125	B B B	3RU1146-4DD0 3RU1146-4ED0 3RU1146-4FD0 3RU1146-4HD0		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41F 41F 41F 41F
G G G		10 10	45 63 57 75	125 160	<b>&gt;</b>	3RU1146-4JD0 3RU1146-4KD0		1 1	1 unit 1 unit	41F 41F
		10	70 90	160	<b>&gt;</b>	3RU1146-4LD0		1	1 unit	41F

<sup>1)</sup> Maximum protection by fuse only for overload relay, type of coordination "2". Fuse values in connection with contactors, see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload

Relays\*, http://support.automation.siemens.com/WW/view/en/35681830 → "Technical Specifications" → "Short-Circuit Protection with Fuses/Motor Starter Protectors for Motor Feeders".

<sup>1)</sup> Maximum protection by fuse only for overload relay, type of coordination "2". Fuse values in connection with contactors, see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681830 → "Technical Specifications" → "Short-Circuit Protection with Fuses/Motor Starter Protectors for Motor Feeders".

<sup>&</sup>lt;sup>2)</sup> Auxiliary conductor connections with spring-type terminals and main conductor connections with screw terminals.

<sup>3)</sup> With the appropriate terminal supports (see "Accessories", page 7/112), the 3RU11 overload relays for mounting onto contactors can also be installed as stand-alone units.

### SIRIUS 3RU1 Thermal Overload Relays

### Accessories

### Overview

### Overload relays for standard applications

The following optional accessories are available for the 3RU11 thermal overload relays:

- Terminal supports for stand-alone installation for the overload relays
- Mechanical RESET (for all sizes)

- Cable release for resetting devices which are difficult to access (for all sizes)
- Electrical remote RESET module in three voltage variants (for all sizes)
- · Terminal covers

### Technical specifications

### Terminal supports for stand-alone installation

point, both cross-sections must be in the range specified.

Туре		3RU1946-3AA01
For overload relays		3RU1146
Mounting type		For screw and snap-on mounting onto TH 35 and TH 75 standard mounting rails
Connection for main circuit		
Connection type		Screw terminals with box terminal
Terminal screw	mm	4 mm Allen screw
Operating devices	mm	4 mm Allen screw
Prescribed tightening torque	Nm	4 6
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded	$mm^2$	2 x (2.5 16)
• Finely stranded without end sleeve	$\text{mm}^2$	
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	2 x (2.5 35) <sup>1)</sup> , 1 x (2.5 50) <sup>1)</sup>
Stranded	$\text{mm}^2$	2 x (10 50) <sup>1)</sup> , 1 x (10 70) <sup>1)</sup>
AWG cables, solid or stranded	AWG	2 x (10 1/0) <sup>1)</sup> , 1 x (10 2/0) <sup>1)</sup>
• Ribbon cable conductors (Number x Width x Thickness)	mm	2 x (6 x 9 x 0.8)
1) If two different conductor cross-sections are connected to one clamping		

### Selection and ordering data

Selection and ord	ering data						
	Version	Size D	Γ Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Terminal supports	for stand-alone installation		_				
3RU19.6-3AA01	For separate mounting of the overload relays; screw and snap-on mounting onto standard mounting rail	\$3 <b>&gt;</b>	3RU1946-3AA	01	1	1 unit	41F
Mechanical RESE	Г						
and the	Resetting plungers, holders and formers	S3 >	3RU1900-1A		1	1 unit	41F
<b>/</b> *	Pushbuttons with extended stroke (12 mm), IP65, Ø 22 mm	S3 B	3SB3000-0EA	11	1	1 unit	41J
3RU1900-1A with pushbutton and extension plunger	Extension plungers For compensation of the distance between the pushbutton and the unlatching button of the relay	S3 A	3SX1335		1	1 unit	41J

# Overload Relays SIRIUS 3RU1 Thermal Overload Relays

### Accessories


	Version			Size	DT	Article No.	Price per PU	PU (UNIT,	PS*	PG
								SET, M)		
Cable releases wit	th holder for RESET									
edusio reledesee mi	For Ø 6.5 mm holes in									
	max. control panel this									
	• Length 400 mm			S3	<b>&gt;</b>	3RU1900-1B		1	1 unit	41F
	Length 600 mm			S3		3RU1900-1C		1	1 unit	41F
V										
3RU1900-1.										
Modules for remo	te RESET, electrical									
	Operating range 0.85 power consumption A									
11411	ON period 0.2 4 s, switching frequency 6	iΩ/h								
	• 24 30 V AC/DC	0,11		S3	Α	3RU1900-2AB71		1	1 unit	41F
	• 110 127 V AC/DC			S3	Α	3RU1900-2AF71		1	1 unit	41F
	• 220 250 V AC/DC			S3	Α	3RU1900-2AM71		1	1 unit	41F
000000000000000000000000000000000000000										
3RU1900-2A.71 Terminal covers										
Terminal bovers	Covers for cable lugs	s and busbar conr	ections							
	• Length 55 mm			S3	В	3RT1946-4EA1		1	1 unit	41B
	Covers for box termi	nals								
	• Length 20.8 mm			S3		3RT1946-4EA2		1	1 unit	41B
General accessor	ries									
	Version	Size	Color	For	DT	Article No.	Price	PU	PS*	PG
				overload relays			per PU	(UNIT, SET, M)		
Tools for opening	spring-type termina	als								
						Spring-type terminals	$\approx$			
1	Screwdrivers	Length approx.	Titanjum	Main and	Α	3RA2908-1A		1	1 unit	41B
3RA2908-1A	For all SIRIUS devices with spring-type	200 mm, 3.0 mm x 0.5 mm	gray/ black,	auxiliary circuit						
3HA29U6-TA	terminals		partially insulated	connection: 3RU1						
Blank labels			irisulated	31101						
	Unit labeling plates 1)	20 mm x 7 mm	Pastel	3RU1	D	3RT1900-1SB20		100	340 units	41B
	for SIRIUS devices	00 7	turquoise	ODLIA		0DT0000 40D00		100	0.40	440
		20 mm x 7 mm	Titanium gray	3RU1	D	3RT2900-1SB20		100	340 units	41B
45 A B B B B B B B B B B B B B B B B B B	Adhesive inscription labels 1)	19 mm x 6 mm	Pastel	3RU1	С	3RT1900-1SB60		100	3 060 units	41B
SB0_001			turquoise	00111	_			400	0.000 !!	
3RT1900-1SB20	for SIRIUS devices	19 mm x 6 mm	Zinc yellow	3RU1	С	3RT1900-1SD60		100	3 060 units	41B

PC labeling system for individual inscription of unit labeling plates available from: murrplastik Systemtechnik GmbH (see Chapter 16, "Appendix" → "External Partners").

### SIRIUS 3RB3 Electronic Overload Relays

### 3RB30, 3RB31 up to 80 A for standard applications

### Overview



- 1 Switch position indicator and TEST function of the wiring: Indicates a trip and enables the wiring test.
- 2 Trip class setting/internal ground-fault detection (only 3RB31): Using the rotary switch you can set the required trip class and activate the internal ground-fault detection dependent on the start-up conditions.
- 3 Solid-state test (device test): Enables a test of all important device components and functions.
- 4 Connecting terminals (removable joint block for auxiliary circuits): Depending on the device version, the terminals for screw and spring-type connection are configured for the main and auxiliary circuit.
- (5) Selector switch for manual/automatic RESET: With the slide switch you can choose between manual and automatic RESET.
- 6 Motor current setting: Setting the device to the rated motor current is easy with the large rotary knob.
- A device set to manual RESET can be reset locally by pressing the RESET button. On 3RB31 overload relays an electrical remote RESET is integrated.
- 8 Connection for mounting onto contactors:
  Optimally adapted in electrical, mechanical and design terms to the contactors 3RT2. The overload relay can be connected directly using these connection pins. Stand-alone installation is possible as an alternative (in conjunction with a terminal support for stand-alone installation).

A sealable transparent cover can be optionally mounted (accessory). It secures the motor current setting against adjustment.

SIRIUS 3RU3133-4.B0 electronic overload relay

The 3RB30/3RB31 electronic overload relays up to 80 A with internal power supply have been designed for inverse-time delayed protection of loads with normal and heavy starting (for "Function", see the manual

"SIRIUS Innovations – SIRIUS 3RU2/3RB3 Overload Relays", http://support.automation.siemens.com/WW/view/en/60298164) against excessive temperature rises due to overload, phase unbalance or phase failure. An overload, phase unbalance or phase failure result in an increase of the motor current beyond the set rated motor current. This current rise is detected by the current transformers integrated into the devices and evaluated by corresponding solid-state circuits which then output a pulse to the auxiliary contacts. The auxiliary contacts then switch off the load by means of a contactor. The break time depends on the ratio between the tripping current and current setting  $I_e$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Curves"

http://support.automation.siemens.com/WW/view/en/34290881/134300).

In addition to inverse-time delayed protection of loads against excessive temperature rises due to overload, phase unbalance and phase failure, the 3RB31 electronic overload relays also allow internal ground-fault detection (not possible in conjunction with contactor assemblies for wye-delta starting). This provides protection of loads against high-resistance short circuits due to damage to the insulation material, moisture, condensed water etc.

The "tripped" status is signaled by means of a switch position indicator. Resetting takes place either manually or automatically after the recovery time has elapsed ("Function", see manual "SIRIUS Innovations – SIRIUS 3RU2/3RB3 Overload Relays", http://support.automation.siemens.com/WW/view/en/60298164).

The 3RB3 electronic overload relays are suitable for operation with frequency converters. Please follow the instructions in the manual "SIRIUS Innovations – 3RU2/3RB3 Overload Relays", see http://support.automation.siemens.com/WW/view/en/60298164.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

3RB20 and 3RB21 overload relays in sizes S2 to S10/S12, see page 7/130 onwards.

### Use in hazardous areas

The 3RB30/3RB31 electronic overload relays are suitable for the overload protection of motors with the following types of protection:

- 🐼 II (2) G [Ex e] [Ex d] [Ex px]
- 😥 II (2) D [Ex t] [Ex p]

EC type test certificate for Group II, Category (2) G/D exists. It has the number PTB 09 ATEX 3001.

3RB30, 3RB31 up to 80 A for standard applications

### Article No. scheme

Dinit of the Auticle No.	1 - 4 O 1	441-	C+I-	CHI-	74-		OHL	041-	4 041-	4 444	
Digit of the Article No.	1st - 3rd	4th	5th	юtп	7 tn		8th	9th	Tuth	11th	
						-					
Electronic overload relays	3 R B										
SIRIUS 3rd generation		3									
Device series											
Size, rated operational current and power											
Version of the automatic RESET, electrical remote RESET											
Trip class (CLASS)											
Setting range of the overload release											
Connection methods											
Installation type	-										
Example	3 R B	3	0	1	6	-	1	R	В	0	

### Note:


The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

### Benefits

The most important features and benefits of the 3RB30/3RB31 electronic overload relays are listed in the overview table (see "General Data" on page 7/87).

### Advantages through energy efficiency



Overview of the energy management process

We offer you a unique portfolio for industrial energy management, using an energy management system that helps to optimally define your energy needs. We split up our industrial energy management into three phases – identify, evaluate and realize – and we support you with the appropriate hardware and software solutions in every process phase.

The innovative products of the SIRIUS industrial controls portfolio can also make a substantial contribution to a plant's energy efficiency (see www.siemens.com/sirius/energysaving).

3RB30/3RB31 electronic overload relays contribute to energy efficiency throughout the plant as follows:

- Reduced inherent power loss
- · Less heating of the control cabinet
- Smaller control cabinet air conditioners can be used

### Application

### Industries

The 3RB30/3RB31 electronic overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed protection of their electrical loads (e.g. motors) under normal and heavy starting conditions (CLASS 5E to 30E), minimize project completion times, inventories and energy consumption, and optimize plant availability and maintenance management.

### Application

The 3RB30/3RB31 electronic overload relays have been designed for the protection of three-phase motors in sinusoidal 50/60 Hz voltage networks. The relays are not suitable for the protection of single-phase AC or DC loads.

The 3RU21 thermal overload relay or the 3RB22/3RB23 solid-state overload relay can be used for single-phase AC loads. For DC loads we recommend the 3RU21 thermal overload relay.

### Ambient conditions

The devices are insensitive to external influences such as shocks, corrosive ambient conditions, ageing and temperature fluctuations.

For the temperature range from -25 °C to +60 °C, the 3RB30/3RB31 electronic overload relays compensate the temperature in accordance with IEC 60947-4-1.

### SIRIUS 3RB3 Electronic Overload Relays

### 3RB30, 3RB31 up to 80 A for standard applications

### Technical specifications

The following technical information is intended to provide an initial overview of the various types of device and functions.

Detailed information, see

- Manual "SIRIUS Innovations SIRIUS 3RU2/3RB3 Overload
- http://support.automation.siemens.com/WW/view/en/60298164
- or specific information on a particular article number via the product data sheet.

http://support.a	utomation siemens	com/M/M/view/en	/34290881/133200

		http://support.auton	nation.siemens.com/WW/view	v/en/34290881/133200
Туре		3RB301., 3RB311.	3RB302., 3RB312.	3RB3036, 3RB3133
		S00	S0	S2
Dimensions (W x H x D)	<b>=</b> ./			
(overload relay with stand-alone installation support)	•			
<ul> <li>Screw terminals</li> <li>Spring-type terminals</li> </ul>	mm mm	45 x 89 x 80 45 x 102 x 80	45 x 97 x 94 45 x 116 x 95	55 x 105 x 117 55 x 105 x 117
	111111	43 X 102 X 00	45 X 110 X 95	33 X 103 X 117
General data		O		
Trips in the event of		Overload, phase failure, + ground fault (for 3RB3		
Trip class acc. to IEC 60947-4-1	CLASS	3RB30: 10E, 20E; 3RB31: 5E, 10E, 20E or 3	30E adjustable	
Phase failure sensitivity		Yes		
Reset and recovery				
Reset options after tripping		Manual and automatic R electrical remote RESET	ESET, 3RB31 has an integrate (24 V DC)	d connection for
Recovery time		A 0 '		
- For automatic RESET - For manual RESET		Approx. 3 min Immediately		
- For remote RESET		Immediately		
Features				
Display of operating state on device		Yes, by means of switch	position indicator slide	
TEST function			y pressing the TEST button/ and wiring of control circuit b elf-monitoring	y actuating the switch
RESET button		Yes		
STOP button		No		
Protection and operation of explosion-proof motors				
EC type test certificate number according to		PTB 09 ATEX 3001		On request
directive 94/9/EC (ATEX)		(x) II (2) G [Ex e] [Ex d] (x) II (2) G [Ex t] [Ex p] See	[Ex px]	·
			mens.com/WW/view/en/40591327	
Ambient temperatures				
Storage/transport	°C	-40 +80		
Operation	°C	-25 +60		
Temperature compensation	°C	+60		
<ul> <li>Permissible rated current at</li> <li>Temperature inside control cabinet 60 °C</li> <li>Temperature inside control cabinet 70 °C</li> </ul>	%	100 On request		
Repeat terminals		'		
Coil repeat terminals		Yes	Not required	
Auxiliary contact repeat terminal		Yes	Not required	
Degree of protection acc. to IEC 60529		IP20		
Touch protection acc. to IEC 61140		Finger-safe for vertical co	ontact from the front	
Shock resistance with sine acc. to IEC 60068-2-27	g/ms	15/11 (signaling contact 97/98 "Tripped" position: 9 g/11 ms)		15/11 (signaling contact 97/98 in "Tripped" position: 8 g/11 ms)
Electromagnetic compatibility (EMC) – Interference immunity		J/		,
Conductor-related interference				
- Burst acc. to IEC 61000-4-4 (corresponds to degree of severity 3) - Surge acc. to IEC 61000-4-5	kV kV	2 (power ports), 1 (signal 2 (line to earth), 1 (line to	,	
(corresponds to degree of severity 3)		, 12 Odi a 1/1, 1 (iii lo to	-/	
<ul> <li>Electrostatic discharge according to IEC 61000-4-2 (corresponds to degree of severity 3)</li> </ul>	kV	8 (air discharge), 6 (cont	act discharge)	
<ul> <li>Field-related interference acc. to IEC 61000-4-3 (corresponds to degree of severity 3)</li> </ul>	V/m	10		
Electromagnetic compatibility (EMC) – emitted interference		EN 55022 (CISPR 22)	. to EN 55011 (CISPR 11) and	
Resistance to extreme climates – air humidity	%	95		

### 3RB30, 3RB31 up to 80 A for standard applications

		3RB30, 3F	RB31 up to 80 A for	standard applications
Туре		3RB301., 3RB311.	3RB302., 3RB312.	3RB3036, 3RB3133
Size		S00	S0	S2
Dimensions (W x H x D)	,	000	00	02
(overload relay with stand-alone installation support)  • Screw terminals	mm	45 x 89 x 80	45 x 97 x 94	55 x 105 x 117
Spring-type terminals	mm mm	45 x 102 x 80	45 x 97 x 94 45 x 116 x 95	55 x 105 x 117
General data (continued)				
Dimensions		"Dimensional drawings"		
			vations – SIRIUS 3RU2/3RE ation.siemens.com/WW/vie	
		<ul> <li>Product data sheet,</li> </ul>		
Installation altitude above sea level	m		n.siemens.com/WW/view/en/34	1290881/133200
Mounting position	m	Up to 2 000 Any		
Type of mounting			alone installation with term	inal support
7		J,		
		appear appear	appear appear	ODD0000 ODD0400
Type		3RB301., 3RB311.	3RB302., 3RB312.	3RB3036, 3RB3133
Size Main circuit		S00	S0	S2
Rated insulation voltage <i>U</i> <sub>i</sub>	V	690		
(pollution degree 3)	V	090		
Rated impulse withstand voltage $U_{\rm imp}$	kV	6		
Rated operational voltage U <sub>e</sub>	V	690		
Type of current				
<ul><li>Direct current</li><li>Alternating current</li></ul>		No Yes, 50/60 Hz ± 5 %		
Current setting	Α	0.1 0.4	0.1 0.4	12.5 50
<b>3</b>		up to	up to	and
Heavy storting	Α	4 16	10 40 novations – SIRIUS 3RU2/3	20 to 80
Heavy starting			on.siemens.com/WW/view/	
Power loss per unit (max.)	W	0.05 0.2		
Short-circuit protection				
<ul><li>With fuse without contactor</li><li>With fuse and contactor</li></ul>			ering data" on pages 7/119 n with Fuses/Motor Starter	
With race and contactor		Feeders", see Configura	ation Manual for "Configuri	ng SIRIUS Innovations -
			eless and Fused Load Feed on.siemens.com/WW/view/	
Protective separation between main and auxiliary current paths		Titp://oupportiautomatic		31,007 1 1 100.
acc. to IEC 60947-1 (pollution degree 2)		000		
<ul> <li>For systems with grounded neutral point</li> <li>For systems with ungrounded neutral point</li> </ul>	V	690 600		
Conductor cross-sections of main circuit				
Connection type		Screw terminals		
Tourise Leaves			MA Desiglative size 0	
Terminal screw Operating devices	mm	M3, Pozidriv size 2 Ø 5 6	M4, Pozidriv size 2	
Prescribed tightening torque	mm Nm	0.8 1.2	Ø 5 6 2 2.5	
Conductor cross-sections (min./max.),	INIII	0.0 1.2	2 2.0	
1 or 2 conductors can be connected	0	4)	4)	4)
Solid or stranded	mm <sup>2</sup>	2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.75 2.5) <sup>1)</sup> ,	2 x (1 2.5) <sup>1)</sup> 2 x (2.5 10) <sup>1)</sup>	1 x (1 50) <sup>1)</sup> , 2 x (1 35) <sup>1)</sup>
	0	2 x (0.5 4) <sup>1)</sup>		
<ul> <li>Finely stranded with end sleeve (DIN 46228-1)</li> </ul>	$mm^2$	2 x (0.5 1.5) <sup>1)</sup> 2 x (0.75 2.5) <sup>1)</sup>	2 x (1 2.5) <sup>1)</sup> , 2 x (2.5 6) <sup>1)</sup> ,	2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup>
			max. 1 x 10	`
AWG cables, solid or stranded	AWG	2 x (20 16) <sup>1)</sup> , 2 x (18 14) <sup>1)</sup> ,	2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup>	2 x (18 2) <sup>1)</sup> , 1 x (18 1) <sup>1)</sup>
		2 x 12	2 x (14 0)	1 X (10 1)
Connection type		Spring-type term	ninals	
Operating devices	mm	3.0 x 0.5 and 3.5 x 0.5		
Conductor cross-sections (min./max.),				
1 conductor can be connected	m-2	1 v (0 E 4)	1 v /1 10\	
<ul><li>Solid or stranded</li><li>Finely stranded without end sleeve</li></ul>	mm <sup>2</sup> mm <sup>2</sup>	1 x (0.5 4) 1 x (0.5 2.5)	1 x (1 10) 1 x (1 6)	
<ul> <li>Finely stranded with end sleeve (DIN 46228-1)</li> </ul>	mm <sup>2</sup>	1 x (0.5 2.5)	1 x (1 6)	
AWG cables, solid or stranded     Connection type	AWG	1 x (20 12)	1 x (18 8)	
		Straight-through	r transformers	
Diameter of opening	mm			15
1)				

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

### SIRIUS 3RB3 Electronic Overload Relays

### 3RB30, 3RB31 up to 80 A for standard applications

Туре		3RB301., 3RB311.	3RB302., 3RB312.	3RB3036, 3RB3133
Size		S00	S0	S2
Auxiliary circuit				
Number of NC contacts  Number of NC contacts		1		
		1 NO for the signal "trip	nod":	
Auxiliary contacts – assignment		1 NC for disconnecting		
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	300		
Rated impulse withstand voltage U <sub>imp</sub>	kV	4		
Auxiliary contacts – contact rating				
• NC contact with alternating current AC-14/AC-15, rated operational current	t			
$I_{ m e}$ at $U_{ m e}$ : - 24 V	Α	4		
- 120 V	A	4		
- 125 V - 250 V	A A	4		
NO contact with alternating current AC-14/AC-15, rated operational	^	3		
current $I_{\rm e}$ at $U_{\rm e}$ :				
- 24 V	A	4		
- 120 V - 125 V	A A	4		
- 250 V	A	3		
NC contact, NO contact with direct current DC-13, rated operational				
current $I_{\rm e}$ at $U_{\rm e}$ : - 24 V	Α	2		
- 24 V - 60 V	A	0.55		
- 110 V	Α	0.3		
- 125 V - 250 V	A A	0.3 0.11		
• Conventional thermal current $I_{th}$	Α	5		
Contact reliability (suitability for PLC control; 17 V, 5 mA)	, ,	Yes		
Short-circuit protection		100		
With fuse, operational class gG	Α	6		
Ground-fault protection (only 3RB31)		The information refers to	o sinusoidal residual cu	rrents at 50/60 Hz.
$ullet$ Tripping value $I_{\Lambda}$		$> 0.75 \times I_{\text{motor}}$		
• Operating range <i>I</i>			alue < $I_{mater}$ < 3.5 × uni	per current setting value
• Response time $t_{\text{trip}}$ (in steady-state condition)	S	< 1	a.ao (1111010) (0.0 % ap)	por barroni botting valuo
Integrated electrical remote RESET (only 3RB31)				
Connecting terminals A3, A4		24 V DC, max. 200 mA	for approx. 20 ms, then	< 10 mA
Protective separation between auxiliary current paths	V	300		
acc. to IEC 60947-1				
CSA, UL, UR rated data				
Auxiliary circuit – switching capacity		3RB30: B600, R300; 3F	RB31: B300, R300	
Conductor cross-sections for auxiliary circuit		0		
Connection type		Screw terminals		
Terminal screw		M3, Pozidriv size 2		
Operating devices	mm	Ø 5 6		
Prescribed tightening torque	Nm	0.8 1.2		
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected				
Solid or stranded	mm <sup>2</sup>	$1 \times (0.5 \dots 4)^{1},$ $2 \times (0.5 \dots 2.5)^{1}$		
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	$1 \times (0.5 \dots 2.5)^{1},$ $2 \times (0.5 \dots 1.5)^{1},$		
AWG cables, solid or stranded	AWG	2 × (20 14)		
Connection type		Spring-type term	ninals	
Operating devices	mm	3.0 x 0.5		
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected				
Solid or stranded	$\text{mm}^2$	2 × (0.25 1.5)		
Finely stranded without end sleeve	mm <sup>2</sup>	2 × (0.25 1.5)		
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 × (0.25 1.5)		
AWG cables, solid or stranded	AWG	2 × (24 16)		
If two different conductor cross-sections are connected to one clamping.		, · -/		

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

3RB30, 3RB31 up to 80 A for standard applications

### Selection and ordering data

### 3RB30 electronic overload relays, CLASS 10E

Features and technical specifications:

- Connection methods
- Sizes S00 and S0:
  - Main and auxiliary circuit: Either screw or spring-type terminals
- Size S2:
  - Main circuit: Screw terminals with box terminal or as straight-through transformer,
  - auxiliary circuit: Either screw or spring-type terminals
- Overload protection, phase failure protection and unbalance protection
- Internal power supply
- Auxiliary contacts 1 NO + 1 NC

- Manual and automatic RESET
- Switch position indicator
- TEST function and self-monitoring
- Sealable covers (optional accessory)

PU (UNIT, SET, M) = 1 PS\* = 1 unit PG = 41G

3RB3016-	1TB0 3RB3026-1VB	0 3RB3036-1.B0	3RB3036-1.W1	3RB3016-	-1TE0 3RB3026-1VE0 3	⊕ U → BRB303	66-1.[	3RB3036-1.X	(1
Size contactor <sup>2)</sup>	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>1)</sup>	DT	Screw terminals	<b>+</b>	DT	Spring-type terminals	
					Article No.	Price er PU		Article No.	Price per PU
	CLASS	A	A		þ	er PU			per PU
Size S00			2)						
S00		inting onto contactor			000000000000000000000000000000000000000		^	000000000000	
	10E 10E	0.1 0.4 0.32 1.25	4 6		3RB3016-1RB0 3RB3016-1NB0		A A	3RB3016-1RE0 3RB3016-1NE0	
	10E	1 4	20		3RB3016-1NB0		A	3RB3016-1NE0	
	10E 10E	3 12	25		3RB3016-1PB0		A	3RB3016-1PE0	
	10E	4 16	25		3RB3016-1TB0		A	3RB3016-1TE0	
Size S0	TOL	4 10	20		31103010-1100			31103010-1110	
S0	Devices for mou	ınting onto contactoi	,2)						
00	10F	0.1 0.4	4	•	3RB3026-1RB0		Α	3RB3026-1RE0	
	10E	0.32 1.25	6	•	3RB3026-1NB0		A	3RB3026-1NE0	
	10E	1 4	20	<b>&gt;</b>	3RB3026-1PB0		Α	3RB3026-1PE0	
	10E	3 12	25	<b>&gt;</b>	3RB3026-1SB0		Α	3RB3026-1SE0	
	10E	6 25	50	<b>&gt;</b>	3RB3026-1QB0		Α	3RB3026-1QE0	
	10E	10 40	50	<b>&gt;</b>	3RB3026-1VB0		Α	3RB3026-1VE0	
Size S2									
S2	Devices with sci for mounting on	rew terminals (main o to contactor <sup>2)</sup>	current side) and		•				
	10E	12 50	250 N	EW A	3RB3036-1UB0		Α	3RB3036-1UD0	
	10E	20 80	250 N	EW A	3RB3036-1WB0		Α	3RB3036-1WD0	
	Devices with str installation	aight-through transf	ormer for stand-alor	те					
	10E	12 50	250 N	EW A	3RB3036-1UW1		Α	3RB3036-1UX1	
	10E	20 80	250 N	EW A	3RB3036-1WW1		Α	3RB3036-1WX1	

<sup>1)</sup> Maximum protection by fuse only for overload relay, type of coordination "2". Fuse values in connection with contactors, see Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load

Feeders "http://support.automation.siemens.com/WW/view/en/39714188.

<sup>2)</sup> With the appropriate terminal supports (see "Accessories", page 7/122), these overload relays can also be installed as stand-alone units.

### SIRIUS 3RB3 Electronic Overload Relays

### 3RB30, 3RB31 up to 80 A for standard applications

### 3RB30 electronic overload relays, CLASS 20E

Features and technical specifications:

- Connection methods
- Sizes S00 and S0:

Main and auxiliary circuit: Either screw or spring-type terminals

- Size S2:
- Main circuit: Screw terminals with box terminal or as straight-through transformer,
- auxiliary circuit: Either screw or spring-type terminals
- Overload protection, phase failure protection and unbalance protection
- Internal power supply
- Auxiliary contacts 1 NO + 1 NC

- Manual and automatic RESET
- Switch position indicator
- TEST function and self-monitoring
- Sealable covers (optional accessory)

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41G \end{array}$ 

3RB3016-	ITB0 3RB3026-1VB	3RB3036-1.B0	3RB3036-1.W1	3RB3016	-1TE0 3RB3026-1VE0	3RB30	36-1.	D0 3RB3036-1.X	K1
Size contactor <sup>2)</sup>	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>1)</sup>		Screw terminals	<b>+</b>	DT	Spring-type terminals	<u> </u>
					Article No.	Price per PU		Article No.	Price per PU
	CLASS	A	A			perro			perro
Size S00			2)						
S00		nting onto contactor							
	20E	0.1 0.4	4		3RB3016-2RB0		A	3RB3016-2RE0	
	20E	0.32 1.25	6		3RB3016-2NB0		A	3RB3016-2NE0	
	20E	1 4	20	<b>•</b>	3RB3016-2PB0		A	3RB3016-2PE0	
	20E	3 12	25		3RB3016-2SB0		A	3RB3016-2SE0	
0' 00	20E	4 16	25	<b>&gt;</b>	3RB3016-2TB0		Α	3RB3016-2TE0	
Size S0			2)						
S0		nting onto contactor							
	20E	0.1 0.4	4	<b>&gt;</b>	3RB3026-2RB0		Α.	3RB3026-2RE0	
	20E	0.32 1.25	6	•	3RB3026-2NB0		Α	3RB3026-2NE0	
	20E	1 4	20	•	3RB3026-2PB0		Α	3RB3026-2PE0	
	20E	3 12	25	•	3RB3026-2SB0		Α	3RB3026-2SE0	
	20E	6 25	50	<b>•</b>	3RB3026-2QB0		A	3RB3026-2QE0	
	20E	10 40	50	<u> </u>	3RB3026-2VB0		Α	3RB3026-2VE0	
Size S2									
S2	Devices with scr for mounting on	ew terminals (main d to contactor <sup>2)</sup>	current side) and						
	20E	12 50	250 N	EW A	3RB3036-2UB0		Α	3RB3036-2UD0	
	20E	20 80	250 N	EW A	3RB3036-2WB0		Α	3RB3036-2WD0	
	Devices with strainstallation	aight-through transf							
	20E	12 50	250 N	<i>EW</i> A	3RB3036-2UW1		Α	3RB3036-2UX1	
	20E	20 80	250	<i>EW</i> A	3RB3036-2WW1		Α	3RB3036-2WX1	

<sup>1)</sup> Maximum protection by fuse only for overload relay, type of coordination "2". Fuse values in connection with contactors, see Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders"

http://support.automation.siemens.com/WW/view/en/39714188.

<sup>2)</sup> With the appropriate terminal supports (see "Accessories", page 7/122), these overload relays can also be installed as stand-alone units.

### 3RB30, 3RB31 up to 80 A for standard applications

### 3RB31 electronic overload relays, CLASS 5E, 10E, 20E or 30E (adjustable)

Features and technical specifications:

- Connection methods
- Sizes S00 and S0:
  - Main and auxiliary circuit: Either screw or spring-type terminals
- Size S2:
  - Main circuit: Screw terminals with box terminal or as straight-through transformer,
  - auxiliary circuit: Either screw or spring-type terminals
- Overload protection, phase failure protection and unbalance protection
- Internal ground-fault detection (activatable)
- Internal power supply

- Auxiliary contacts 1 NO + 1 NC
- · Manual and automatic RESET
- Electrical remote RESET integrated
- · Switch position indicator
- TEST function and self-monitoring
- Sealable covers (optional accessory)

PU (UNIT, SET, M) = 1 PS\* = 1 unit PG = 41G

3RB3113-41	B0 3RB3123-4VB0	3RB3133-4.B0	3RB3133-4.W1 3F	RB3113-4TE	3RB3123-4VE0	3RB310	33-4.	DO 3RB3133-4.>	K1
Size contactor <sup>2)</sup>	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit protect with fuse, type of coordination "2", operational class g		Screw terminals	<b>+</b>	DT	Spring-type terminals	<u> </u>
	CLASS	A	Α		Article No.	Price per PU		Article No.	Price per PU
Size S00	02.100		7.						
S00	Devices for mour	nting onto contacto	or <sup>2)</sup>						
	5E, 10E, 20E or 30E	0.1 0.4	4	▶	3RB3113-4RB0		Α	3RB3113-4RE0	
	adjustable	0.32 1.25	6	▶	3RB3113-4NB0		Α	3RB3113-4NE0	
		1 4	20		3RB3113-4PB0		Α	3RB3113-4PE0	
		3 12	25		3RB3113-4SB0		Α	3RB3113-4SE0	
		4 16	25	▶	3RB3113-4TB0		Α	3RB3113-4TE0	
Size S0			2)						
S0		nting onto contacto					١.		
	5E, 10E, 20E or 30E adjustable		4		3RB3123-4RB0		Α	3RB3123-4RE0	
	adjustable	0.32 1.25	6		3RB3123-4NB0		A	3RB3123-4NE0	
		1 4	20		3RB3123-4PB0		A	3RB3123-4PE0	
		3 12 6 25	25 50		3RB3123-4SB0 3RB3123-4QB0		A A	3RB3123-4SE0 3RB3123-4QE0	
		10 40	50		3RB3123-4QB0 3RB3123-4VB0		A	3RB3123-4QE0 3RB3123-4VE0	
Size S2		10 40	30		3HD3123-4VD0		А	3HD3123-4VE0	
S2	Devices with scree	ew terminals (main o contactor <sup>2)</sup>	current side) and						
	5E, 10E, 20E or 30E	12 50	250	NEW A	3RB3133-4UB0		Α	3RB3133-4UD0	
	adjustable	20 80	250	NEW A	3RB3133-4WB0		Α	3RB3133-4WD0	
	Devices with strainstallation	ight-through transi	former for stand-al	one					
	5E, 10E, 20E or 30E	12 50	250	<b>VEW</b> A	3RB3133-4UW1		Α	3RB3133-4UX1	
	adjustable	20 80	250	<b>VEW</b> A	3RB3133-4WW1		Α	3RB3133-4WX1	

<sup>1)</sup> Maximum protection by fuse only for overload relay, type of coordination "2". Fuse values in connection with contactors, see Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders"

http://support.automation.siemens.com/WW/view/en/39714188.

<sup>2)</sup> With the appropriate terminal supports (see "Accessories", page 7/122), these overload relays can also be installed as stand-alone units.

### SIRIUS 3RB3 Electronic Overload Relays

### Accessories

### Overview

### Overload relays for standard applications

The following optional accessories are available for the 3RB30/3RB31 electronic overload relays:

- Size-specific terminal support for stand-alone installation, in sizes S00 and S0 also with spring-type terminals
- Mechanical RESET (for all sizes)
- Cable release for resetting devices which are difficult to access (for all sizes)
- Sealable cover (for all sizes)

### S

For separate mounting of the overload relays; S00 B Screw and snap-on mounting onto standard mounting rail  S0 B  S0 B  SRU2916-3AC01  1 1 unit 41F										
Terminal supports for stand-alone installation  Terminal supports for overload relays with screw terminals  For separate mounting of the overload relays; S00	Selection and	ordering data								
Terminal supports for overload relays; S00		Version	Size		DT	Article No.		(UNIT,	PS*	PG
terminals  For separate mounting of the overload relays; screw and snap-on mounting onto standard mounting rail  For separate mounting of the overload relays; screw and snap-on mounting onto standard so a surgest and snap-on mounting onto standard so a surgest and snap-on mounting onto standard so a surgest and snap-on mounting of the overload relays; screw and snap-on mounting onto standard mounting rail  Spring-type terminals  Spring-type terminals  For separate mounting of the overload relays; screw and snap-on mounting onto standard mounting rail  Spring-type terminals  Spring-type terminals  Spring-type terminals  Spring-type terminals  1 1 unit 41F  1 1 unit 41F  1 1 unit 41F	Terminal supp	orts for stand-alone installation								
screw and snap-on mounting onto standard so so sardy and snap-on mounting onto standard so so sometimes and snap-on mounting onto standard so so sometimes and snap-on mounting onto standard so so sometimes and snap-on mounting onto standard so						Screw terminals	<b>+</b>			
mounting rail  S2 Nat/ A  SRU2936-3AA01  Terminal supports for overload relays with spring-type terminals  For separate mounting of the overload relays; screw and snap-on mounting onto standard mounting rail  S2 Nat/ A  SRU2936-3AA01  Spring-type terminals  Spring-type terminals  Spring-type terminals  Spring-type terminals  Spring-type terminals  Spring-type terminals  SRU2916-3AC01  1 1 unit 41F  3RU2926-3AC01  1 1 unit 41F	000	For separate mounting of the overload relays;	S00		<b>&gt;</b>	3RU2916-3AA01		1	1 unit	41F
S2 NAM 3RU2936-3AA01 1 1 unit 41F  Terminal supports for overload relays with spring-type terminals  For separate mounting of the overload relays; screw and snap-on mounting onto standard mounting rail  Spring-type terminals  3RU2916-3AC01 1 1 unit 41F  3RU2926-3AC01 1 1 unit 41F  3RU2926-3AC01 1 1 unit 41F			S0		<b>&gt;</b>	3RU2926-3AA01		1	1 unit	41F
SRU2916-3AA01  Spring-type terminals  For separate mounting of the overload relays; S00 B screw and snap-on mounting onto standard mounting rail  SRU2926-3AA01  SRU2926-3AA01  SRU2926-3AA01	1111	mounting rail	S2	NEW	Α	3RU2936-3AA01		1	1 unit	41F
screw and snap-on mounting onto standard S0 B 3RU2926-3AC01 1 1 unit 41F	3RU2916-3AA01					Spring-type terminals	<u> </u>			
mounting rail 330 B 3802926-3AO1	0.102010 07101		S00		В	3RU2916-3AC01		1	1 unit	41F
	6 6 6		S0		В	3RU2926-3AC01		1	1 unit	41F
3702233-34401	3RU2926-3AA01									
	3NU2930-3AAU1									



3RU2916-3AC01



3RU2926-3AC01

and extension plunger

01102020 011001					4		
Mechanical RE	SET						
	Resetting plungers, holders and formers	S00 S2	<b>&gt;</b>	3RB3980-0A	1	1 unit	41F
<i>J</i> P:	Pushbuttons with extended stroke (12 mm), IP65, Ø 22 mm	S00 S2	В	3SB3000-0EA11	1	1 unit	41J
	Extension plungers For compensation of the distance between a pushbutton and the unlatching button of the relay	S00 S2	А	3SX1335	1	1 unit	41J
3RB3980-0A with pushbutton							

									Access	ories
	Version			Size	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Cable releases	with holder for RESI	ΞT								
3RB3980-0.	For Ø 6.5 mm holes in t max. control panel thic • Length 400 mm • Length 600 mm	the control panel; kness 8 mm		\$00 \$2 \$00 \$2	<b>&gt;</b>	3RB3980-0B 3RB3980-0C		1	1 unit 1 unit	41F 41F
Sealable covers	;									
3RB3984-0	For covering the setting	g knobs		S00 S2	•	3RB3984-0		1	1 unit	41F
General access	ories									
	Version	Size	Color	For overload relays	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Tools for opening	ng spring-type termi	nals								
	)					Spring-type terminals	$\stackrel{\circ}{\square}$			
3RA2908-1A	Screwdrivers For all SIRIUS devices with spring-type terminals	Length approx. 200 mm, 3.0 mm x 0.5 mm	Titanium gray/ black, partially insulated	Main and auxiliary circuit connection: 3RB3	A	3RA2908-1A		1	1 unit	41B
Blank labels	Unit labeling plates <sup>1)</sup>	20 mm v 7 mm	Pastel	3RB3	D	3RT1900-1SB20		100	240 unito	/1D
3RT1900-1SB20	for SIRIUS devices		turquoise						340 units	41B
3RT2900-1SB20  1) PC labeling system of unit labeling place.	ım for individual inscripti ates available from:	20 mm x 7 mm	Titanium gray	3RB3	D	3RT2900-1SB20		100	340 units	41B
murrplastik Syste		Partners").								

### More information

### Manuals

- System Manual "SIRIUS Innovations System Overview" http://support.automation.siemens.com/WW/view/en/60311318
- Manual "SIRIUS Innovations SIRIUS 3RU2/3RB3 Overload Relays"

  ANALL: (20000404)

http://support.automation.siemens.com/WW/view/en/60298164

### SIRIUS 3RB2 Electronic Overload Relays

### 3RB20, 3RB21 up to 630 A for standard applications

### Overview

### Note:

The 3RB20 and 3RB21 devices (sizes S00/S0 to S12) can be found

- in the Catalog Add-On IC 10 AO · 2015 at the Information and Download Center
- in the interactive catalog CA 01
- in the Industry Mall



- (1) Switch position indicator and TEST function of the wiring: Indicates a trip and enables the wiring test.
- 2 Trip class setting/internal ground-fault detection (only 3RB21): Using the rotary switch you can set the required trip class and activate the internal ground-fault detection dependent on the start-up conditions.
- (3) Solid-state test (device test): Enables a test of all important device components and functions.
- 4 Connecting terminals (removable terminal block for auxiliary circuits): The generously sized terminals permit connection of two conductors with different cross-sections for the main and auxiliary circuits. The auxiliary circuit can be connected with screw terminals and alternatively with spring-type terminals.
- (5) Selector switch for manual/automatic RESET: With the slide switch you can choose between manual and automatic RESET.
- Motor current setting:
   Setting the device to the rated motor current is easy with the large rotary knob.
- 7 A device set to manual RESET can be reset locally by pressing the RESET button. On the 3RB21 overload relay a solid-state remote RESET is integrated.
- (8) Connection for mounting onto contactors: Optimally adapted in electrical, mechanical and design terms to the contactors 3RT1. These connecting pins can be used for direct mounting of the overload relay to the contactor. Stand-alone installation is possible as an alternative (partly in conjunction with a terminal bracket for stand-alone installation).

SIRIUS 3RB2143-4ED0 electronic overload relay

The 3RB20 and 3RB21 electronic overload relays up to 630 A with internal power supply have been designed for inverse-time delayed protection of loads with normal and heavy starting ("Function", see Reference Manual

"Protection Equipment – 3RU1, 3RB2 Overload Relays" http://support.automation.siemens.com/WW/view/en/35681297) against excessive temperature rises due to overload, phase unbalance or phase failure.

An overload, phase unbalance or phase failure result in an increase of the motor current beyond the set rated motor current. This current rise is detected by the current transformers integrated into the devices and evaluated by corresponding solid-state circuits which then output a pulse to the auxiliary contacts. The auxiliary contacts then switch off the load by means of a contactor. The break time depends on the ratio between the tripping current and current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Curves" http://support.automation.siemens.com/WW/view/en/ 20357046/134300).

In addition to inverse-time delayed protection of loads against excessive temperature rises due to overload, phase unbalance and phase failure, the 3RB21 electronic overload relays also allow internal ground-fault detection (not possible in conjunction with contactor assemblies for wye-delta starting). This provides protection of loads against high-resistance short circuits due to damage to the insulation material, moisture, condensed water etc.

The "tripped" status is signaled by means of a switch position indicator. Resetting takes place either manually or automatically after the recovery time has elapsed ("Function", see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297).

The 3RB2 electronic overload relays are suitable for operation with frequency converters. Please follow the instructions in the Reference Manual "Protection Equipment – 3RU1 and 3RB2 Overload Relays", see

http://support.automation.siemens.com/WW/view/en/35681297.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

For 3RB30 and 3RB31 overload relay sizes S00 to S2, see page 7/119 onwards.

### Use in hazardous areas

The 3RB20/3RB21 electronic overload relays are suitable for the overload protection of motors with the following types of protection:

- 😥 II (2) G [Ex e] [Ex d] [Ex px]
- 🐼 II (2) D [Ex t] [Ex p]

EC type test certificate for Group II, Category (2) G/D exists. It has the number PTB 06 ATEX 3001.

### 3RB20, 3RB21 up to 630 A for standard applications

### Article No. scheme

mt 1: 4:1 A :1 I A:	4	4.1	E.1	0.1			0.1	0.11	4.0.1	4.44
Digit of the Article No.	1st - 3rd	4th	5th	6th	/th		8th	9th	10th	11th
						-				
Electronic overload relays	3 R B									
SIRIUS 2nd generation		2								
Device series										
Size, rated operational current and power										
Version of the automatic RESET, electrical remote RESET										
Trip class (CLASS)										
Setting range of the overload release										
Connection methods										
Installation type	-									
Example	3 R B	2	0	4	6	-	1	Q	В	0

### Note:

The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

### Benefits

The most important features and benefits of the 3RB20/3RB21 electronic overload relays are listed in the overview table (see "General Data", page 7/87 onwards).

### Application

### Industries

The 3RB20 and 3RB21 electronic overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed protection of their electrical loads (e.g. motors) under normal and heavy starting conditions (CLASS 5 to 30), minimize project completion times, inventories and energy consumption, and optimize plant availability and maintenance management.

### **Application**

The 3RB20 and 3RB21 electronic overload relays have been designed for the protection of three-phase motors in sinusoidal 50/60 Hz voltage networks. The relays are not suitable for the protection of single-phase AC or DC loads.

The 3RU11 thermal overload relays or the 3RB22 to 3RB24 solid-state overload relays can be used for single-phase AC loads. For DC loads we recommend the 3RU11 thermal overload relay.

### **Ambient conditions**

The devices are insensitive to external influences such as shocks, corrosive ambient conditions, ageing and temperature fluctuations.

For the temperature range from -25 C to +60 °C, the 3RB20 and 3RB21 electronic overload relays compensate the temperature in accordance with IEC 60947-4-1.

For the 3RB20 and 3RB21 electronic overload relays with the sizes S6, S10 and S12, the upper set value of the setting range must be reduced for ambient temperatures > 50 °C by a certain factor.

### SIRIUS 3RB2 Electronic Overload Relays

### 3RB20, 3RB21 up to 630 A for standard applications

### Technical specifications

The following technical information is intended to provide an initial overview of the various types of device and functions.

Detailed information, see Reference Manual "Protection Equipment - Overload Relays 3RU1, 3RB2", http://support.automation.siemens.com/WW/view/en/35681297

Type Size		<b>3RB2046, 3RB2143</b> S3	<b>3RB2056, 3RB2153</b> S6	<b>3RB2066, 3RB2163</b> S10/S12			
Dimensions (W x H x D) (overload relay with stand-alone installation support)	, mm	70 x 86 x 124	120 x 119 x 155	145 x 147 x 156			
General data							
Trips in the event of		Overload, phase failure, an	d nhasa unhalanca				
•		+ ground fault (for 3RB21 o					
Trip class acc. to IEC 60947-4-1	CLASS	3RB20: 10 or 20; 3RB21: 5, 10, 20 and 30 ad	ljustable				
Phase failure sensitivity		Yes					
Overload warning		No					
Reset and recovery							
Reset options after tripping		3RB20: Manual and automa 3RB21: Manual, automatic					
<ul><li>Recovery time</li><li>For automatic RESET</li></ul>		Approx. 3 min					
- For manual RESET		Immediately					
- For remote RESET		Immediately					
Features							
Display of operating state on device		Yes, by means of switch po	sition indicator slide				
TEST function		Yes, test of electronics by p test of auxiliary contacts an indicator slide/self-monitoria	d wiring of control circuit by	actuating the switch position			
RESET button		Yes					
STOP button		No					
Protection and operation of explosion-proof motors							
EC type test certificate number according to		PTB 06 ATEX 3001					
directive 94/9/EC (ATEX)		€ II (2) G [Ex e] [Ex d] [Ex	(px]				
		⟨ II (2) G [Ex t] [Ex p]					
		see http://support.automatic	on.siemens.com/WW/view/e	n/23814648			
Ambient temperatures							
Storage/transport	°C	-40 +80					
Operation	°C	-25 +60					
Temperature compensation	°C	+60					
<ul> <li>Permissible rated current at</li> <li>Temperature inside control cabinet 60 °C, stand-alone installation</li> </ul>	%	100	100	100 or 90 <sup>1)</sup>			
Temperature inside control cabinet 60 °C, mounted on contactor	%	100	70	70			
- Temperature inside control cabinet 70 °C	%	On request					
Degree of protection acc. to IEC 60529		IP20	IP20				
			(terminal compartment: I	P00 degree of protection)			
Touch protection acc. to IEC 61140		Finger-safe for vertical contact from the front	Finger-safe; for busbar connection wit cover	Finger-safe th with cover			
Shock resistance with sine acc. to IEC 60068-2-27	g/ms	15/11 (signaling contact 97	/98 in position "tripped": 4 g	/11 ms)			
Electromagnetic compatibility (EMC) - Interference immunity							
Conductor-related interference							
- Burst acc. to IEC 61000-4-4 (corresponds to degree of severity 3) - Surge acc. to IEC 61000-4-5	kV kV	2 (power ports), 1 (signal p 2 (line to earth), 1 (line to line	,				
(corresponds to degree of severity 3)  • Electrostatic discharge according to IEC 61000-4-2	kV	8 (air discharge), 6 (contac	,				
(corresponds to degree of severity 3)  • Field-related interference acc. to IEC 61000-4-3	V/m	10					
(corresponds to degree of severity 3)	.,						
Electromagnetic compatibility (EMC) – emitted interference		Degree of severity B acc. to	EN 55011 (CISPR 11) and	EN 55022 (CISPR 22)			
Resistance to extreme climates – air humidity	%	100					
Dimensions		"Dimensional drawings", see Reference Manual "Protection Equipment - Overload Relays 3RU1, 3RB2", http://support.automation.siemens.com/WW/view/en/35681297					
Installation altitude above sea level	m	Up to 2 000					
Mounting position		Any					
Type of mounting		Direct mounting/stand-aloninstallation with terminal support	e Direct mounting/stand-ale	one installation			

 $<sup>^{\</sup>rm 1)}$  90 % for relay with current setting range 160 A to 630 A.

### 3RB20, 3RB21 up to 630 A for standard applications

Туре		3RB2046, 3RB2143
Size		S3
Main circuit		
Rated insulation voltage $U_{\rm i}$ (pollution degree 3)	V	1 000
Rated impulse withstand voltage $U_{\rm imp}$	kV	8
Rated operational voltage U <sub>e</sub>	V	1 000
Type of current		
Direct current		No
Alternating current		Yes, 50/60 Hz ± 5 %
Current setting	Α	12.5 50, 25 100
Power loss per unit (max.)	W	0.05
Short-circuit protection		
With fuse without contactor		See "Selection and ordering data" on pages 7/130 to 7/132
With fuse and contactor		"Short-Circuit Protection with Fuses/Motor Starter Protectors for Motor Feeders", see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297 → "Technical Specifications" → "Short-Circuit Protection with Fuses for Motor Feeders"
Protective separation between main and auxiliary current paths acc. to IEC 60947-1 (pollution degree 2)		
For systems with grounded neutral point	V	690
For systems with ungrounded neutral point	V	600
Conductor cross-sections of the main circuit		
Connection type		Screw terminals with box terminal
Terminal screw		M8, 4 mm Allen screw
Operating devices	mm	4 mm Allen screw
Prescribed tightening torque	Nm	4 6
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
• Solid	mm <sup>2</sup>	2 × (2.5 16)
Finely stranded without end sleeve	mm <sup>2</sup>	
Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 × (2.5 35) <sup>1)</sup> , 1 × (2.5 50) <sup>1)</sup>
Stranded	mm <sup>2</sup>	$2 \times (10 \dots 50)^{1},$ $1 \times (10 \dots 70)^{1}$
AWG cables, solid or stranded	AWG	$2 \times (10 \dots 1/0)^{1}$ , $1 \times (10 \dots 2/0)^{1}$
Ribbon cables (Number x Width x Thickness)	mm	$2 \times (6 \times 9 \times 0.8)$
Connection type		oo Busbar connections
Terminal screw		M6 × 20
Prescribed tightening torque	Nm	4 6
Conductor cross-sections (min./max.)	_	
Finely stranded with cable lug	mm <sup>2</sup>	2 × 70
Stranded with cable lug	mm <sup>2</sup>	3 × 70
<ul> <li>AWG cables, solid or stranded, with cable lug</li> </ul>	AWG	2/0
With connecting bars (max. width)	mm	12
Connection type		Straight-through transformers
Diameter of opening	mm	18

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

7/127

### SIRIUS 3RB2 Electronic Overload Relays

### 3RB20, 3RB21 up to 630 A for standard applications

Туре		3RB2056, 3RB2153	3RB2066, 3RB2163
Size		S6	S10/S12
Main circuit	\ /	1.000	
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	1 000	
Rated impulse withstand voltage U <sub>imp</sub>	kV V	8	
Rated operational voltage U <sub>e</sub>	V	1 000	
Type of current		No	
<ul><li>Direct current</li><li>Alternating current</li></ul>		Yes, 50/60 Hz ± 5 %	
Current setting	Α	50 200	55 250,
			160 630
Power loss per unit (max.)	W	0.05	
Short-circuit protection			
With fuse without contactor     With fuse and contactor		See Reference Manual "Protection Equ	otor Starter Protectors for Motor Feeders" sipment – 3RU1, 3RB2 Overload Relays", n/WW/view/en/35681297 → "Technical"
Protective separation between main and auxiliary current paths acc. to IEC 60947-1 (pollution degree 2)	;		
For systems with grounded neutral point     For systems with ungrounded neutral point	V V	690	
For systems with ungrounded neutral point     Conductor cross-sections of the main circuit	V	600	
Connection type		Screw terminals with box term	inal
		Screw terminals with box term	
Terminal screw	mm	4 mm Allen screw	5 mm Allen screw
Operating devices	mm	4 mm Allen screw	5 mm Allen screw
Prescribed tightening torque	Nm	1 12	20 22
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected			
<ul><li>Solid</li><li>Finely stranded without end sleeve</li></ul>	mm <sup>2</sup> mm <sup>2</sup>	With 3RT1955-4G box terminal:	 2 × (50 185),
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 × (1 × max. 50, 1 × max. 70), 1 × (10 70); With 3RT1956-4G box terminal: 2 × (1 × max. 95, 1 × max. 120), 1 × (10 120) With 3RT1955-4G box terminal: 2 × (1 × max. 50, 1 × max. 70), 1 × (10 70); With 3RT1956-4G box terminal:	Rear clamping point only: 1 × (70 240); rear clamping point only: 1 × (120 185) 2 × (50 185), Rear clamping point only: 1 × (70 240); rear clamping point only:
• Stranded	mm <sup>2</sup>	2 × (1 × max. 95, 1 × max. 120), 1 × (10 120) With 3RT1955 -4G box terminal: 2 × (max. 70), 1 × (16 70); With 3RT1956-4G box terminal: 2 × (max. 120),	1 × (120 185)  2 × (70 240),  Rear clamping point only:  1 × (95 300);  rear clamping point only:  1 × (120 240)
AWG cables, solid or stranded	AWG	1 × (16 120) With 3RT1955-4G box terminal: 2 × (max. 1/0), 1 × (6 2/0); With 3RT1956-4G box terminal: 2 × (max. 3/0), 1 × (6 250 (comit))	$2 \times (2/0 \dots 500 \text{ kcmil}),$ rear clamping point only: $1 \times (3/0 \dots 600 \text{ kcmil});$ rear clamping point only: $1 \times (250 \text{ kcmil} \dots 500 \text{ kcmil})$
Ribbon cables (Number x Width x Thickness)	mm	$1 \times (6 \dots 250 \text{ kcmil})$ With 3RT 1955-4G box terminal: $2 \times (6 \times 15.5 \times 0.8)$ , $1 \times (3 \times 9 \times 0.8 \dots 6 \times 15.5 \times 0.8)$ ; With 3RT 1956-4G box terminal: $2 \times (10 \times 15.5 \times 0.8)$ , $1 \times (3 \times 9 \times 0.8 \dots 10 \times 15.5 \times 0.8)$	$2 \times (20 \times 24 \times 0.5),$ $1 \times (6 \times 9 \times 0.8 \dots 20 \times 24 \times 0.5)$
Connection type		oo Busbar connections	
Terminal screw		M8 × 25	M10 × 30
Prescribed tightening torque	Nm	10 14	14 24
Conductor cross-sections (min./max.)	LALLI	10 17	1127
Finely stranded with cable lug Stranded with cable lug AWG cables, solid or stranded, with cable lug With connecting bars (max. width)	mm <sup>2</sup> mm <sup>2</sup> AWG mm	16 95 <sup>1)</sup> 25 120 <sup>1)</sup> 4 250 kcmil	50 240 <sup>2)</sup> 70 240 <sup>2)</sup> 2/0 500 kcmil 25
Connection type		Straight-through transformers	
Diameter of opening	mm	24.5	
<ol> <li>When connecting cable lugs according to DIN 46235 with condu</li> </ol>			cording to DIN 46234 with conductor

When connecting cable lugs according to DIN 46235 with conductor cross-sections of 95 mm<sup>2</sup> and more, the 3RT1956-4EA1 terminal cover must be used to ensure phase clearance.

When connecting cable lugs according to DIN 46234 with conductor cross-sections of 240 mm<sup>2</sup> and more as well as to DIN 46235 with conductor cross-sections of 185 mm<sup>2</sup> and more, the 3RT1956-4EA1 terminal cover must be used to ensure the phase clearance.

### 3RB20, 3RB21 up to 630 A for standard applications

Tune		2DD2046 2DD2446	appane appare	appage appage
Type Sizo		3RB2046, 3RB2143	3RB2056, 3RB2153	3RB2066, 3RB2163
Size Auxiliary circuit		S3	S6	S10/S12
Auxiliary circuit		1		
Number of NC contacts  Number of NC contacts		1		
Auxiliary contacts – assignment		<ul><li>1 NO for the signal "trip</li><li>1 NC for disconnecting</li></ul>		
Rated insulation voltage $U_i$ (pollution degree 3)	V	300		
Rated impulse withstand voltage $U_{imp}$	kV	4		
• NC contacts – contact rating  • NC contact with alternating current AC-14/AC-15, rated operational current $I_e$ at $U_e$ :  - 24 V  - 120 V  - 125 V  - 250 V	A A A	4 4 4 3		
NO contact with alternating current AC-14/AC-15, rated operational current $I_{\rm e}$ at $U_{\rm e}$ :    - 24 V    - 120 V    - 125 V    - 250 V	A A A	4 4 4 3		
• NC contact, NO contact with direct current DC-13, rated operational current $I_{\rm e}$ at $U_{\rm e}$ :   - 24 V   - 60 V   - 110 V   - 125 V   - 250 V	A A A A	2 0.55 0.3 0.11		
Conventional thermal current $I_{th}$	A	5		
Contact reliability (suitability for PLC control; 17 V, 5 mA)		Yes		
Short-circuit protection				
With fuse, operational class gG	А	6		
Ground-fault protection (only 3RB21)			to sinusoidal residual ci	urrents at 50/60 Hz.
$ullet$ Tripping value $I_{\Lambda}$		$> 0.75 \times I_{\text{motor}}$		
• Operating range <i>I</i>			value $< I_{ m motor} < 3.5  imes  m uz$	oper current setting value
• Response time $t_{trip}$ (in steady-state condition)	S	< 1		
Integrated electrical remote RESET (only 3RB21)				
Connecting terminals A3, A4		24 V DC, 100 mA, 2.4	W short-term	
Protective separation between auxiliary current paths acc. to IEC 609	47-1 V	300		
CSA, UL, UR rated data				
Auxiliary circuit – switching capacity		B300, R300		
Conductor cross-sections of the auxiliary circuit				
Connection type		Screw terminals	3	
Terminal screw		M3, Pozidriv size 2		
Operating devices	mm	Ø 5 6		
Prescribed tightening torque	Nm	0.8 1.2		
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected				
Solid and stranded	mm <sup>2</sup>	$1 \times (0.5 \dots 4)^{1)}, 2 \times (0.5 \dots 4)^{1}$	5 2.5) <sup>1)</sup>	
Finely stranded without end sleeve	mm <sup>2</sup>			
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	1 × (0.5 2.5) <sup>1)</sup> , 2 × (	0.5 1.5) <sup>1)</sup>	
AWG cables, solid or stranded		2 × (20 14)		
Connection type		Spring-type terr	ninals	
Operating devices	mm	3.0 x 0.5		
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected				
Solid and stranded	mm <sup>2</sup>	2 × (0.25 1.5)		
Finely stranded without end sleeve	mm <sup>2</sup>			
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 × (0.25 1.5)		
AWG cables, solid or stranded		2 × (24 16)		
1) If two different conductor areas sections are connected to one element	🗸	/		

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

### SIRIUS 3RB2 Electronic Overload Relays

### 3RB20, 3RB21 up to 630 A for standard applications

### Selection and ordering data

### 3RB20 electronic overload relays for mounting onto contactors and stand-alone installation, CLASS 10

Features and technical specifications:

- · Connection methods
- Size S3

Main circuit: Busbar connection with box terminal or as straight-through transformer,

auxiliary circuit: Either screw or spring-type terminals

Main circuit: With busbar connection or as straight-through transformer,

auxiliary circuit: Either screw or spring-type terminals

Sizes S10/S12:

Main circuit: With busbar connection, auxiliary circuit: Either screw or spring-type terminals

- · Overload protection, phase failure protection and unbalance protection
- Internal power supply
- Auxiliary contacts 1 NO + 1 NC
- · Manual and automatic RESET
- Switch position indicator
- TEST function and self-monitoring

PU(UNIT, SET, M) = 1= 1 unit PG = 41G






160

Current setting value

of the inverse-time

delayed overload





(on auxiliary current side)	₩
Article No.	Price



2		0	_

### Devices with screw terminals, for mounting onto contactor

10 12.5 ... 50 S3

CLASS

315 25 ... 100 Devices with straight-through transformer,

for stand-alone installation

10	25 100	315

3RB2046-1UB0 Α 3RB2046-1UD0 3RB2046-1EB0 3RB2046-1ED0

3RB2046-1EW1 3RB2046-1EX1

### Size S6

### Devices with connecting bar,

for mounting onto contactor and stand-alone installation 50 ... 200

Devices with straight-through transformer,

for mounting onto contactor and stand-alone installation For mounting 50 ... 200 onto S6 contactors with

<b>&gt;</b>	3RB2056-1FC2

3RB2056-1FF2

3RB2056-1FW2 3RB2056-1FX2

### box terminals Size S10/S12

### Devices with connecting bar,

### for mounting onto contactor and stand-alone installation

S10/S12 10 55 ... 250 400 and size 14 10 160 ... 630 800 (3TF68/ 3TF69)<sup>2)</sup>

<b>&gt;</b>	3RB2066-1GC2	<b></b>	3RB2066-1GF2
<b>&gt;</b>	3RB2066-1MC2	▶	3RB2066-1MF2

<sup>-1</sup>MF2 2) For 3TF68/3TF69 contactors, direct mounting is not possible.

<sup>1)</sup> Maximum protection by fuse only for overload relay, type of coordination "2". For fuse values in connection with contactors, see the Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297 "Technical Specifications" → "Short-Circuit Protection with Fuses for Motor Feeders".

### 3RB20, 3RB21 up to 630 A for standard applications


### 3RB20 electronic overload relays for mounting onto contactors and stand-alone installation, CLASS 20

Features and technical specifications:

- Connection methods
- Size S3
  - Main circuit: Busbar connection with box terminal or as straight-through transformer,
- auxiliary circuit: Either screw or spring-type terminals
- Size Se
  - Main circuit: With busbar connection or as straight-through transformer.
- auxiliary circuit: Either screw or spring-type terminals
- Sizes S10/S12:
- Main circuit: With busbar connection,
- auxiliary circuit: Either screw or spring-type terminals

- Overload protection, phase failure protection and unbalance protection
- Internal power supply
- Auxiliary contacts 1 NO + 1 NC
- · Manual and automatic RESET
- Switch position indicator
- TEST function and self-monitoring

PU (UNIT, SET, M) = 1 PS\* = 1 unit PG = 41G



# 1) Maximum protection by fuse only for overload relay, type of coordination "2". For fuse values in connection with contactors, see the Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297 → "Technical Specifications" → "Short-Circuit Protection with Fuses for

Motor Feeders".

<sup>2)</sup> For 3TF68/3TF69 contactors, direct mounting is not possible.

### SIRIUS 3RB2 Electronic Overload Relays

### 3RB20, 3RB21 up to 630 A for standard applications

### 3RB21 electronic overload relays for mounting onto contactors and stand-alone installation. CLASS 5, 10, 20 and 30 adjustable

Features and technical specifications:

- · Connection methods
  - Size S3

Main circuit: Busbar connection with box terminal or as straight-through transformer,

auxiliary circuit: Either screw or spring-type terminals

- Size S6
- Main circuit: With busbar connection or as straight-through transformer,
- auxiliary circuit: Either screw or spring-type terminals
- Sizes S10/S12:
- Main circuit: With busbar connection,
- auxiliary circuit: Either screw or spring-type terminals

- · Overload protection, phase failure protection and unbalance protection
- Internal ground-fault detection (activatable)
- Internal power supply
- Auxiliary contacts 1 NO + 1 NC
- · Manual and automatic RESET
- Electrical remote RESET integrated
- Switch position indicator
- TEST function and self-monitoring

PU(UNIT, SET, M) = 1PS\* = 1 unit PG = 41G





Size contactor Trip class



Short-circuit protection with fuse,

160

315

type of coordina-

tion "2", operational class gG<sup>1)</sup>

3RB2153-4FX2

Current setting value

of the inverse-time

delayed overload

release

Α



DT	Screw terminals (on auxiliary current side)	<b>(1)</b>	DT	Spring-type terminals (on auxiliary current side)	
	Article No.	Price per PU		Article No.	Price per PU

### Devices with screw terminals, for mounting onto contactor

CLASS

S3 5, 10, 20 and 30

12.5 ... 50 adjustable S3 25 ... 100

Devices with straight-through transformer,

S3	▶	3RB2143-4EW1	▶	3RB2143-4EX1
ioi stand-alone instanation				

### Size S6

### Devices with connecting bar,

for mounting onto contactor and stand-alone installation

5, 10, 20 and 30 50 ... 200 3RB2153-4FC2 3RB2153-4FF2 adjustable Devices with straight-through transformer,

### for mounting onto contactor and stand-alone installation

For mounting 5, 10, 20 and 30 onto S6 conadjustable

tactors with box terminals

3RB2153-4FW2

3RB2143-4UB0

3RB2143-4EB0

3RB2153-4FX2

3RB2143-4UD0

3RB2143-4ED0

### Size S10/S12<sup>2)</sup>

### Devices with connecting bar, for mounting onto contactor and stand-alone installation

S10/S12 5, 10, 20 and 30 55 ... 250 400 and size 14 adjustable 160 ... 630 800 (3TF68/ 3TF69)<sup>2)</sup>

1) Maximum protection by fuse only for overload relay, type of coordination "2". For fuse values in connection with contactors, see the Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297 → "Technical Specifications" → "Short-Circuit Protection with Fuses for Motor Feeders".

3RB2163-4GC2 3RB2163-4GF2 3RB2163-4MC2 3RB2163-4MF2

<sup>2)</sup> For 3TF68/3TF69 contactors, direct mounting is not possible.

Accessories for 3RB20, 3RB21

### Overview

### Overload relays for standard applications

The following optional accessories are available for the 3RB20 and 3RB21 electronic overload relays:

• Mechanical RESET (for all sizes)

- Cable release for resetting devices which are difficult to access (for all sizes)
- Sealable cover (for all sizes)
- Terminal covers for sizes S3 to S10/S12
- Box terminal blocks for sizes S6 and S10/S12

Selection	and	ordering	data
-----------	-----	----------	------

	Version	Size	DT	Article No. Pric		PS*	PG
Mechanical RESE	т						
<b></b>	Resetting plungers, holders and formers	S3 S10/S12	<b>&gt;</b>	3RU1900-1A	1	1 unit	41F
	Pushbuttons with extended stroke (12 mm), IP65, Ø 22 mm	S3 S10/S12	В	3SB3000-0EA11	1	1 unit	41J
	Extension plungers For compensation of the distance between a pushbutton and the unlatching button of the relay	S3 S10/S12	А	3SX1335	1	1 unit	41J
3RU1900-1A with pushbutton and extension plunger							
Cable releases wi	th holder for RESET						
A	For Ø 6.5 mm holes in the control panel; max. control panel thickness 8 mm	S3 S10/S12					
	• Length 400 mm		<b>&gt;</b>	3RU1900-1B	1	1 unit	41F
	• Length 600 mm		•	3RU1900-1C	1	1 unit	41F
3RU1900-1.							
Sealable covers							
0.0	For covering the setting knobs	S3 S10/S12	<b>&gt;</b>	3RB2984-0	1	10 units	41F
3RB2984-0							
Terminal covers							
Broth 11 -	Covers for cable lugs and busbar connections						
- ending	Length 55 mm	S3	В	3RT1946-4EA1	1	1 unit	41B
SIEMENS	Length 100 mm	S6	<b>&gt;</b>	3RT1956-4EA1	1	1 unit	41B
and the same of th	Length 120 mm	S10/S12	<b>&gt;</b>	3RT1966-4EA1	1	1 unit	41B
	Covers for box terminals						
3RT1956-4EA1	• Length 20.8 mm	S3	<b>•</b>	3RT1946-4EA2	1	1 unit	41B
100	• Length 25 mm	S6	<b>•</b>	3RT1956-4EA2	1	1 unit	41B
SIEMENS	Length 30 mm  Covers for screw terminals	S10/S12 S6	<b>&gt;</b>	3RT1966-4EA2 3RT1956-4EA3	1	1 unit 1 unit	41B 41B
3RT1956-4EA2	between contactor and overload relay, without box terminals (1 unit required per combination)	S10/S12	•	3RT1966-4EA3	1	1 unit	41B
Box terminal bloc	ks						
	For round and ribbon cables	4)					
n n	• Up to 70 mm <sup>2</sup>	S6 <sup>1)</sup>	<b>&gt;</b>	3RT1955-4G	1	1 unit	41B
	• Up to 120 mm <sup>2</sup>	S6	<b>&gt;</b>	3RT1956-4G	1	1 unit	41B
	• Up to 240 mm <sup>2</sup>	S10/S12	<b></b>	3RT1966-4G	1	1 unit	41B
3RT1954G	For technical specifications for conductor cross-sec Reference Manual "Protection Equipment – 3RU1, 3F Relays", http://support.automation.siemens.com/WW/view/en	RB2 Overload	d				

<sup>1)</sup> In the scope of supply for 3RT1054-1 contactors (55 kW).

### Accessories for 3RB20, 3RB21


### General accessories

	Version	Size	Color	For over- load relays	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Tools for opening	spring-type termin	als								
						Spring-type terminals	$\stackrel{\infty}{\square}$			
3RA2908-1A	Screwdrivers For all SIRIUS devices with spring-type terminals	Length approx. 200 mm, 3.0 mm x 0.5 mm	Titanium gray/ black, partially insulated	Main and auxiliary circuit connection: 3RB2	A	3RA2908-1A		1	1 unit	41B
Blank labels										
	Unit labeling plates <sup>1)</sup> for SIRIUS devices	20 mm x 7 mm	Pastel turquoise	3RB2	D	3RT1900-1SB20		100	340 units	41B
		20 mm x 7 mm	Titanium gray	3RB2	D	3RT2900-1SB20		100	340 units	41B
0_01429b	Adhesive inscription labels 1)	19 mm x 6 mm	Pastel turquoise	3RB2	С	3RT1900-1SB60		100	3 060 units	41B
3RT1900-1SB20	For SIRIUS devices	19 mm x 6 mm	Zinc yellow	3RB2	С	3RT1900-1SD60		100	3 060 units	41B
3RT2900-1SB20										

PC labeling system for individual inscription of unit labeling plates available from: murrplastik Systemtechnik GmbH (see Chapter 16, "Appendix" → "External Partners").

### 3RB22, 3RB23 up to 630 A for High-Feature applications

### Overview



- 1 3RB2985 function expansion module: Enables more functions to be added, e.g. internal ground-fault detection and/or an analog output with corresponding signals.
- 2 Motor current and trip class setting: Setting the device to the motor current and to the required trip class dependent on the start-up conditions is easy with the two rotary switches
- 3 Connecting terminals (removable joint block): The generously sized terminals permit connection of two conductors with different cross-sections for the auxiliary, control and sensor circuits. Connection is possible with screw connection and alternatively with spring-type connection.
- Test/RESET button:
   Enables testing of all important device components and functions, plus resetting of the device after a trip when manual RESET is selected.
- (5) Selector switch for manual/automatic RESET: With this switch you can choose between manual and automatic RESET:
- Red LED "OVERLOAD":
   A continuous red light signals an active overload trip; a flickering red light signals an imminent trip (overload warning).
- 7 Red LED "THERMISTOR": A continuous red light signals an active thermistor trip.
- 8 Red LED "GND FAULT": A continuous red light signals a ground-fault tripping.
- Green LED "READY":
   A continuous green light signals that the device is working correctly.

### SIRIUS 3RB22 and 3RB23 evaluation modules

the set rated motor current.

The 3RB22 and 3RB23 electronic overload relays up to 630 A (up to 820 A possible in combination with a series transformer) are from a modular system and comprise an evaluation unit, a current measuring module and a connecting cable. The 3RB22 overload relays (with monostable auxiliary contacts)

The 3RB22 overload relays (with monostable auxiliary contacts) and the 3RB23 overload relays (with bistable auxiliary contacts) are supplied from an external voltage.

These units have been designed for inverse-time delayed protection of loads with normal and heavy starting ("Function", see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297) against excessive temperature rises due to overload, phase unbalance or phase failure. An overload, phase unbalance or

This current rise is detected by means of a current measuring module (see page 7/152) and electronically evaluated by the evaluation module which is connected to it. The evaluation electronics sends a signal to the auxiliary contacts. The auxiliary

phase failure result in an increase of the motor current beyond

The break time depends on the ratio between the tripping current and current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Curves" http://support.automation.siemens.com/WW/view/en/20357046/134300).

contacts then switch off the load by means of a contactor.

The "tripped" status is signaled by means of a continuous red "OVERLOAD" LED.

The LED indicates imminent tripping of the relay due to overload, phase unbalance or phase failure by flickering when the limit current has been violated. In the case of the 3RB22 and 3RB23 overload relays this warning can also be issued through auxiliary contacts.

In addition to the described inverse-time delayed protection of loads against excessive temperature rises, the 3RB22 and 3RB23 electronic overload relays also allow direct temperature monitoring of the motor windings (full motor protection) by connection with broken-wire interlock of a PTC sensor circuit. With this temperature-dependent protection, the loads can be protected against overheating caused indirectly by reduced coolant flow, for example, which cannot be detected by means of the current alone. In the event of overheating, the devices switch off the contactor, and thus the load, by means of the auxiliary contacts. The "tripped" status is signaled by means of a continuously illuminated "THERMISTOR" LED.

To protect the loads against high-resistance short circuits due to damage to the insulation, humidity, condensed water, etc., the 3RB22 and 3RB23 electronic overload relays offer the possibility of internal ground-fault detection in conjunction with a function expansion module (for details, see Reference Manual "Protection Equipment - Overload Relays 3RU1, 3RB2", http://support.automation.siemens.com/WW/view/en/35681297, not possible in conjunction with contactor assemblies for wye-delta starting). In the event of a ground fault the 3RB22 and 3RB23 relays trip instantaneously.

The "tripped" status is signaled by means of a continuous red "Ground Fault" LED. Signaling through auxiliary contacts is also possible.

After tripping due to overload, phase unbalance, phase failure, thermistor or ground-fault tripping, the relay is reset manually or automatically after the recovery time has elapsed ("Function", see Reference Manual

"Protection Equipment – 3RU1, 3RB2 Overload Relays" http://support.automation.siemens.com/WW/view/en/35681297). In conjunction with a function expansion module, the motor current measured by the microprocessor can be output in the form of an analog signal DC 4 mA to 20 mA for operating rotary coil instruments or for feeding into analog inputs of programmable logic controllers.

With an additional AS-Interface analog module the current values can also be transferred over the AS-i bus system.

The 3RB2 electronic overload relays are suitable for operation with frequency converters. Please follow the instructions in the Reference Manual "Protection Equipment – 3RU1 and 3RB2 Overload Relays", see

http://support.automation.siemens.com/WW/view/en/35681297.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

### Use in hazardous areas

The 3RB22 electronic overload relays (monostable) with the 3RB29 current measuring module are suitable for the overload protection of explosion-proof motors.

EC type test certificate for Category (2) G/D exists. It has the number PTB 05 ATEX 3022.

### SIRIUS 3RB2 Electronic Overload Relays

### 3RB22, 3RB23 up to 630 A for High-Feature applications

### Article No. scheme

Digit of the Article No.	1st - 3rd	1+h	5th	Gth	7+h		8th	Oth	10th	1 1+h	
Digit of the Article No.										1 1111	
						-					
Electronic overload relays	3 R B										
SIRIUS 2nd generation		2									
Device series											
Size, rated operational current and power											
Version of the automatic RESET, electrical remote RESET											
Trip class (CLASS)											
Setting range of the overload release											
Connection methods											
Installation type											
Example	3 R B	2	2	8	3	-	4	Α	Α	1	

### Note:


The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

### Benefits

The most important features and benefits of the 3RB22 and 3RB23 electronic overload relays are listed in the overview table (see "General Data", page 7/87 onwards).

### Advantages through energy efficiency



Overview of the energy management process

We offer you a unique portfolio for industrial energy management, using an energy management system that helps to optimally define your energy needs. We split up our industrial energy management into three phases – identify, evaluate, and realize – and we support you with the appropriate hardware and software solutions in every process phase.

The innovative products of the SIRIUS industrial controls portfolio can also make a substantial contribution to a plant's energy efficiency (see www.siemens.com/sirius/energysaving).

3RB22 and 3RB23 electronic overload relays contribute to energy efficiency throughout the plant as follows:

- Reduced inherent power loss
- Less heating of the control cabinet
- Smaller control cabinet air conditioners can be used

### Application

### Industries

The 3RB22 and 3RB23 electronic overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed and temperature-dependent protection of their electrical loads (e.g. motors) under normal and heavy starting conditions (CLASS 5 to 30), minimize project completion times, inventories and energy consumption, and optimize plant availability and maintenance management.

### Application

The 3RB22 and 3RB23 devices have been designed for the protection of three-phase asynchronous and single-phase AC motors.

If single-phase AC motors are to be protected by the 3RB22 and 3RB23 electronic overload relays, the main current paths of the current measuring modules must be series-connected ("Circuit Diagrams", see Reference Manual

"Protection Equipment - 3RU1, 3RB2 Overload Relays "http://support.automation.siemens.com/WW/view/en/35681297).

### Ambient conditions

The devices are insensitive to external influences such as shocks, corrosive ambient conditions, ageing and temperature fluctuations.

For the temperature range from  $-25\,^{\circ}\text{C}$  to  $+60\,^{\circ}\text{C}$ , the 3RB22 and 3RB23 electronic overload relays compensate the temperature in accordance with IEC 60947-4-1.

Configuration notes for use of the devices below –25  $^{\circ}\text{C}$  or above +60  $^{\circ}\text{C}$  on request.

3RB22, 3RB23 up to 630 A for High-Feature applications

### Technical specifications

The following technical information is intended to provide an initial overview of the various types of device and functions.

Detailed information, see

- Reference Manual "Protection Equipment 3RU1, 3RB2 Overload Relays",
  - http://support.automation.siemens.com/WW/view/en/35681297
- or specific information on a particular article number via the product data sheet. 00

product data cricot,	
http://support.automation.siemens.com/WW/vie	w/en/20357046/133200

Type – Overload relay: evaluation modules		3RB2283-4A.1 3RB2383-4A.1
Size contactor	₫	S00 S10/S12
Dimensions of evaluation modules (W x H x D)	<b>y</b> mm	45 x 111 x 95
General data		
Trips in the event of		Overload, phase failure and phase unbalance (> 40 % according to NEMA), + ground fault (with corresponding function expansion module) and activation of the thermistor motor protection (with closed PTC sensor circuit)
Trip class acc. to IEC 60947-4-1	CLASS	5, 10, 20 and 30 adjustable
Phase failure sensitivity		Yes
Overload warning		Yes, from 1.125 x $I_{\rm e}$ for symmetrical loads and from 0.85 x $I_{\rm e}$ for unsymmetrical loads
Reset and recovery		
Reset options after tripping		Manual, automatic and remote RESET
Recovery time     For automatic RESET	min.	- for tripping due to overcurrent: 3 (stored permanently) - for tripping by thermistor: time until the motor temperature has fallen 5 K below the response temperature
- For manual RESET	min.	<ul> <li>for tripping due to a ground fault: no automatic RESET</li> <li>for tripping due to overcurrent: 3 (stored permanently)</li> <li>for tripping by thermistor: time until the motor temperature has fallen 5 K below the response temperature</li> <li>for tripping due to a ground fault: Immediately</li> </ul>
- For remote RESET	min.	- for tripping due to a ground radic. Immediately - for tripping due to overcurrent: 3 (stored permanently) - for tripping by thermistor: time until the motor temperature has fallen 5 K below the response temperature - for tripping due to a ground fault: Immediately
Features		
Display of operating state on device		Yes, with four LEDs: - green LED "Ready" - red LED "Ground Fault" - red LED "Thermistor" - red LED "Overload"
TEST function		Yes, test of LEDs, electronics, auxiliary contacts and wiring of control circuit by pressing the button TEST/RESET / self-monitoring
RESET button		Yes, with the TEST/RESET button
STOP button		No
Protection and operation of explosion-proof motors		
EC type test certificate number according to directive 94/9/EC (ATEX)		PTB 05 ATEX 3022 ( II (2) GD, see http://support.automation.siemens.com/WW/view/en/23115758
Ambient temperatures		
Storage/transport	°C	-40 +80
Operation	°C	-25 +60
Temperature compensation	°C	+60
<ul> <li>Permissible rated current</li> <li>Temperature inside control cabinet 60 °C</li> <li>Temperature inside control cabinet 70 °C</li> </ul>	%	100 On request
Degree of protection acc. to IEC 60529	/3	IP20: Current measuring modules in sizes S6 and S10/S12 with busbar connection in conjunction with cover.
Touch protection acc. to IEC 61140		Finger-safe: Current measuring modules in sizes S6 and S10/S12 with busbar connection in conjunction with cover.
Shock resistance with sine acc. to IEC 60068-2-27	g/ms	15/11
Electromagnetic compatibility (EMC) – Interference immun	ity	
<ul> <li>Conductor-related interference</li> <li>Burst acc. to IEC 61000-4-4 (corresponds to degree of severity 3)</li> </ul>	kV	2 (power ports), 1 (signal port)
- Surge acc. to IEC 61000-4-5 (corresponds to degree of severity 3)	kV	2 (line to earth), 1 (line to line)
Electrostatic discharge according to IEC 61000-4-2 (corresponds to degree of severity 3)	kV	8 (air discharge), 6 (contact discharge)
Field-related interference according to IEC 61000-4-3 (corresponds to degree of severity 3)	V/m	10
Electromagnetic compatibility (EMC) – emitted interference	е	Degree of severity A according to EN 55011 (CISPR 11) and EN 55022 (CISPR 22)

### 3RB22, 3RB23 up to 630 A for High-Feature applications

Type – Overload relay: evaluation modules Size contactor Dimensions of evaluation modules (W x H x D)	mm	<b>3RB2283-4A.1</b> S00 S10/S12 45 x 111 x 95
General data (continued)		
Resistance to extreme climates – air humidity	%	100
Dimensions		"Dimensional drawings", see  Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297  Product data sheet, http://support.automation.siemens.com/WW/view/en/20357046/133200
Installation altitude above sea level	m	Up to 2 000
Mounting position		Any
Type of mounting  • Evaluation modules	0:	Stand-alone installation
Current measuring module	Size	S00 to S3: Stand-alone installation, S6 and S10/S12: stand-alone installation or mounting onto contactors
Torre Occasional relative evaluation are dules		ODD0000 44 4 ODD0000 44 4

Type – Overload relay: evaluation modules		3RB2283-4A.1, 3RB2383-4A.1
Size contactor		S00 S10/S12
Auxiliary circuit		
Number of NO contacts		2
Number of NC contacts		2
Number of CO contacts		
Auxiliary contacts – assignment		Alternative 1  1 NO for the signal "tripped by overload and/or thermistor"  1 NC for disconnecting the contactor  1 NO for the signal "tripped by ground fault"  1 NC for disconnecting the contactor  or 1)  Alternative 2  1 NO for the signal "tripped by overload and/or thermistor and/or ground fault"  1 NC for disconnecting the contactor  1 NO for overload warning  1 NC for disconnecting the contactor
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	300
Rated impulse withstand voltage U <sub>imp</sub>	kV	4
Auxiliary contacts – contact rating		
<ul> <li>NC contact with alternating current AC-14/AC-15, rated operational current I<sub>e</sub> at U<sub>e</sub> <ul> <li>24 V</li> <li>120 V</li> <li>125 V</li> <li>250 V</li> </ul> </li> <li>NO contact with alternating current AC-14/AC-15, rated operational current I<sub>e</sub> at U<sub>e</sub> <ul> <li>24 V</li> <li>120 V</li> <li>125 V</li> <li>250 V</li> </ul> </li> <li>NC contact, NO contact with direct current DC-13, rated operational current I<sub>e</sub> at U<sub>e</sub> <ul> <li>24 V</li> <li>250 V</li> </ul> </li> </ul>	A A A A A A A A	6 6 6 3 6 6 6 6 6 3
- 24 V - 60 V - 110 V - 125 V - 250 V	A A A A	2 0.55 0.3 0.3 0.2
$ullet$ Conventional thermal current $I_{ m th}$	Α	5
Contact reliability (suitability for PLC control; 17 V, 5 mA)		Yes
Short-circuit protection		
With fuse, operational class gG	Α	6
With miniature circuit breaker, C characteristic	Α	1.6
Protective separation between auxiliary current paths acc. to IEC 60947-1	V	300
CSA, UL, UR rated data		
Auxiliary circuit – switching capacity		B300, R300

The assignment of auxiliary contacts may be influenced by function expansion modules.

### 3RB22, 3RB23 up to 630 A for High-Feature applications

Type – Overload relay: evaluation modules		3RB2283-4A.1, 3RB2383-4A.1
Size contactor		S00 S10/S12
Control circuit		
<b>Rated insulation voltage </b> <i>U</i> <sub>i</sub> (pollution degree 3)	V	300
Rated impulse withstand voltage $U_{\rm imp}$	kV	4
Rated control supply voltage U <sub>s</sub>		
• 50/60 Hz AC	V	24 240
• DC	V	24 240
Operating range		
• 50/60 Hz AC		$0.85 \times U_{\text{s min}} \le U_{\text{s}} \le 1.1 \times U_{\text{s max}}$
• DC		$0.85 \times U_{\text{s min}} \le U_{\text{s}} \le 1.1 \times U_{\text{s max}}$
Rated power		
• 50/60 Hz AC	W	0.5
• DC	W	0.5
Mains buffering time	ms	200
Sensor circuit		
Thermistor motor protection (PTC thermistor sensor)		
Summation cold resistance	kΩ	≤ 1.5
Response value	kΩ	3.4 3.8
Return value	kΩ	1.5 1.65
Ground-fault detection		The information refers to sinusoidal residual currents at 50/60 Hz.
$\bullet$ Tripping value $I_{\Delta}^{-1})$ - For 0.3 × $I_{\rm e}$ < $I_{\rm motor}$ < 2.0 × $I_{\rm e}$ - For 2.0 × $I_{\rm e}$ < $I_{\rm motor}$ < 8.0 × $I_{\rm e}$		$> 0.3 \times I_{\rm e}$ $> 0.15 \times I_{\rm motor}$
• Response time $t_{\text{trip}}$	ms	500 1 000
Analog output <sup>1)2)</sup>		
Rated values		
Output signal	mA	4 20
Measuring range		0 1.25 $\times$ $I_{\rm e}$ 4 mA corresponds to 0 $\times$ $I_{\rm e}$ 16.8 mA corresponds to 1.0 $\times$ $I_{\rm e}$ 20 mA corresponds to 1.25 $\times$ $I_{\rm e}$
• Load, max.	Ω	100
Conductor cross-sections for the auxiliary, contro sensor circuit as well as the analog output	ol and	
Connection type		Screw terminals
Terminal screw		M3, Pozidriv size 2
Operating devices	mm	3.0 x 0.5
Prescribed tightening torque	Nm	0.8 1.2
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded		$1 \times (0.5 \dots 4)^{3)}, 2 \times (0.5 \dots 2.5)^{3)}$
<ul> <li>Finely stranded without end sleeve</li> </ul>	mm <sup>2</sup>	
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	$1 \times (0.5 \dots 2.5)^{3)}, 2 \times (0.5 \dots 1.5)^{3)}$
AWG cables, solid or stranded	AWG	2 × (20 14)
Connection type		Spring-type terminals
Operating devices	mm	$3.0 \times 0.5$
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded	mm <sup>2</sup>	2 × (0.25 1.5)
• Finely stranded without end sleeve	$\text{mm}^2$	
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	2 × (0.25 1.5)
<ul> <li>AWG cables, solid or stranded</li> </ul>	AWG	2 × (24 16)

<sup>1)</sup> For the 3RB22 and 3RB23 overload relays in combination with a corresponding function expansion module.

<sup>2)</sup> Analog input modules, e.g. SM 331, must be configured for 4-wire measuring transducers. In this case the analog input module must not supply current to the analog output of the 3RB22 and 3RB23 relay.

<sup>3)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

### 3RB22, 3RB23 up to 630 A for High-Feature applications

### Selection and ordering data

### Functions of the 3RB22 and 3RB23 evaluation modules in combination with the 3RB2985 function expansion modules

Evaluation modules	With function expansion module	Basic functions	Inputs A1/A2	T1/T2	Y1/Y2
3RB2283-4AA1 3RB2283-4AC1 3RB2383-4AA1		Inverse-time delayed protection, temperature-dependent protection, electrical remote RESET, overload warning	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET
3RB2383-4AC1	3RB2985-2CA1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, overload warning	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET
	3RB2985-2CB1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, ground-fault signal	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET
	3RB2985-2AA0	Inverse-time delayed protection, temperature-dependent protection, electrical remote RESET, overload warning, analog output	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET
	3RB2985-2AA1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, overload warning, analog output	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET
	3RB2985-2AB1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, ground-fault signal, analog output	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET

Evaluation modules	With function	Outputs				
	expansion module	I (-) / I (+)	95/96 NC	97/98 NO	05/06 NC	07/08 NO
3RB2283-4AA1 3RB2283-4AC1 3RB2383-4AA1 3RB2383-4AC1		No	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection)	Signal "tripped"	Overload warning	Overload warning
	3RB2985-2CA1	No	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection + ground fault)	Signal "tripped"	Overload warning	Overload warning
	3RB2985-2CB1	No	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection)	Signal "tripped"	Disconnection of the contactor (ground fault)	Signal "ground-fault tripping"
	3RB2985-2AA0	Analog signal	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection)	Signal "tripped"	Overload warning	Overload warning
	3RB2985-2AA1	Analog signal	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection + ground fault)	Signal "tripped"	Overload warning	Overload warning
	3RB2985-2AB1	Analog signal	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection)	Signal "tripped"	Disconnection of the contactor (ground fault)	Signal "ground-fault tripping"

3RB22, 3RB23 up to 630 A for High-Feature applications

# 3RB22 and 3RB23 electronic overload relays (evaluation modules) for full motor protection, stand-alone installation, CLASS 5, 10, 20 and 30 (adjustable)

Туре	3RB2283-4A.1, 3RB2383-4A.1
Features and technical specifications	
Overload protection, phase failure protection and unbalance protection	✓
Supplied from an external voltage	24 240 V AC/DC
Auxiliary contacts	2 NO + 2 NC
Electrical remote RESET integrated	✓
Four LEDs for operating and status displays	✓
TEST function and self-monitoring	✓
Internal ground-fault detection	(with function expansion module)
Screw or spring-type terminals for auxiliary, control and sensor circuits	✓
Input for PTC sensor circuit	✓
Analog output	(with function expansion module)

✓ Available

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41G \end{array}$ 





3RB2283-4AA1, 3RB2383-4AA1

3RB2283-4AC1, 3RB2383-4AC1

Size contactor	Version	DT	Screw terminals	<b></b>	DT	Spring-type terminals	
				rice PU		Article No.	Price per PU
Evaluation modules							
S00 S12	Monostable	<b></b>	3RB2283-4AA1		▶	3RB2283-4AC1	
	Bistable	•	3RB2383-4AA1		<b></b>	3RB2383-4AC1	

### Note:

Overview of overload relays – matching contactors, see page 7/93.

Current measuring modules and related connecting cables, see page 7/152, general accessories, see page 7/154 onwards.

### SIRIUS 3RB2 Electronic Overload Relays

### 3RB22, 3RB23 up to 630 A for High-Feature applications

### Function expansion modules for 3RB22 and 3RB23 overload relays (evaluation modules)

	Size contactor	Version	For overload relays	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Sizes S00 to S12									
		For plugging into evaluation module (1 unit)							
	S00 S12	Analog Basic 1 modules <sup>1)</sup> Analog output DC 4 20 mA, with overload warning	3RB22, 3RB23	•	3RB2985-2AA0		1	1 unit	41F
3RB2985-21		Analog Basic 1 GF modules <sup>1)2)</sup> Analog output DC 4 20 mA, with internal ground-fault detection and overload warning	3RB22, 3RB23	•	3RB2985-2AA1		1	1 unit	41F
		Analog Basic 2 GF modules <sup>1)2)</sup> Analog output DC 4 20 mA, with internal ground-fault detection and overload ground-fault signaling	3RB22, 3RB23	•	3RB2985-2AB1		1	1 unit	41F
		Basic 1 GF modules <sup>2)</sup> with internal ground-fault detection and overload warning	3RB22, 3RB23	•	3RB2985-2CA1		1	1 unit	41F
		Basic 2 GF modules <sup>2)</sup> with internal ground-fault detection and ground-fault signaling	3RB22, 3RB23	•	3RB2985-2CB1		1	1 unit	41F


### Note:

Analog input modules, e.g. SM 331, must be configured for 4-wire measuring transducers. In this case the analog input module must not supply current to the analog output of the 3RB22/3RB23 relay.

- 1) The analog signal DC 4 mA up to 20 mA can be used for operating rotary coil instruments or for feeding into analog inputs of programmable logic controllers.
- 2) The following information on ground-fault protection refers to sinusoidal residual currents at 50/60 Hz:
  - With a motor current of between 0.3 and 2 times the current setting  $I_{\rm e}$ , the unit will trip at a ground-fault current equal to 30 % of the current setting.
  - With a motor current of between 2 and 8 times the current setting  $I_{\rm e}$  the unit will trip at a ground-fault current equal to 15 % of the current setting.
- The response delay amounts to between 0.5 s and 1 s.

### 3RB24 for IO-Link, up to 630 A for High-Feature applications

### Overview



- 1 Plug-in point for operator panel: enables connection of the 3RA6935-0A operator panel.
- ② Motor current and trip class setting: Setting the device to the motor current and to the required trip class dependent on the start-up conditions is easy with the two rotary switches.
- 3 Connecting terminals (removable terminal block): The generously sized terminals permit connection of two conductors with different cross-sections for the auxiliary, control and sensor circuits. Connection is possible with screw connection and alternatively with spring-type connection.
- 4 Test/RESET button: Enables testing of all important device components and functions, plus resetting of the device after a trip when manual RESET is selected.
- (5) Selector switch for manual/automatic RESET: With this switch you can choose between manual and automatic RESET.
- 6 Red LED "OVERLOAD": A continuous red light signals an active overload trip; a flickering led light signals an imminent trip (overload warning).
- Red LED "THERMISTOR": A continuous red light signals an active thermistor trip.
- (8) Red LED "GND FAULT": A continuous red light signals an active ground-fault trip.
- Green LED "DEVICE/IO-Link:
   A continuous green light signals that the device is working correctly, a green flickering light signals the communication through IO-Link.

### SIRIUS 3RB24 evaluation module

The modular 3RB24 electronic overload relay, which is powered via IO-Link (with monostable auxiliary contacts) up to 630 A (up to 820 A possible with a series transformer) have been designed for inverse-time delayed protection of loads with normal and heavy starting ("Function", see Manual "SIRIUS 3RB24 Electronic Overload Relay for IO-Link", http://support.automation.siemens.com/WW/view/en/46165627) against excessive temperature rises due to overload, phase unbalance or phase failure. It comprises an evaluation unit, a current measuring module and a connecting cable.

The evaluation module 3RB24 also offers an engine starter function: The contactors, which are connected via the auxiliary contacts, can also be actuated for operation via IO-Link. In this way, direct, reversing and wye-delta starters up to 630 A (or 830 A) can be connected to the controller wirelessly via the IO-Link controller.

An overload, phase unbalance or phase failure result in an increase of the motor current beyond the set rated motor current.

This current rise is detected by means of the current measuring module (see page 7/152) and electronically evaluated by the evaluation module which is connected to it. The evaluation electronics sends a signal to the auxiliary contacts. The auxiliary contacts then switch off the load by means of a contactor.

The break time depends on the ratio between the tripping current and current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Curves", http://support.automation.siemens.com/WW/view/en/20357046/134300). The "tripped" status is signaled by means of a continuously illuminated red "OVERLOAD" LED and also reported as a group fault via IO-Link.

The LED indicates imminent tripping of the relay due to overload, phase unbalance or phase failure by flickering when the limit current has been violated. This warning can also be reported to the higher-level PLC via IO-Link at the 3RB24 overload relay.

In addition to the described inverse-time delayed protection of loads against excessive temperature rises, the 3RB24 electronic overload relays also allow direct temperature monitoring of the motor windings (full motor protection) by connection with broken-wire interlock of a PTC sensor circuit. With this temperature-dependent protection, the loads can be protected against overheating caused indirectly by reduced coolant flow, for example, which cannot be detected by means of the current alone. In the event of overheating, the devices switch off the contactor, and thus the load, by means of the auxiliary contacts. The "tripped" status is signaled by means of a continuously illuminated "THERMISTOR" LED and also reported as a group fault via IO-Link.

To protect the loads against incomplete ground faults due to damage to the insulation, humidity, condensed water, etc., the 3RB24 electronic overload relays offer the possibility of internal ground-fault detection (for details, see Manual "SIRIUS 3RB24 Solid-State Overload Relay for IO-Link", http://support.automation.siemens.com/WW/view/en/46165627, not possible in conjunction with contactor assemblies for wyedelta starting). In the event of a ground fault, the 3RB24 relays trip instantaneously.

The "tripped" status is signaled by means of a flashing red LED "Ground Fault" and reported at the overload relay 3RB24 as a group fault via IO-Link.

The reset after overload, phase unbalance, phase failure, thermistor or ground-fault tripping is performed manually by key on site, via IO-Link or by electrical remote RESET or automatically after the cooling time (motor model) or for thermistor protection after sufficient cooling. Power cuts in devices due to function monitors (broken wire or short-circuit on the thermistor) can only be reset on-site ("Function", see Manual "SIRIUS 3RB24 Solid-State Overload Relay for IO-Link", http://support.automation.siemens.com/WW/view/en/46165627).

In conjunction with a function expansion module, the motor current measured by the microprocessor can be output in the form of an analog signal DC 4 to 20 mA for operating rotary coil instruments or for feeding into analog inputs of programmable logic controllers.

The current values can be transmitted to the higher-level controller via IO-Link.

The 3RB24 electronic overload relay for IO-Link is suitable for operation with frequency converters. Please follow the instructions in the manual "SIRIUS 3RB24 Solid-State Overload Relay for IO-Link", see

http://support.automation.siemens.com/WW/view/en/46165627.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

### SIRIUS 3RB2 Electronic Overload Relays

### 3RB24 for IO-Link, up to 630 A for High-Feature applications

### Use in hazardous areas

The 3RB24 electronic overload relays for IO-Link with the 3RB29 current measuring module are suitable for the overload protection of motors with the following types of protection:

- 🔊 II (2) G [Ex e] [Ex d] [Ex px]
- 😥 II (2) D [Ex t] [Ex p]

EC type test certificate for Group II, Category (2) G/D exists. It has the number PTB 11 ATEX 3014.

### Article No. scheme

Digit of the Article No.	1st - 3rd	4th	5th	6th	7th		8th	9th	10th	11th	
						-					
Electronic overload relays	3 R B										
SIRIUS 2nd generation		2									
Device series											
Size, rated operational current and power											
Version of the automatic RESET, electrical remote RESET											
Trip class (CLASS)											
Setting range of the overload release											
Connection methods											
Installation type											
Example	3 R B	2	4	8	3	-	4	Α	Α	1	

### Note:


The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

### Benefits

The most important features and benefits of the 3RB24 electronic overload relays for IO-Link are listed in the overview table (see "General Data", page 7/87 onwards).

### Advantages through energy efficiency



Overview of the energy management process

We offer you a unique portfolio for industrial energy management, using an energy management system that helps to optimally define your energy needs. We split up our industrial energy management into three phases – identify, evaluate, and realize – and we support you with the appropriate hardware and software solutions in every process phase.

The innovative products of the SIRIUS industrial controls portfolio can also make a substantial contribution to a plant's energy efficiency (see www.siemens.com/sirius/energysaving).

3RB24 electronic overload relays for IO-Link contribute to energy efficiency throughout the plant as follows:

- Transmission of current values
- Reduced inherent power loss
- Less heating of the control cabinet
- Smaller control cabinet air conditioners can be used

### Application

### Industries

The 3RB24 electronic overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed and temperature-dependent protection of their electrical loads (e.g. motors) under normal and heavy starting conditions (CLASS 5 to 30), minimize project completion times, inventories and energy consumption, and optimize plant availability and maintenance management.

### Application

The 3RB24 electronic overload relays have been designed for the protection of three-phase asynchronous and single-phase AC motors.

In addition to protection function, these devices can be used together with contactors as direct or reversing starters (star-delta (wye-delta) start also possible), which are controlled via IO-Link. This makes it possible to directly control drives via IO-Link from a higher-level controller or on site via the optional

hand-held device lamps and also, for example, to return current values directly via IO-Link.

If single-phase AC motors are to be protected by the 3RB24 electronic overload relays, the main current paths of the current measuring modules must be series-connected ("Circuit Diagrams", see Manual

"SIRIUS 3RB24 Solid-State Overload Relay for IO-Link", http://support.automation.siemens.com/WW/view/en/46165627).

### Ambient conditions

The devices are insensitive to external influences such as shocks, corrosive ambient conditions, ageing and temperature fluctuations.

For the temperature range from -25 C to +60 °C, the 3RB24 electronic overload relays compensate the temperature in accordance with IEC 60947-4-1.

Configuration notes for use of the devices below -25  $^{\circ}\text{C}$  or above +60  $^{\circ}\text{C}$  on request.

### 3RB24 for IO-Link, up to 630 A for High-Feature applications

### Technical specifications

Touch protection acc. to IEC 61140

Shock resistance with sine acc. to IEC 60068-2-27

The following technical information is intended to provide an initial overview of the various types of device and functions.

### Detailed information, see

- Manual "SIRIUS 3RB24 Solid-State Overload Relay for IO-Link",
  - http://support.automation.siemens.com/WW/view/en/46165627
- or specific information on a particular article number via the product data sheet, http://support.automation.siemens.com/WW/view/en/20357046/133200

Type – Overload relay: evaluation modules		3RB2483-4A.1
Size contactor		S00 S10/S12
Dimensions of evaluation modules (W x H x D)	mm	45 x 111 x 95
\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \		
General data		
Trips in the event of		Overload, phase failure and phase unbalance (> 40 % according to NEMA), + ground fault (connectable and disconnectable) and activation of the thermistor motor protection (with closed PTC sensor circuit)
Trip class acc. to IEC 60947-4-1	CLASS	5, 10, 20 and 30 adjustable
Phase failure sensitivity		Yes
Overload warning		Yes, from 1.125 × $I_{\rm e}$ for symmetrical loads and from 0.85 × $I_{\rm e}$ for unsymmetrical loads
Reset and recovery		
Reset options after tripping		Manual and automatic RESET, electrical remote RESET or through IO-Link
Recovery time		
- For automatic RESET - For manual RESET	min.	<ul> <li>for tripping due to overcurrent: 3 (stored permanently)</li> <li>for tripping by thermistor: time until the motor temperature has fallen 5 K below the response temperature</li> <li>for tripping due to a ground fault: no automatic RESET</li> <li>for tripping due to overcurrent: 3 (stored permanently)</li> </ul>
	111111.	<ul> <li>for tripping by thermistor: time until the motor temperature has fallen 5 K below the response temperature</li> <li>for tripping due to a ground fault: Immediately</li> </ul>
- For remote RESET	min.	<ul> <li>for tripping due to overcurrent: 3 (stored permanently)</li> <li>for tripping by thermistor: time until the motor temperature has fallen 5 K below the response temperature</li> <li>for tripping due to a ground fault: Immediately</li> </ul>
Features		,
Display of operating state on device		Yes, with 4 LEDs: Green "DEVICE/IO-Link" LED Red LED "Ground Fault" Red LED "Thermistor" Red "Overload" LED
TEST function		Yes, test of LEDs, electronics, auxiliary contacts and wiring of control circuit by pressing the button TEST/RESET / self-monitoring
RESET button		Yes, with the TEST/RESET button
STOP button		No
Protection and operation of explosion-proof motors		
EC type test certificate number according to directive 94/9/EC (ATEX)		PTB 11 ATEX 3014  □ II (2) G [Ex e] [Ex d] [Ex px]  □ II (2) G [Ex t] [Ex p],  see  http://support.automation.siemens.com/WW/view/en/60524083
Ambient temperatures		
Storage/transport	°C	-40 +80
• Operation	°C	-25 +60
Temperature compensation	°C	+60
Permissible rated current		
- Temperature inside control cabinet 60 °C	%	100
- Temperature inside control cabinet 70 °C	%	On request
Degree of protection acc. to IEC 60529		IP20: Current measuring modules in sizes S6 and S10/S12 with busbar connection in conjunction with the cover

conjunction with the cover

g/ms

15/11

Finger-safe: Current measuring modules in sizes S6 and S10/S12 with busbar connection in conjunction with the cover

### SIRIUS 3RB2 Electronic Overload Relays

### 3RB24 for IO-Link, up to 630 A for High-Feature applications

- • • • • • • • •		
Type – Overload relay: evaluation modules	_	3RB2483-4A.1
Size contactor	<u> </u>	S00 S10/S12
Dimensions of evaluation modules	✓ mm	45 x 111 x 95
(W x H x D)	1	
General data (continued)		
Electromagnetic compatibility (EMC) - Interference immu	ınity	
Conductor-related interference		
- Burst acc. to IEC 61000-4-4 (corresponds to degree of severity 3)	kV	2 (power ports), 1 (signal ports)
- Surge acc. to IEC 61000-4-5 (corresponds to degree of severity 3)	kV	2 (line to earth), 1 (line to line)
Electrostatic discharge according to IEC 61000-4-2 (corresponds to degree of severity 3)	kV	8 (air discharge), 6 (contact discharge)
Field-related interference according to IEC 61000-4-3 (corresponds to degree of severity 3)	V/m	10
Electromagnetic compatibility (EMC) - emitted interferen	ce	Degree of severity A according to EN 55011 (CISPR 11) and EN 55022 (CISPR 22)
Resistance to extreme climates – air humidity	%	100
Dimensions		"Dimensional drawings", see  • Manual "SIRIUS 3RB24 Solid-State Overload Relay for IO-Link", http://support.automation.siemens.com/WW/view/en/46165627  • Product data sheet
		http://support.automation.siemens.com/WW/view/en/20357046/133200
Installation altitude above sea level	m	Up to 2 000
Mounting position		Any
Type of mounting		
Evaluation modules		Stand-alone installation
Current measuring module	Size	S00 to S3: Stand-alone installation, S6 and S10/S12: stand-alone installation or mounting onto contactors

### 3RB24 for IO-Link, up to 630 A for High-Feature applications

Type – Overload relay: evaluation modules		3RB2483-4A.1
Size contactor		S00 S10/S12
Auxiliary circuit		
Number of auxiliary switches		1 CO contact, 1 NO contact connected in series internally
Auxiliary contacts – assignment		<ul> <li>1 CO contact for selecting the contactor (for reversing starter function), actuated by the control system</li> <li>1 NO contact for normal switching duty, actuated by the control system</li> </ul>
		(opens automatically when tripping occurs)
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	300
Rated impulse withstand voltage $U_{\rm imp}$	kV	4
Auxiliary contacts – contact rating		
<ul> <li>NC contact with alternating current AC-14/AC-15, rated operational current I<sub>e</sub> at U<sub>e</sub></li> <li>24 V</li> <li>120 V</li> <li>125 V</li> <li>250 V</li> </ul>	A A A	6 6 6 3
NO contact with alternating current AC-14/AC-15, rated operational current $I_e$ at $U_e$ 24 V 120 V 125 V 250 V  NC contact, NO contact with direct current DC-13,	A A A	6 6 6 3
rated operational current $I_{\rm e}$ at $U_{\rm e}$ = 24 V = 60 V = 110 V = 125 V = 250 V	A A A A	2 0.55 0.3 0.3 0.2
$ullet$ Conventional thermal current $I_{th}$	Α	5
Contact reliability (suitability for PLC control; 17 V, 5 mA)		Yes
Short-circuit protection		
<ul> <li>With fuse, operational class gG</li> </ul>	Α	6
<ul> <li>With miniature circuit breaker, C characteristic</li> </ul>	Α	1.6
Protective separation between auxiliary current paths acc. to IEC 60947-1	V	300
CSA, UL, UR rated data		
Auxiliary circuit – switching capacity		B300, R300
Conductor cross-sections of the auxiliary circuit		
Connection type		Screw terminals
Terminal screw		M3, Pozidriv size 2
Operating devices	mm	3.0 x 0.5
Prescribed tightening torque	Nm	0.8 1.2
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected	_	
Solid or stranded	mm <sup>2</sup>	$1 \times (0.5 \dots 4)^{1)}, 2 \times (0.5 \dots 2.5)^{1)}$
Finely stranded without end sleeve	mm <sup>2</sup>	
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	$1 \times (0.5 \dots 2.5)^{1)}, 2 \times (0.5 \dots 1.5)^{1)}$
AWG cables, solid or stranded	AWG	2 × (20 14)
Connection type		Spring-type terminals
Operating devices	mm	3.0 x 0.5
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded	mm <sup>2</sup>	2 × (0.25 1.5)
<ul> <li>Finely stranded without end sleeve</li> </ul>	mm <sup>2</sup>	-
<ul> <li>Finely stranded with end sleeve (DIN 46228-1)</li> </ul>	mm <sup>2</sup>	2 × (0.25 1.5)
AWG cables, solid or stranded	AWG	2 × (24 16)

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

### SIRIUS 3RB2 Electronic Overload Relays

### 3RB24 for IO-Link, up to 630 A for High-Feature applications

Time Overland valous evaluation modules		2000402 44 4
Type – Overload relay: evaluation modules		3RB2483-4A.1
Size contactor		S00 S10/S12
Control circuit		
Rated insulation voltage $U_i$ (pollution degree 3)	V	300
Rated impulse withstand voltage $U_{\rm imp}$	kV	4
Rated control supply voltage $U_s^{-1}$		
• DC	V	24 through IO-Link
Operating range		
• DC		$0.85 \times U_{\text{s min}} \leq U_{\text{s}} \leq 1.1 \times U_{\text{s max}}$
Rated power		
• DC	W	0.5
Mains buffering time	ms	200
Sensor circuit		
Thermistor motor protection (PTC thermistor sensor)		
Summation cold resistance	$k\Omega$	≤ 1.5
Response value	$k\Omega$	3.4 3.8
Return value	$k\Omega$	1.5 1.65
Ground-fault detection		The information refers to sinusoidal residual currents at 50/60 Hz.
$ullet$ Tripping value $I_{\Delta}$		
- For 0.3 × $I_{\rm e}$ < $I_{\rm motor}$ < 2.0 × $I_{\rm e}$ - For 2.0 × $I_{\rm e}$ < $I_{\rm motor}$ < 8.0 × $I_{\rm e}$		$> 0.3 \times I_{\rm e}$ $> 0.15 \times I_{\rm motor}$
	200.0	
• Response time t <sub>trip</sub>	ms	500 1 000
Analog output <sup>1)</sup>		
Rated values		4 00
Output signal	mA	4 20
Measuring range		0 1.25 $\times$ $I_{\rm e}$ 4 mA corresponds to 0 $\times$ $I_{\rm e}$ 16.8 mA corresponds to 1.0 $\times$ $I_{\rm e}$ 20 mA corresponds to 1.25 $\times$ $I_{\rm e}$
• Load, max.	Ω	100
Conductor cross-sections for the control and sensor circuit as well as the analog output		
Connection type		Screw terminals
Terminal screw		M3, Pozidriv size 2
Operating devices	mm	3.0 x 0.5
Prescribed tightening torque	Nm	0.8 1.2
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
• Solid	$\text{mm}^2$	$1 \times (0.5 \dots 4)^{2}$ , $2 \times (0.5 \dots 2.5)^{2}$
Finely stranded without end sleeve	$\text{mm}^2$	
• Finely stranded with end sleeve (DIN 46228-1)		$1 \times (0.5 \dots 2.5)^{2)}, 2 \times (0.5 \dots 1.5)^{2)}$
• Stranded	$\text{mm}^2$	<del>-</del>
AWG cables, solid or stranded	AWG	2 × (20 14)
Connection type		Spring-type terminals
Operating devices	mm	3.0 x 0.5
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
• Solid	mm <sup>2</sup>	2 × (0.25 1.5)
Finely stranded without end sleeve	$\text{mm}^2$	
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 × (0.25 1.5)
• Stranded	mm <sup>2</sup>	2 × (0.25 1.5)
AWG cables, solid or stranded	AWG	2 × (24 16)
1) Analog input modules, e.g. SM 331, must be configured for 4-wire measing		,

<sup>1)</sup> Analog input modules, e.g. SM 331, must be configured for 4-wire measuring transducers. The analog input module may not supply current to the analog output of the 3RB24 overload relay.

If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

3RB24 for IO-Link, up to 630 A for High-Feature applications

### Selection and ordering data

# 3RB24 electronic overload relays (evaluation modules) for full motor protection, stand-alone installation, CLASS 5, 10, 20 and 30 (adjustable)

Туре	3RB2483-4A.1
Features and technical specifications	
Overload protection, phase failure protection and unbalance protection	✓
Supplied from an external voltage	✓ 24 V DC through IO-Link
Direct-on-line or reversing starters (wye-delta starting also possible) controllable through IO-Link	✓
Auxiliary contacts	1 CO and 1 NO in series
Manual and automatic RESET	✓
Remote RESET	√ (electrically or via IO-Link)
Four LEDs for operating and status displays	✓
TEST function and self-monitoring	✓
Internal ground-fault detection	✓
Screw or spring-type terminals for auxiliary, control and sensor circuits	✓
Input for PTC sensor circuit	✓
Analog output	✓
IO-Link-specific functions	
• Connection of direct-on-line, reversing and star-delta starters to the controller via IO-Link	✓
On-site controlling of the starter using the hand-held device	✓
• Accessing process data (e.g. current values in all three phases) via IO-Link	✓
• Accessing parameterization and diagnostics data (e.g. tripped signals) via IO-Link	✓

✓ Available

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41G \end{array}$ 





3RB2483-4AA1

3RB2483-4AC1

Size contactor	Version	DT	Screw terminals	DT DT		Spring-type terminals	<u> </u>
			Article No.	Article No. Price per PU		Article No.	Price per PU
Evaluation modules							
S00 S12	Monostable	<b>&gt;</b>	3RB2483-4AA1		Α	3RB2483-4AC1	

### Notes:

- Overview of overload relays matching contactors, see page 7/93.
- Analog input modules, e.g. SM 331, must be configured for 4-wire measuring transducers. The analog input module may not supply current to the analog output of the 3RB24 relay.

Current measuring modules and related connecting cables, see page 7/152 onwards, "Accessories", see page 7/153 onwards.

### SIRIUS 3RB2 Electronic Overload Relays

### Current measuring modules for 3RB22, 3RB23, 3RB24

### Overview



The current measuring modules are designed as system components for connecting to evaluation units 3RB22 to 3RB24. Using these evaluation units the motor current is measured and the measured value sent to the evaluation unit for evaluation.

The current measuring modules in sizes up to S3 are equipped with straight-through transformers and can be snap-fitted under the evaluation units. The larger evaluation units are installed directly on the contactor or as stand-alone units.

SIRIUS 3RB2906 current measuring module

### Technical specifications

The following technical information is intended to provide an initial overview of the various types of device and functions.

Detailed information, see Reference Manual "Protection Equipment - Overload Relays 3RU1, 3RB2", http://support.automation.siemens.com/WW/view/en/35681297

Type – Overload relays: Current measuring modules	1	3RB2906		3RB2956	3RB2966		
Size contactor		S00/S0	S2/S3	S6	S10/S12		
Dimensions of current measuring modules (W x H x D)	mm		55 x 94 x 72	? 120 x 119 x 145	145 x 147 x 148		
Main circuit							
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	1 000					
Rated impulse withstand voltage $U_{imp}$	kV	6		8			
Rated operational voltage $U_{\rm e}$	V	1 000					
Type of current							
Direct current		No					
Alternating current		Yes, 50/60 H	z ± 5 %				
Current setting	А	0.3 3; 2.4 25	10 100	20 200	63 630		
Power loss per unit (max.)	W	0.5					
Short-circuit protection							
With fuse without contactor		See "Selection	on and ordering	ng data" on page 7/18	52		
With fuse and contactor		See configur	ation manual	S			
		Fused Load	d Feeders",	ovations - Selection I n.siemens.com/WW/v	Data for Fuseless and view/en/50250039		
		<ul> <li>"SIRIUS Configuration – Selection Data for Fuseless Load Feeders", http://support.automation.siemens.com/WW/view/en/68115041</li> </ul>					
Protective separation between main and auxiliary current paths acc. to IEC 60947-1 (pollution degree 2)	3						
<ul> <li>For systems with grounded neutral point</li> </ul>	V	690					
<ul> <li>For systems with ungrounded neutral point</li> </ul>	V	600					

### Current measuring modules for 3RB22, 3RB23, 3RB24

Time Overland valeries		2DD0000		2DD2056	appace
Type – Overload relays: Current measuring modules		3RB2906		3RB2956	3RB2966
Size contactor		S00/S0	S2/S3	S6	S10/S12
Dimensions of current measuring modules	mm o mm	45 x 84 x 45	55 x 94 x 72	120 x 119 x 145	145 x 147 x 148
(W x H x D)  Conductor cross-sections of main circuit	<del></del> //				
Connection type		Screw	terminals wit	th box terminal	
Commodular type		Screw	torrinato w	ar box torrillia	
Terminal screw	mm			4 mm Allen screw	5 mm Allen screw
Operating devices	mm			4 mm Allen screw	5 mm Allen screw
Prescribed tightening torque	Nm			10 12	20 22
Conductor cross-sections (min./max.), 1 or 2 cond • Solid or stranded	mm <sup>2</sup>			With 3RT1955-4G box terminal: 2 × (max. 70), 1 × (16 70) With 3RT1956-4G box terminal:	2 × (70 240), Rear clamping point only: 1 × (95 300) Rear clamping point only:
Finely stranded without end sleeve	mm <sup>2</sup>	_		2 × (max. 120), 1 × (16 120) With 3RT1955-4G box terminal: 2 × (1 × max. 50, 1 × max. 70), 1 × (10 70) With 3RT1956-4G box terminal:	1 × (120 240)  2 × (50 185), Rear clamping point only: 1 × (70 240)  Rear clamping point only:
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>			2 × (1 × max. 95, 1 × max. 120), 1 × (10 120) With 3RT1955-4G box terminal: 2 × (1 × max. 50, 1 × max. 70), 1 × (10 70) With 3RT1956-4G box terminal:	1 × (120 185)  2 × (50 185), Rear clamping point only: 1 × (70 240)  Rear clamping point only:
• AWG cables	AWG			2 × (1 × max. 95, 1 × max. 120), 1 × (10 120) With 3RT1955-4G box terminal: 2 × (max. 1/0), 1 × (6 2/0) With 3RT1956-4G box terminal: 2 × (max. 3/0),	1 × (120 185)  2 × (2/0 500 kcmil), rear clamping point only: 1 × (3/0 600 kcmil)  Rear clamping point only: 1 ×
• Ribbon cables (Number x Width x Thickness)	mm			$1 \times (6 \dots 250 \text{ kcmil})$ With 3RT1955-4G box terminal: $2 \times (6 \times 15.5 \times 0.8)$ , $1 \times (3 \times 9 \times 0.8 \dots 6 \times 15.5 \times 0.8)$ With 3RT1956-4G box terminal: $2 \times (10 \times 15.5 \times 0.8)$ , $1 \times (3 \times 9 \times 0.8 \dots 6 \times 15.5 \times 0.8)$ , $1 \times (3 \times 9 \times 0.8 \dots 6 \times 15.5 \times 0.8)$ , $1 \times (3 \times 9 \times 0.8 \dots 6 \times 15.5 \times 0.8)$	(250 kcmil 500 kcmil) 2 × (20 × 24 × 0.5), 1 × (6 × 9 × 0.8 20 × 24 × 0.5)
Connection type		oo Busba	r connection	s	
Terminal screw				M8 × 25	M10 x 30
Prescribed tightening torque	Nm			10 14	14 24
Conductor cross-sections (min./max.), 1 or 2 cond					
Solid with cable lug	mm <sup>2</sup>			16 95 <sup>1)</sup>	50 240 <sup>2)</sup>
Stranded with cable lug	mm <sup>2</sup>			25 120 <sup>1)</sup>	70 240 <sup>2)</sup>
AWG cables, solid or stranded, with cable lug	AWG			4 250 kcmil	2/0 500 kcmil
With connecting bars (max. width)	mm			17	25
Connection type			ht-through tra		
6:			4.4	05	
Diameter of opening	mm 35 with conductor	7.5	14	25	 16234 with conductor

When connecting cable lugs according to DIN 46235 with conductor cross-sections of 95 mm<sup>2</sup> and more, the 3RT1956-4EA1 terminal cover must be used to ensure phase clearance.

When connecting cable lugs according to DIN 46234 with conductor cross-sections of 240 mm<sup>2</sup> and more as well as to DIN 46235 with conductor cross-sections of 185 mm<sup>2</sup> and more, the 3RT1956-4EA1 terminal cover must be used to ensure the phase clearance.

### SIRIUS 3RB2 Electronic Overload Relays

### Current measuring modules for 3RB22, 3RB23, 3RB24

### Selection and ordering data

### Current measuring modules (essential accessory)







3RB2906-2JG1



3RB2956-2TG2



3RB2966-2WH2

Size contactor	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>1)</sup>	For overload relays	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
	A	Α							
Sizes S00/S0									
Devices with straight- for stand-alone install		r,							
S00/S0	0.3 3	20	3RB22 to	<b>&gt;</b>	3RB2906-2BG1		1	1 unit	41G
	2.4 25	63	3RB24	<b>&gt;</b>	3RB2906-2DG1		1	1 unit	41G
Sizes S2/S3									
Devices with straight- for stand-alone install		r,							
S2/S3	10 100	315	3RB22 to 3RB24	•	3RB2906-2JG1		1	1 unit	41G
Size S6									
Devices with busbar of for mounting onto con		one installation							
S6	20 200	315	3RB22 to 3RB24	•	3RB2956-2TH2		1	1 unit	41G
Devices with straight- for mounting onto cor									
For mounting onto S6 contactors with box terminals	20 200	315	3RB22 to 3RB24	•	3RB2956-2TG2		1	1 unit	41G
Sizes S10/S12 <sup>2)</sup>									
Devices with busbar of for mounting onto con		one installation							
S10/S12 and size 14 (3TF68/3TF69) <sup>2)</sup>	63 630	800	3RB22 to 3RB24	•	3RB2966-2WH2		1	1 unit	41G

### Note:

The connecting cable between the current measuring module and the evaluation module is not included in the scope of supply; please order separately (see "Accessories").

- Maximum protection by fuse only for overload relay, type of coordination "2". For fuse values in connection with contactors, see Configuration Manuals
  - "Configuring SIRIUS Innovations Selection Data for Fuseless and Fused Load Feeders", http://support.automation.siemens.com/WW/view/en/39714188

  - "SIRIUS Configuration Selection Data for Fuseless Load Feeders", http://support.automation.siemens.com/WW/view/en/40625241.

### Accessories

	Size contactor	Version	For overload relays	DT		Price r PU	PU (UNIT, SET, M)	PS*	PG
Connecting cab	les (neces	sary accessories)							
		For connection between evaluation module and current measuring module							
	S00 S3	Length 0.1 m     (only for mounting of the evaluation module directly onto the current measuring module)	3RB24, 3RB29	•	3RB2987-2B		1	1 unit	41F
3RB2987-2.	S00 S12	• Length 0.5 m	3RB24, 3RB29	<b>&gt;</b>	3RB2987-2D		1	1 unit	41F

Additional general accessories, see page 7/154.

<sup>&</sup>lt;sup>2)</sup> For 3TF68/3TF69 contactors, direct mounting is not possible.

Accessories for 3RB22, 3RB23, 3RB24

### Overview

### Overload relays for High-Feature applications

The following optional accessories are available for the 3RB22 to 3RB24 electronic overload relays:

- Operator panel for the evaluation modules 3RB24
- Manuals, see "More information"
- Sealable cover for the evaluation modules 3RB22 to 3RB24
- Terminal covers for the 3RB29 current measuring modules size S6 and S10/S12
- Box terminal blocks for the 3RB29 current measuring modules size S6 and S10/S12
- Push-in lugs for screw fixing for 3RB22 to 3RB24 evaluation modules and 3RB2906 current measuring modules

### Selection and ordering data

### Accessories for 3RB24 overload relays

	Version	For overload relays	DT	Article No. Pric per Pl		PS*	PG
Operator panels for e	evaluation modules						
3RA6935-0A	Operator panels (set) One set comprises:  • 1 x operator panel • 1 x 3RA6936-0A enabling module • 1 x 3RA6936-0B interface cover • 1 x fixing terminal  Note: The connecting cable between the evaluation module and the operator panel is not included in the scope of supply; please order separately.	3RB24	A	3RA6935-0A	1	1 unit	42F
	Connecting cable Length 2.5 m (round), for connecting the evaluation module to the operator panel	3RB24	•	3UF7933-0BA00-0	1	1 unit	42J
	Enabling modules (replacement)	3RB24	Α	3RA6936-0A	1	1 unit	42F
	Interface covers	3RB24	Α	3RA6936-0B	1	5 units	42F

Additional general accessories, see next page.

### More information

### Manuals

- System Manual "SIRIUS Innovations System Overview" http://support.automation.siemens.com/WW/view/en/60311318
- Manual "SIRIUS 3RB24 Solid-State Overload Relay for IO-Link" http://support.automation.siemens.com/WW/view/en/46165627

### Accessories for 3RB22, 3RB23, 3RB24

### General accessories

	Version		Size	For overload relays	DT	Article No.	Price per PU	PU (UNIT,	PS*	PG
							, ,	SÈT, M)		
Sealable covers	s for evaluation mo	dules								
	For covering the se	tting knobs		3RB22 to 3RB24	<b>&gt;</b>	3RB2984-2		1	10 units	41F
3RB2984-2	- (									
Terminal cover	s for current measu Covers for cable lu		nnootiono					ı		
berthod bod	Length 100 mm	igs and busbar co	S6	3RB2956	•	3RT1956-4EA1		1	1 unit	41B
	Length 120 mm		S10/S12	3RB2966		3RT1966-4EA1		1	1 unit	41B
SIEMENS	Covers for box ter	minals	010/012	01182000		01111000 1EA1			1 dint	110
	• Length 25 mm		S6	3RB2956	<b></b>	3RT1956-4EA2		1	1 unit	41B
DT1050 4544	• Length 30 mm		S10/S12	3RB2966	<b></b>	3RT1966-4EA2		1	1 unit	41B
3RT1956-4EA1	Covers for screw t	erminals between	S6	3RB2956	<b></b>	3RT1956-4EA3		1	1 unit	41B
SIEMENS	contactor and overl	oad relay,	S10/S12		<b></b>	3RT1966-4EA3		1	1 unit	41B
	without box termina (1 unit required per									
3RT1956-4EA2										
Box terminal bl	ocks for current me	-	es					1		
	For round and ribbo	on cables	0.01)	000000						
D n	• Up to 70 mm <sup>2</sup>		S6 <sup>1)</sup>	3RB2956		3RT1955-4G		1	1 unit	41B
	• Up to 120 mm <sup>2</sup>		S6	3RB2956	<b>•</b>	3RT1956-4G		1	1 unit	41B
	• Up to 240 mm <sup>2</sup>		S10/S12			3RT1966-4G		1	1 unit	41B
aprilar 10	For technical specific Manual "Protection E				ence					
3RT1954G	http://support.autor									
Push-in lugs fo	r evaluation module	es and current n	neasurinç	g modules						
	For screw fixing the	evaluation		3RB22 to	В	3RP1903		1	10 units	41H
3RP1903	modules			3RB24						
	For screw fixing the measuring modules (2 units per module	3	S00 S3	3RB2906	Α	3RB1900-0B		100	10 units	41F
3RB1900-0B	` '	,								
1) In the scope of s	supply for 3RT1054-1 co	ntactors (55 kW).								
	Version	Size	Color	For overload	DT	Article No.	Price	PU	PS*	PG
				relays			per PU	(UNIT, SET, M)		
Tools for openi	ng spring-type tern	ninals								
	>					Spring-type terminals	8			
5	Screwdrivers	Length approx.	Titanium	Main and	Α	3RA2908-1A		1	1 unit	41B
	For all SIRIUS	200 mm,	gray/	auxiliary				·		
3RA2908-1A	devices with spring-type	3.0 mm x 0.5 mm	black, partially	circuit connection:						
	terminals		insulated							
Blank labels										
	Unit labeling	20 mm x 7 mm	Pastel	3RB2	D	3RT1900-1SB20		100	340 units	41B
	plates <sup>1)</sup> for SIRIUS devices		turquoise		_					
	ioi oii iioo devices	20 mm x 7 mm	Titanium gray	3RB2	D	3RT2900-1SB20		100	340 units	41B
			gray							
3RT1900-1SB20										
<b></b>										
3RT2900-1SB20										
PC Jahaling eyet	em for individual inscrip	tion of unit labeling	plotos	m	ırrolo	stik Systemtechnik Gml	all			

<sup>1)</sup> PC labeling system for individual inscription of unit labeling plates available from:

murrplastik Systemtechnik GmbH (see Chapter 16, "Appendix"  $\rightarrow$  "External Partners").